
一. 平台侧

1. 登陆及认证(个人账户))阿里云平台: <u>www.aliyun.com,</u>选择"产品"→"物联网"→"物联网设备管理"



2. 创建产品



3. 在"设备"界面,重点关注: ProductKey,DeviceName,DeviceSecret 三个参数;



二. 模组侧--对照《M5310-A MQTT 使用指导》进行参数配置

1. AT+MQTTCFG="a1l8GFyxX9I.iot-as-mqtt.cn-shanghai.aliyuncs.com",1883,"666888|securemode=3,signmethod=hmacsha1|",60,"TEST&a1KYwyQE5Bt","8709fa5458602c0fa1cef8eab01dc14e4b651e7b",0

备注:

"TEST&a1KYwyQE5Bt"对应 deviceName+"&"+productKey,参照平台侧设置更改;


"8709fa5458602c0fa1cef8eab01dc14e4b651e7b"对应哈希加密算法,

在线转换网址: http://encode.chahuo.com/, 操作步骤参考下图, 转换完成后进行替换;




- 2. AT+MQTTOPEN=1,1,0 连接 MQTT 服务器
- 3. AT+MQTTSUB="/a1KYwyQE5Bt/TEST/get",1 订阅 topic

平台侧已有订阅主题,可自定义;



4. AT+MQTTPUB="/a1KYwyQE5Bt/TEST/update",1,0,0,3,"7E7A7A" 发布消息

平台侧已有发布主题,可自定义;



5. 断开连接-销毁参数配置

AT+MQTTDISC 断开连接

AT+MQTTDEL 释放资源,之后可以再次使用+MQTTCFG 进行配置