

Toolkit Doc10 Base Skirts April 30, 2010



Base Skirt Front + Rear R/R

- Base Skirt Front. Removal 1422
 - 1. Remove Front Bottom Panel
 - 2. Using the 4mm bit with the T-handle driver, remove 12 Flathead screws starting at the back working your way to the front. 3063-08 (Fig 1,2)





3. To remove first pull the Skirt sides appart slightly so the tabs clear the rubber standoffs, and then move the Skirt forward. (Fig 3)



- Base Skirt Rear, Removal 1539
 - 1. Using the 4mm bit with the T-handle driver, remove 8 Flathead screws starting at the sides working your way to the rear. 3063-08 (Fig 4,5)





- Base Skirt Front or Rear, Install
 - 1. Reverse the removal procedure.
 - 2. Using Loctite 248, install the screws and torque to 6.34Nm using the Large torque driver.

