
BGM220P Silicon labs

PTSPACE


Create Your First Project

Step 1: Create a project






Step 1: Create a project





Step 2: Choose SL Project Wizard & Finish






Step 3: Target Selection & Next

Target Boards: BGM220 Explorer


Kit Board

Target Device: BGM220PC22HNA






Step 4: Empty C Project & Next





Step 4: Empty C Project & Next





Step 5: Finish

