



TAK Server Configuration Guide

Version 4.10

September 2023

Distribution Statement A: Approved for public release; distribution is unlimited.

1 Table of Contents

1	About TAK Server	4
2	Change Log	4
3	System Requirements	4
	3.1 Server Requirements	4
	3.2 AWS / GovCloud Recommended Instance Type	4
4	Installation	
	4.1 Overview and Installer Files	5
	4.2 New Installation: One Server	7
	4.2.1 TAK Server Installation	7
	4.2.1.1 Rocky Linux 8	7
	4.2.1.2 RHEL 8	8
	4.2.1.3 RHEL 7	9
	4.2.1.4 Ubuntu and Raspberry Pi OS	9
	4.2.1.5 CentOS 7	10
	4.2.2 Configure TAK Server installation	11
	4.3 New Installation: Two Servers	13
	4.3.1 Server One: Database Server	13
	4.3.1.1 Dependency Setup	.13
	4.3.1.1.1 Rocky Linux 8	13
	4.3.1.1.2 RHEL 8	13
	4.3.1.1.3 RHEL 7	14
	4.3.1.1.4 Ubuntu & Raspberry Pi OS	15
	4.3.1.1.5 CentOS 7	16
	4.3.2 Server Two: Core Server	16
	4.3.2.1 Install TAK Server	17
	4.3.2.1.1 Rocky Linux 8	17
	4.3.2.1.2 RHEL 8	17
	4.3.2.1.3 RHEL 7	17
	4.3.2.1.4 Ubuntu & Raspberry Pi OS	18
	4.3.2.1.5 CentOS 7	18
	4.3.2.2 Configuration	19
	4.4 Use Setup Wizard to Configure TAK Server	22
	4.5 Upgrade existing TAK Server installation	23
	4.5.1 Single-Server Upgrade	23
	4.5.1.1 Rocky Linux 8	23
	4.5.1.2 RHEL 8	24
	4.5.1.3 RHEL 7	25
	4.5.1.4 Ubuntu and Raspberry Pi OS	25
	4.5.1.5 Centos 7	26
	4.5.2 Two-Server Upgrade	26
	4.5.2.1 Rocky Linux 8	26
	4.5.2.2 RHEL 8	
	4.5.2.3 RHEL 7	28
	4.5.2.4 Ubuntu and Raspberry Pi OS	

4.5.2.5 Centos 7	30
4.6 Docker Install	32
4.7 Configure System Firewall	38
4.7.1 RHEL, Rocky Linux, and CentOS	38
4.7.2 Ubuntu and Rasapberry Pi	39
4.8 Software Installation Location	39
5 Configuration	39
5.1 Configuring Security through Web UI (Certificates/TLS)	40
5.2 Group Filtering	
5.3 Group Assignment by Input	41
5.3.1 Input Configuration UI	
5.4 Group Assignment Using Authentication Messages	41
5.5 Group Assignment Using Client Certificates	42
5.6 Authentication Backends	43
5.6.1 File-Based	43
5.6.2 Active Directory (AD) / LDAP	43
5.6.3 Configuring LDAP through Web Interface	
5.7 Configuring Messaging and Repository Settings through W	
5.8 Optionally Disabling UI and WebTAK on HTTPS Ports	
5.9 VBM Admin Configuration	46
6 WebTAK	
7 Device Profiles	
8 Federation	
8.1 Enable Federation	
8.2 Upload Federate Certificate	
8.3 Make the Connection	
8.4 Federated Group Mapping	
8.5 Mission Federation Disruption Tolerance	
8.6 Data Package and Mission File Blocker	
8.7 Federation Example	
8.8 Alternate Configuration	
9 Metrics	
10 Logging	
11 Group Filtering for Multicast Networks	
12 OAuth2 Authentication	
13 User Management UI	
14 Data Retention Tool	
Appendix A: Acronyms and Abbreviations	
Appendix B: Certificate Generation	
1 Configure TAK Server Certificate	
2 Installing Client Certificates	
Appendix C: Certificate Signing	
Appendix D: PostgreSQL TLS Configuration	
1 Configure PostgreSQL server to use TLS	
2 Generate Client keys and certificates	
3 Configure TAK Server to use SSL	74

1 About TAK Server

TAK Server is a situational awareness server, that provides a dynamic Common Operating Picture to users of the Team Awareness Kit, including ATAK (Android), WinTAK (Windows) and WebTAK. TAK enables sharing of geolocated information in real time for military forces, law enforcement, and emergency responders. It supports both wireless and wired networks, as well as cloud and data center deployment.

2 Change Log

See https://wiki.tak.gov/display/DEV/TAK+Server+Change+Log

3 System Requirements

Supported Operating Systems:

- Rocky Linux 8 (Replacement for CentOS 8, which is EOL)
- Red Hat Enterprise Linux (RHEL) 8 or 7
- Ubuntu 22
- Raspberry Pi OS (64-bit)
- CentOS 7 (not CentOS 8 Stream)

Java 17 is required. Java 17 is installed by default via package dependencies, but if your system has a different Java version installed in addition to Java 17, ensure that TAK Server is using Java 17.

3.1 Server Requirements

- 4 processor cores
- 8 GB RAM
- 40 GB disk storage

For Raspberry Pi installations, a Pi 4, Model B, Quad-Core 64-bit 8GB RAM version is recommended for a minimal TAK Server setup (TAK Server messaging and api services with local PostgreSQL database)

NOTE: Insecure ports are a potential security risk and may allow attackers to gain access to the system resulting in the disclosure of personal and sensitive information. Use of unencrypted ports should be avoided to ensure a secure TAK Server deployment.

3.2 AWS / GovCloud Recommended Instance Type

- c5.xlarge
 - o 4 vCPU

- o 8 GB RAM
- Up to 10 Gbps network bandwidth
- For 2-server installation, use this instance type for both servers.

TAK Server is a TLS-enabled networking server. In order to ensure consistent performance, burstable AWS EC2 instance types such as T2 are not recommended. TLS and TCP processing requires consistent, continuous CPU performance. C4 and C5 instances are designed for predictable CPU performance, and are better-suited for TAK Server deployments.

More information about instance types may be found here:

https://aws.amazon.com/ec2/instance-types

Usage of larger instance types or physical servers is supported for scalability, to support more concurrent active users.

4 Installation

4.1 Overview and Installer Files

TAK Server supports multiple deployment configurations:

- **Single server install**: One server running TAK Server core (messaging, API, plugins and database): recommended for fewer than 500 users.
- **Two server install**: One server running TAK Server core (messaging, API, plugins and database) and a second server running PostgreSQL database: recommended for more than 500 users.
- **Containerized docker install**: One container running TAK Server core (messaging, API, plugins and database) and another container running PostgreSQL database (designed for operating systems other than CentOS 7 / RHEL 7)

The following installation files are provided:

```
Installer for single-server install
    RHEL/Rocky/CentOS takserver-4.10-RELEASE-x.noarch.rpm
    Ubuntu/RaspPi: takserver_4.10-RELEASE-x_all.deb
```

```
Database installer for two-server install
```

```
RHEL/Rocky/CentOS: takserver-database-4.10-RELEASE-x.noarch.rpm
Ubuntu/RaspPi: takserver-database_4.10-RELEASE-x_all.deb
```

Core installer for two-server install

```
RHEL/Rocky/CentOS: takserver-core-4.10-RELEASE-x.noarch.rpm
Ubuntu/RaspPi: takserver-core 4.10-RELEASE-x all.deb
```

Containerized docker install bundle

takserver-docker-4.10-RELEASE-x.zip

Containerized hardeneded docker install bundle

takserver-docker-hardened-4.10-RELEASE-x.zip

Installer for federation hub (beta)

```
RHEL/Rocky/CentOS: takserver-fed-hub-4.10-RELEASE-x.noarch.rpm
Ubuntu/RaspPi: takserver-fed-hub 4.10-RELEASE-x all.deb
```

Federation hub documentation available here:

https://wiki.tak.gov/display/TPC/Federation+Hub

Verifying GPG signatures on RPM packages

The GPG public key for TAK Server can be found under https://artifacts.tak.gov/ui/repos/tree/General/TAKServer/release/. Select the TAK Server release version and download the file *takserver-public-gpg.key*

Import the key to the RPM key management:

```
> sudo rpm --import takserver-public-gpg.key
```

Verifying signature for the rpm installer package:

```
> rpm --checksig takserver-4.10-RELEASE<version>.noarch.rpm
```

Example of a successful output: takserver-4.10-RELEASE28.noarch.rpm: rsa sha1 (md5) pgp md5 OK Example of a failed output: takserver-4.10-RELEASE28.noarch.rpm: RSA sha1 ((MD5) PGP) md5 NOT OK (MISSING KEYS: (MD5) PGP#6851f5b5)

If the RPM packages were not signed with a GPG key, the output might look like: takserver-4.10-RELEASE25.noarch.rpm: sha1 md5 OK

Verifying GPG signatures for DEB packages

Select the appropriate TAK Server release version and download the file *takserver-public-gpg.key* and *deb_policy.pol*

Install the debsig-verify utility

> sudo apt install debsig-verify

Using the ID within the deb_policy.pol file, ex. 039FCDA2D8907527, run the following command to verify signed TAK Server deb resources:

```
> sudo mkdir /usr/share/debsig/keyrings/039FCDA2D8907527
> sudo mkdir /etc/debsig/policies/039FCDA2D8907527
> sudo touch /usr/share/debsig/keyrings/039FCDA2D8907527/debsig.gpg
> sudo gpg --no-default-keyring --keyring
/usr/share/debsig/keyrings/039FCDA2D8907527/debsig.gpg --import takserver-public-gpg.key
> sudo cp deb_policy.pol /etc/debsig/policies/039FCDA2D8907527/debsig.pol
> debsig-verify -v takserver-4.10-RELEASE_all.deb
```

Confirm signature verification by identifying statement:

debsig: Verified package from 'TAK Product Center' (TAK Server Release)

4.2 New Installation: One Server

Start with a fresh install of a supported OS. For AWS / cloud installation, see recommended instance type on page 4. An OS install with a GUI is recommended, so that a web browser can be run locally to configure TAK Server.

Increase system limit for number of concurrent TCP connections (do once):

```
> echo -e "* soft nofile 32768\n* hard nofile 32768" | sudo tee --
append /etc/security/limits.conf > /dev/null
```

4.2.1 TAK Server Installation

4.2.1.1 Rocky Linux 8

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository. Install java 17. Disable the postgresql module (so the later postgresql and postgis specific versions aren't inaccessible due to 'modular filtering'). Enable PowerTools (needed for dependencies of postgis.) Install TAK server. Apply SELinux takserver-policy.

```
> sudo dnf install epel-release -y
> sudo dnf install -y
https://download.postgresql.org/pub/repos/yum/reporpms/EL-8-x86_64/pgdg-
redhat-repo-latest.noarch.rpm
> sudo dnf -qy module disable postgresql && sudo dnf update -y
```

- > sudo dnf install java-17-openjdk-devel -y
- > sudo dnf config-manager --set-enabled powertools
- > sudo dnf install takserver-4.10-RELEASEx.noarch.rpm -y
- > sudo dnf install checkpolicy
- > cd /opt/tak && sudo ./apply-selinux.sh && sudo semodule -l | grep takserver

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.2.1.2 RHEL 8

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository. Install java 17. Disable the postgresql module (so the later postgresql and postgis specific versions aren't inaccessible due to 'modular filtering'). Enable Repository Management and repository CodeReady Builder. Install TAK server. Apply SELinux takserver-policy.

- > sudo dnf install https://dl.fedoraproject.org/pub/epel/epel-release-latest-8.noarch.rpm -y
- > sudo dnf install -y

https://download.postgresql.org/pub/repos/yum/reporpms/EL-8-x86_64/pgdg-redhat-repo-latest.noarch.rpm

- > sudo dnf update -y && sudo dnf install java-17-openjdk-devel -y
- > sudo dnf module disable postgresql
- > sudo subscription-manager config --rhsm.manage_repos=1
- > sudo subscription-manager repos --enable codeready-builder-for-rhel-8-x86_64-rpms

Note: If you get the error 'This system has no repositories available through subscriptions', you need to subscribe your system with "sudo subscription-manager register --username <your_username> --password <your_password> --auto-attach"

- > sudo dnf install takserver-4.10-RELEASEx.noarch.rpm -y
- > sudo dnf install checkpolicy
- > cd /opt/tak && sudo ./apply-selinux.sh && sudo semodule -l | grep takserver

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.2.1.3 RHEL 7

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install OpenJDK 17 and other dependencies. Install TAK server

- > sudo yum install https://dl.fedoraproject.org/pub/epel/epel-release-latest-7.noarch.rpm -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm
- > sudo rpm -ivh takserver-4.10-RELEASEx.noarch.rpm --nodeps

Note that the yum package manager does not currently support JDK 17 on RHEL 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.2.1.4 Ubuntu and Raspberry Pi OS

Install the postgres repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install TAK server

> sudo mkdir -p /etc/apt/keyrings

- > sudo curl https://www.postgresql.org/media/keys/ACCC4CF8.asc --output
 /etc/apt/keyrings/postgresql.asc
- > sudo sh -c 'echo "deb [signed-by=/etc/apt/keyrings/postgresql.asc]
 http://apt.postgresql.org/pub/repos/apt/ \$(lsb_release -cs)-pgdg main" >
 /etc/apt/sources.list.d/postgresql.list'
- > sudo apt update
- > sudo apt install ./takserver-4.10-RELEASEx_all.deb

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.2.1.5 CentOS 7

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install OpenJDK 17 and other dependencies. Install Tak server.

- > sudo yum install epel-release -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL-7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum install -y postqis33_15 postqis33_15-utils
- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm
- > sudo rpm -ivh takserver-4.10-RELEASEx.noarch.rpm --nodeps

Note that the yum package manager does not currently support JDK 17 on CentOS 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

4.2.2 Configure TAK Server installation

> sudo systemctl daemon-reload

On resource limited hosts, such as a *Raspberry Pi*, you may start/stop only essential api and messaging TAK Server services with:

> sudo systemctl [start|stop] takserver-noplugins

Otherwise, to start/stop all TAK Server service:

> sudo systemctl [start|stop] takserver

You can set TAK Server to start at boot by running

> sudo systemctl enable takserver

or with resource limited hosts:

> sudo systemctl enable takserver-noplugins

For secure operation, TAK Server requires a keystore and truststore (X.509 certificates).

Next, follow the instructions in Appendix B to create these certificates. TAK Server by default is TLS only, so certificate generation, including an administrative certificate is required for configuration. In addition, if you would like to configure TLS for Postgres database connection, follow additional steps in Appendix D.

Verfiy that the steps in Appendix B have been followed by checking the following items:

Certificates are present at:

/opt/tak/certs/files

The TAK Server was restarted, the admin cert has been generated, and an admin account in TAK Server was created with the command:

```
> sudo java -jar /opt/tak/utils/UserManager.jar certmod -A
/opt/tak/certs/files/admin.pem
```

While following the instructions in Appendix B, you will have created an **admin** certificate. Import this certificate into your browser, so that you can access the Admin. It will be located here on your TAK Server machine:

/opt/tak/certs/files/admin.pem

Import this client certificate into your browser.

If you are using Firefox, go to Settings -> Preferences -> Privacy & Security -> Certificates -> View Certificates

Go to Import. Upload this file:

/opt/tak/certs/files/**admin**.p12


Enter the certificate password. The default password is *atakatak*

Browse to:

https://localhost:8443

Select the **admin** certificate to log in.

An error message similar to this indicates that the correct client certificate has not been imported into the browser:



4.3 New Installation: Two Servers

Follow the procedures in the following two sections to install the database server, and the messaging server. For AWS / cloud installation, see recommended instance type on page 4. Use this instance type for both servers.

4.3.1 Server One: Database Server

4.3.1.1 Dependency Setup

First, update firewall rules to allow communication with server two, for TCP port 5432.

4.3.1.1.1 Rocky Linux 8

Setup the extra postgres yum repo for the latest postgres and postgis. Disable the postgresql stream to install the specific postgres version we depend on. Enable the 'powertools' repo for postgis dependencies. Install TAK Server RPM database and its dependencies.

```
> sudo dnf install epel-release -y
> sudo dnf install https://download.postgresql.org/pub/repos/yum/reporpms/EL-
8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
> sudo dnf update -y
> sudo dnf module disable postgresql
> sudo dnf install java-17-openjdk-devel -y
> sudo dnf config-manager --set-enabled powertools
Make sure the database RPM is in the current directory
> sudo dnf install takserver-database-4.10-RELEASE-x.noarch.rpm --
setopt=clean_requirements_on_remove=false -y
Check Java version
> java -version
```

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

```
> sudo alternatives --config java
```

4.3.1.1.2 RHEL 8

Setup the extra postgres yum repo for the latest postgres and postgis. Disable the postgresql stream to install the specific postgres version we depend on. Install TAK Server RPM database and its dependencies.

- > sudo dnf install https://dl.fedoraproject.org/pub/epel/epel-release-latest-8.noarch.rpm -y
- > sudo dnf install https://download.postgresql.org/pub/repos/yum/reporpms/EL-8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo dnf update -y && sudo dnf install java-17-openjdk-devel -y
- > sudo dnf module disable postgresql
- > sudo subscription-manager config --rhsm.manage_repos=1
- > sudo subscription-manager repos --enable codeready-builder-for-rhel-8-x86_64-rpms

Note: If you get the error 'This system has no repositories available through subscriptions', you need to subscribe your system with "sudo subscription-manager register --username <your_username> --password <your_password> --auto-attach"

Make sure the database RPM is in the current directory

```
> sudo dnf install takserver-database-4.10-RELEASE-x.noarch.rpm --
setopt=clean_requirements_on_remove=false -y
```

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.1.1.3 RHEL 7

Setup the extra postgres yum repo for the latest postgres and postgis. Install OpenJDK 17 and other dependencies. Install TAK Server RPM database.

- > sudo yum install https://dl.fedoraproject.org/pub/epel/epel-release-latest-7.noarch.rpm -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum update -y
- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm

Note that the yum package manager does not currently support JDK 17 on RHEL 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Make sure the database RPM is in the current directory

```
> sudo rpm -ivh takserver-database-4.10-RELEASEx.noarch.rpm --nodeps
```

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.1.1.4 Ubuntu & Raspberry Pi OS

Install the postgres repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install TAK Server database. **Use database DEB.** Configure TAK Server Database installation

```
> sudo mkdir -p /etc/apt/keyrings
```

```
> sudo curl https://www.postgresql.org/media/keys/ACCC4CF8.asc --output
/etc/apt/keyrings/postgresql.asc
```

```
> sudo sh -c 'echo "deb [signed-by=/etc/apt/keyrings/postgresql.asc]
http://apt.postgresql.org/pub/repos/apt/ $(lsb_release -cs)-pgdg main" >
/etc/apt/sources.list.d/postgresql.list'
```

```
> sudo apt update
```

```
> sudo apt install takserver-database-4.10-RELEASEx_all.deb
```

Open the file /opt/tak/CoreConfig.example.xml and look for the auto-generated password for the database. This password will be used to configure the Core Server.

```
<connection url="jdbc:postgresql://127.0.0.1:5432/cot" username="martiuser"
password="Database_password" />
```

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

```
> sudo alternatives --config java
```

4.3.1.1.5 CentOS 7

Setup the extra postgres yum repo for the latest postgres and postgis. Install OpenJDK 17 and other dependencies. Install TAK Server RPM database.

> sudo yum install epel-release -y
> sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
> sudo yum update -y
> sudo yum install -y postgis33_15 postgis33_15-utils
> sudo yum install -y postgresql15-server postgresql15-contrib
> sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linux-x64_bin.rpm

Note that the yum package manager does not currently support JDK 17 on Centos 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Make sure the database RPM is in the current directory

```
> sudo yum install takserver-database-4.10-RELEASE-x.noarch.rpm --
setopt=clean_requirements_on_remove=false -y
```

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

```
> sudo alternatives --config java
```

4.3.2 Server Two: Core Server

Start with a fresh install of a supported OS. An install with a GUI is recommended, so that a web browser can be run locally to configure TAK Server.

Increase system limit for number of concurrent TCP connections (do once)

```
> echo -e "* soft nofile 32768\n* hard nofile 32768" | sudo tee --append /etc/security/limits.conf > /dev/null
```

4.3.2.1 Install TAK Server

4.3.2.1.1 Rocky Linux 8

- > sudo dnf install java-17-openjdk-devel -y
- > sudo dnf install takserver-core-4.10-RELEASEx.noarch.rpm -y
- > sudo dnf install checkpolicy
- > cd /opt/tak && sudo ./apply-selinux.sh && sudo semodule -l | grep takserver

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.2.1.2 RHEL 8

- > sudo dnf update -y && sudo dnf install java-17-openjdk-devel -y
- > sudo dnf install takserver-core-4.10-RELEASEx.noarch.rpm -y
- > sudo dnf install checkpolicy
- > cd /opt/tak && sudo ./apply-selinux.sh && sudo semodule -l | grep takserver

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.2.1.3 RHEL 7

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install OpenJDK 17 and other dependencies. Install Tak server.

- > sudo yum install https://dl.fedoraproject.org/pub/epel/epel-release-latest-7.noarch.rpm -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y

- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresgl15-server postgresgl15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm
- > sudo rpm -ivh takserver-core-4.10-RELEASEx.noarch.rpm --nodeps

Note that the yum package manager does not currently support JDK 17 on RHEL 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.2.1.4 Ubuntu & Raspberry Pi OS

> sudo apt install takserver-core-4.10-RELEASEx_all.deb

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.2.1.5 CentOS 7

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install OpenJDK 17 and other dependencies. Install Tak server.

- > sudo yum install epel-release -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm

> sudo rpm -ivh takserver-core-4.10-RELEASEx.noarch.rpm --nodeps

Note that the yum package manager does not currently support JDK 17 on Centos 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Check Java version

> java -version

This should tell you you have 17.x.y. If the "java -version" command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.3.2.2 Configuration

Configure database connection by updating /opt/tak/CoreConfig.xml:

<repository enable="true" numDbConnections="200" primaryKeyBatchSize="500"
insertionBatchSize="500">

<connection url="jdbc:postgresql://<Database_server_IP_address>:5432/cot" username="martiuser"
password="Database_password"/>
</repository>

> sudo systemctl daemon-reload

Start/stop TAK Server services with:

> sudo systemctl [start|stop] takserver

Or on resource limited hosts:

> sudo systemctl [start|stop] takserver-noplugins

You can set TAK Server to start at boot by running

> sudo systemctl enable takserver

For secure operation, TAK Server requires a keystore and truststore (X.509 certificates).

Next, follow the instructions in Appendix B to create these certificates. TAK Server by default is TLS only, so certificate generation, including an administrative certificate is required for configuration.

Verfiy that the steps in Appendix B have been followed by checking the following items:

Certificates are present at:

/opt/tak/certs/files

The admin cert has been generated and an admin account in TAK Server was created with the command:

> sudo java -jar /opt/tak/utils/UserManager.jar certmod -A
/opt/tak/certs/files/admin.pem

Import this client certificate into your browser.

If you are using Firefox, go to Settings -> Preferences -> Privacy & Security -> Certificates -> View Certificates

Go to Import. Upload this file:

/opt/tak/certs/files/admin.p12


Enter the certificate password. The default password is atakatak

Browse to:

https://localhost:8443

Select the admin certificate to log in.


An error message similar to this indicates that the correct client certificate has not been imported into the browser:




Once logged in with the admin certificate, configure the TAK Server with the following instructions:

Configure TAK Server to connect to the database. Access the Database configuration

settings:



Edit the database connection address, specifying the hostname or IP address of the database server:



Restart TAK Server

> sudo systemctl restart takserver

Or on resource limited hosts

> sudo systemctl restart takserver-noplugins

If you would like to configure TLS for Postgres database connection, refer to Appendix D.

4.4 Use Setup Wizard to Configure TAK Server


The TAK Server configuration wizard will help you set up common configuration options once you have installed and started TAK Server. The wizard will guide you through the setup process for a secure configuration, using the default ports that ATAK and WinTAK will connect to.

Once you have created your adminstrative login credentials as in the previous section, go to:

https://localhost:8443/setup/ (Recommended. Uses the more secure client certificate)

Then follow the prompts to begin configuring. The wizard will first walk you through recommended security configuration:

NOTE: Insecure ports are a potential security risk and may allow attackers to gain access to the system resulting in the disclosure of personal and sensitive information. Use of unencrypted ports should be avoided to ensure a secure TAK Server deployment.



In order to remove these, you will have to delete them from the CoreConfig.xml and restart the server


Security Configuration Keystore File: certs/files/takserver.iks

You have unsafe http connectors on the following ports: [8080].

Truststore File: certs/files/truststore-root.jks
TLS Version:TLSv1.2
x509 Groups: true
x509 Add Anonymous: true
Your Security Configuration looks good! You do not need to change anything unless you want to change the default settings.

Next Edit Security

Followed by the recommended federation configuration, if you wish to set up your TAK Server to support federation. (For more information on federation, go to section 8):



4.5 Upgrade existing TAK Server installation

Follow this procedure to upgrade a system running TAK Server.

4.5.1 Single-Server Upgrade

4.5.1.1 Rocky Linux 8

Install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository. Install java 17. Disable the postgresql module (so the later postgresql and postgis specific versions aren't inaccessible due to 'modular filtering'). Enable PowerTools (needed for dependencies of postgis.) Install TAK server.

```
> sudo dnf install epel-release -y
> sudo dnf install -y
https://download.postgresql.org/pub/repos/yum/reporpms/EL-8-x86_64/pgdg-
redhat-repo-latest.noarch.rpm
```

```
> sudo dnf -qy module disable postgresql && sudo dnf update -y
> sudo dnf install java-17-openjdk-devel -y
> sudo dnf config-manager --set-enabled powertools

Upgrade Tak server
> sudo dnf install takserver-4.10-RELEASEx.noarch.rpm --
setopt=clean_requirements_on_remove=false -y

Check Java version:
```

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.1.2 RHEL 8

Setup the extra postgres yum repo for the latest postgres and postgis. Install Java 17. Disable the postgresql stream to install the specific postgres version we depend on. Install TAK Server RPM database and its dependencies.

```
> sudo dnf install <a href="https://dl.fedoraproject.org/pub/epel/epel-release-latest-8.noarch.rpm">https://dl.fedoraproject.org/pub/epel/epel-release-latest-8.noarch.rpm</a> -y
```

```
> sudo dnf install https://download.postgresql.org/pub/repos/yum/reporpms/EL-
8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
```

- > sudo dnf update -y && sudo dnf install java-17-openjdk-devel -y
- > sudo dnf module disable postgresgl
- > sudo subscription-manager config --rhsm.manage_repos=1
- > sudo subscription-manager repos --enable codeready-builder-for-rhel-8-x86_64-rpms

Note: If you get the error 'This system has no repositories available through subscriptions', you need to subscribe your system with "sudo subscription-manager register --username <your username> --password <your password> --auto-attach"

```
Upgrade Tak server
```

```
> sudo dnf install takserver-4.10-RELEASEx.noarch.rpm --
setopt=clean_requirements_on_remove=false -y
```

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.1.3 RHEL 7

If you have not previously done so, install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install OpenJDK 17 and other dependencies. Upgrade TAK server

- > sudo yum install https://dl.fedoraproject.org/pub/epel/epel-release-latest-7.noarch.rpm -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm
- > sudo rpm -Uvh takserver-4.10-RELEASEx.noarch.rpm --nodeps

Note that the yum package manager does not currently support JDK 17 on Centos 7 and RHEL 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.1.4 Ubuntu and Raspberry Pi OS

Upgrade Tak server

> sudo apt install ./takserver-4.10-RELEASEx_all.deb

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.1.5 Centos 7

If you have not previously done so, install EPEL (EPEL provides certain dependencies required by PostgreSQL.) Install postgres yum repository (required in order to install up-to-date Postgresql and PostGIS packages.) Install OpenJDK 17 and other dependencies. Upgrade Tak server.

- > sudo yum install epel-release -y
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm
- > sudo rpm -Uvh takserver-4.10-RELEASEx.noarch.rpm --nodeps

Note that the yum package manager does not currently support JDK 17 on Centos 7 and RHEL 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Check Java version:

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.2 Two-Server Upgrade

4.5.2.1 Rocky Linux 8

Upgrade the two TAK Server packages on the servers on which they are installed.

First, on the core server, install Java 17 and upgrade the core package:

> sudo dnf install java-17-openjdk-devel -y

> sudo dnf install takserver-core-4.10-RELEASEx.noarch.rpm -y

Next, on the database server, upgrade the database. Setup the extra postgres yum repo for the latest postgres and postgis. Disable the postgresql stream to install the specific postgres version we depend on. Install Java 17. Enable the 'powertools' repo for postgis dependencies. Install TAK Server RPM database and its dependencies.

```
> sudo dnf install epel-release -y
> sudo dnf install https://download.postgresql.org/pub/repos/yum/reporpms/EL-
8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
> sudo dnf update -y
> sudo dnf module disable postgresql
> sudo dnf install java-17-openjdk-devel -y
> sudo dnf config-manager --set-enabled powertools

Make sure the database RPM is in the current directory
```

This command will make a copy of your existing Postgresql database and update it to version 15. If there is an issue with the upgraded database, you can fall back to the copy of the previous version. If the upgrade succeeds, there will be a delete_old_cluster.sh script automatically created that you can run to safely remove the previous version's data copy.

> sudo dnf install takserver-database-4.10-RELEASE-x.noarch.rpm --

Check Java version in both servers

setopt=clean_requirements_on_remove=false -y

```
> java -version
```

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

```
> sudo alternatives --config java
```

4.5.2.2 RHEL 8

Upgrade the two TAK Server packages on the servers on which they are installed.

First, on the core server, install Java 17 and upgrade the core package:

```
> sudo dnf update -y && sudo dnf install java-17-openjdk-devel -y
```

```
> sudo dnf install takserver-core-4.10-RELEASEx.noarch.rpm -y
```

Next, on the database server, upgrade the database. Setup the extra postgres yum repo for the latest postgres and postgis. Install Java 17. Disable the postgresql stream to install the specific postgres version we depend on. Install TAK Server RPM database and its dependencies.

- > sudo dnf install https://dl.fedoraproject.org/pub/epel/epel-release-latest-8.noarch.rpm -y
- > sudo dnf install https://download.postgresql.org/pub/repos/yum/reporpms/EL-8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo dnf update -y && sudo dnf install java-17-openjdk-devel -y
- > sudo dnf module disable postgresql
- > sudo subscription-manager config --rhsm.manage_repos=1
- > sudo subscription-manager repos --enable codeready-builder-for-rhel-8-x86_64-rpms

Note: If you get the error 'This system has no repositories available through subscriptions', you need to subscribe your system with "sudo subscription-manager register --username <your_username> --password <your_password> --auto-attach"

Make sure the database RPM is in the current directory

```
> sudo dnf install takserver-database-4.10-RELEASE-x.noarch.rpm --
setopt=clean_requirements_on_remove=false -y
```

This command will make a copy of your existing Postgresql database and update it to version 15. If there is an issue with the upgraded database, you can fall back to the copy of the previous version. If the upgrade succeeds, there will be a delete_old_cluster.sh script automatically created that you can run to safely remove the previous version's data copy.

Check Java version in **both** servers

> java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.2.3 RHEL 7

Install OpenJDK 17 and other dependencies (if you have not previously done so.)

- > sudo yum install -y postgis33_15 postgis33_15-utils
- > sudo yum install -y postgresgl15-server postgresgl15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm

Note that the yum package manager does not currently support JDK 17 on RHEL 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Upgrade the two TAK Server packages on the servers on which they are installed. **First**, upgrade the core package:

> sudo rpm -Uvh takserver-core-4.10-RELEASEx.noarch.rpm --nodeps

Next, upgrade the database. Setup the extra postgres yum repo for the latest postgres and postgis. Install TAK Server RPM database and its dependencies.

- > sudo yum install https://dl.fedoraproject.org/pub/epel/epel-release-latest-7.noarch.rpm
- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL7-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum update -y

Make sure the database RPM is in the current directory

> sudo rpm -Uvh takserver-database-4.10-RELEASEx.noarch.rpm --nodeps

This command will make a copy of your existing Postgresql database and update it to version 15. If there is an issue with the upgraded database, you can fall back to the copy of the previous version. If the upgrade succeeds, there will be a delete_old_cluster.sh script automatically created that you can run to safely remove the previous version's data copy.

```
Check Java version in both servers > java -version
```

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

```
> sudo alternatives --config java
```

4.5.2.4 Ubuntu and Raspberry Pi OS

Upgrade the two TAK Server packages on the servers on which they are installed.

First, upgrade the core package.

```
> sudo apt install ./takserver-core_4.10-RELEASE-x_all.deb
```

Next, upgrade the database.

```
> sudo apt install ./takserver-database_4.10-RELEASE-x_all.deb
```

This command will make a copy of your existing Postgresql database and update it to version 15. If there is an issue with the upgraded database, you can fall back to the copy of the previous version. If the upgrade succeeds, there will be a delete_old_cluster.sh script automatically created that you can run to safely remove the previous version's data copy.

Check Java version in both servers

```
> java -version
```

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.5.2.5 Centos 7

Install OpenJDK 17 and other dependencies (if you have not previously done so.)

```
> sudo yum install -y postgis33_15 postgis33_15-utils
```

- > sudo yum install -y postgresql15-server postgresql15-contrib
- > sudo yum install -y https://download.oracle.com/java/17/latest/jdk-17_linuxx64_bin.rpm

Note that the yum package manager does not currently support JDK 17 on Centos 7. By installing the package manually, you will be responsible for future security updates. For a safer long-term solution, we recommend that you update your OS to RHEL 8 or Rocky Linux 8.

Upgrade the two TAK Server packages on the servers on which they are installed. **First**, upgrade the core package:

```
> sudo rpm -Uvh takserver-core-4.10-RELEASEx.noarch.rpm --nodeps
```

Next, upgrade the database. Setup the extra postgres yum repo for the latest postgres and postgis. Install TAK Server RPM database and its dependencies.

```
> sudo yum install epel-release -y
```

- > sudo yum install https://download.postgresql.org/pub/repos/yum/reporpms/EL-8-x86_64/pgdg-redhat-repo-latest.noarch.rpm -y
- > sudo yum update -y

Make sure the database RPM is in the current directory

```
> sudo yum install takserver-database-4.10-RELEASE-x.noarch.rpm --
setopt=clean_requirements_on_remove=false -y
```

This command will make a copy of your existing Postgresql database and update it to version 15. If there is an issue with the upgraded database, you can fall back to the copy of the previous version. If the upgrade succeeds, there will be a delete_old_cluster.sh script automatically created that you can run to safely remove the previous version's data copy.

Check Java version in **both** servers > java -version

This should tell you have 17.x.y. If the command tells you your Java version is not 17.x.y, then you can use the alternatives command to change it:

> sudo alternatives --config java

4.6 Docker Install

TAK Server can be installed using docker. To begin, you will need the docker release which comes as a zip file called 'takserver-docker-<version>.zip'.

If you using CentOS 7, follow these instructions first to install docker, start the docker daemon and use it as a regular user:

https://www.digitalocean.com/community/tutorials/how-to-install-and-use-docker-on-centos-7

Next, unzip the docker zip file. **All further commands should be run from this top level 'takserver-docker-<version>' directory**. If you are familiar with the rpm install, the 'tak' folder within the 'takserver-docker-<version>' directory represents the '/opt/tak' directory installed by the rpm. When the takserver containers are built, the 'tak' directory will be mounted to '/opt/tak' within the containers. Therefore, any references to '/opt/tak' outside this section of the guide will be equivalent to the 'tak' directory you have on the host, or '/opt/tak' if you are working from inside the container.

The 'tak' directory is where the coreconfig, certificates, logs and other TAK configuration/tools will live. This folder is shared between the host, the takserver container and the takserver database container. This means you can tail the logs or manually edit the coreconfig from the host without being inside the container.

Notes for running in Windows Subsystem for Linux (WSL) 2:

When running TAK Server in the WSL2 environment, follow the steps outlined in the Best Practices section here https://docs.docker.com/desktop/windows/wsl/ to maximize TAK Server performance. Specifically, it's recommended that you copy the 'takserver-docker-<version>.zip' file into your WSL user's home directory and execute all docker commands from there (vs accessing your Windows filesystem from /mnt). For example, if your WSL username was 'tak' and you're running Ubuntu-20.04, copy the docker .zip file to \wsl\$\Ubuntu-20.04\home\tak using Windows Explorer. Next, navigate to that directory within WSL. From there, unzip the file and run the docker commands below for TAK Server. It's important to unzip the file from within WSL to ensure permissions are setup correctly.

TAK Server CoreConfig Setup:

- 1. Open tak/CoreConfig.example.xml and set a database password
- 2. Make any other configuration changes you need

TAK Server Database Container Setup:

- 1. Build TAK server database image:
- > docker build -t takserver-db:"\$(cat tak/version.txt)" -f docker/Dockerfile.takserver-db.
- 2. Create a new docker network for the current tak version:
- > docker network create takserver-"\$(cat tak/version.txt)"

- 3. The TAK Server database container can be configured to persist data directly to the host or only within the container.
 - a. To persist to the host, create an empty host directory (unless you have a directory from a previous docker install you want to reuse). For upgrading purposes, we recommend that you keep the takserver database directory outside of the 'takserver-docker-<version>' directory structure.
- > docker run -d -v <absolute path to takserver database directory>:/var/lib/postgresql/data:z -v \$(pwd)/tak:/opt/tak:z -it -p 5432:5432 --network takserver-"\$(cat tak/version.txt)" --network-alias tak-database --name takserver-db-"\$(cat tak/version.txt)" takserver-db:"\$(cat tak/version.txt)"
 - b. To run TAK server database with container only persistence
- > docker run -d -v \$(pwd)/tak:/opt/tak:z -it -p 5432:5432 --network takserver-"\$(cat tak/version.txt)" --network-alias tak-database --name takserver-db-"\$(cat tak/version.txt)" takserver-db:"\$(cat tak/version.txt)"

TAK Server Container Setup:

- 1. Build TAK Server image:
- > docker build -t takserver: "\$(cat tak/version.txt)" -f docker/Dockerfile.takserver .
- 2. Running TAK Server container: use -p <host port>:<container port> to map any additional ports you have configured. Adding new inputs or changing ports while the container is running will require the container to be recreated so that the new port mapping can be added.
- > docker run -d -v \$(pwd)/tak:/opt/tak:z -it -p 8089:8089 -p 8443:8443 -p 8444:8444 -p 8446:8446 -p 9000:9000 -p 9001:9001 --network takserver-"\$(cat tak/version.txt)" --name takserver-"\$(cat tak/version.txt)"
- 2. **Before using the TAK Server, you must setup the certificates for secure operation.** If you have already configured certificates you can skip this step. You can also copy existing certificates into 'tak/certs/files' and a UserAuthetication.xml file into 'tak/' to reuse existing certificate authentication settings. **Any change to certificates while the container is running will require either a TAK server restart or container restart.** Additional certificate details can be found in Appendix B.
 - a. Edit tak/certs/cert-metadata.sh
 - b. Generate root ca
- > docker exec -it takserver-"\$(cat tak/version.txt)" bash -c "cd /opt/tak/certs && ./makeRootCa.sh"
 - c. Generate server cert
- > docker exec -it takserver-"\$(cat tak/version.txt)" bash -c "cd /opt/tak/certs && ./makeCert.sh server takserver"
 - d. Create client cert(s)
- > docker exec -it takserver-"\$(cat tak/version.txt)" bash -c "cd /opt/tak/certs && ./makeCert.sh client <user>"
 - e. Restart takserver to load new certificates
- > docker exec -d takserver-"\$(cat tak/version.txt)" bash -c "cd /opt/tak/ && ./configureInDocker.sh"
- f. Tail takserver logs from the host. **Once TAK server has successfully started, proceed to the next step.**
- > tail -f tak/logs/takserver-messaging.log
- > tail -f tak/logs/takserver-api.log

3. Accessing takserver

Create admin client certificate for access on secure port 8443 (https):

> docker exec takserver-"\$(cat tak/version.txt)" bash -c "cd/opt/tak/ && java -jar

utils/UserManager.jar certmod -A certs/files/<client cert>.pem"

Hardened TAK Server Setup:

The hardened TAK Database and Server containers provide additional security by including the use of secure Iron Bank base images, container health checks, and minimizing user privileges within the containers.

The hardened TAK images are available in a zip file, takserver-docker-hardened-<version>.zip. The steps for setting up the hardened containers are similar to the standard docker installation steps given above except for the following:

Certificate Generation:

The certificate generation container is only required to run once for TAK Server initialization. Run all commands in this section from the root of the unzipped hardened docker contents.

1. Build the Certificate Authority Setup Image:

```
< docker build -t ca-setup-hardened --build-arg ARG_CA_NAME=<CA_NAME> --build-arg
ARG_STATE=<ST> --build-arg ARG_CITY=<CITY> --build-arg
ARG_ORGANIZATIONAL_UNIT=<UNIT> -f docker/Dockerfile.ca .
```

2. Run the Certificate Authority Setup Container: If certificates have previously been generated and exist in the tak/cert/files path when building the ca-setup-hardened image then certificate generation will be skipped at runtime.

<docker run --name ca-setup-hardened -it -d ca-setup-hardened</p>

- 3. Copy the generated certificates for TAK Server:
- > docker cp ca-setup-hardened:/tak/certs/files files
- > [-d tak/certs/files] || mkdir tak/certs/files \
- && docker cp ca-setup-hardened:/tak/certs/files/takserver.jks tak/certs/files/
- && docker cp ca-setup-hardened:/tak/certs/files/truststore-root.jks tak/certs/files/
- && docker cp ca-setup-hardened:/tak/certs/files/fed-truststore.iks tak/certs/files/
- && docker cp ca-setup-hardened:/tak/certs/files/admin.pem tak/certs/files/
- && docker cp ca-setup-hardened:/tak/certs/files/config-takserver.cfg tak/certs/files/

TAK Server Database Hardened Container Setup:

- 1. Building the hardened docker images requires creating an Iron Bank/Repo1 account to access the approved base images. To create an account, follow the instructions in the <u>IronBank Getting Started</u> page. To download the base images via the CLI, see the instructions in the <u>Registry Access</u> section. After obtaining the necessary credentials, run:
- < docker login registry1.dso.mil
- 2. Follow the instructions in the **TAK Server CoreConfig Setup** section and update the <connection-url> tag with the hardened TAK Database container name. For example:
- <connection url="jdbc:postgresql://tak-database-hardened-<version>:5432/cot" username="martiuser"
 password=<password>/>
- 3. Create a new docker network for the current tak version:
- > docker network create takserver-net-hardened-"\$(cat tak/version.txt)"

Ensure in the db-utils/pg_hba.conf file that there is an entry for the subnet of the hardened takserver network. To determine the subnet of the network:

< docker network inspect takserver-net-hardened-"\$(cat tak/version.txt)"

Or to specify the subnet on network creation:

- < docker network create takserver-net-hardened-"\$(cat tak/version.txt)" --subnet=<subnet>
- 4. Build the hardened TAK Database image:
- <docker build -t tak-database-hardened:"\$(cat tak/version.txt)" -f docker/Dockerfile.hardenedtakserver-db .
- 5. Run the hardened TAK Database container:
- < docker run --name tak-database-hardened-"\$(cat tak/version.txt)" --network takserver-net-hardened-"\$(cat tak/version.txt)" --network-alias tak-database -d tak-database-hardened:"\$(cat tak/version.txt)" -p 5432:5432

TAK Server Hardened Container Setup

- 1. Build the hardened TAK Server image:
- < docker build -t takserver-hardened:"\$(cat tak/version.txt)" -f docker/Dockerfile.hardened-takserver .
- 2. Run the hardened TAK Server container:

< docker run --name takserver-hardened-"\$(cat tak/version.txt)" --network takserver-net-hardened-"\$ (cat tak/version.txt)" -p 8089:8089 -p 8443:8443 -p 8444:8444 -p 8446:8446 -t -d takserver-hardened:"\$(cat tak/version.txt)"

Configuring Certificates

- 1. Get the admin certificate fingerprint
- > docker exec -it ca-setup-hardened bash -c "openssl x509 -noout -fingerprint -md5 -inform pem -in files/admin.pem | grep -oP 'MD5 Fingerprint=\K.*'"
- 2. Add the certificate fingerprint as the admin after the hardened TAK server container has started (about 60 seconds)
- > docker exec -it takserver-hardened-"\$(cat tak/version.txt)" bash -c 'java -jar /opt/tak/utils/UserManager.jar usermod -A -f <admin cert fingerprint> admin'

Useful Commands

*To run these commands on the hardened containers, add the -hardened suffix to the container names.

- View images:
 - > docker images takserver
 - > docker images takserver-db
- View containers

All: > docker ps -a

Running: > docker ps

Stopped: > docker ps -a | grep Exit

- Exec into container
 - > docker exec -it takserver-"\$(cat tak/version.txt)" bash
 - > docker exec -it takserver-db-"\$(cat tak/version.txt)" bash
- Exec command in container
 - > docker exec -it takserver-"\$(cat tak/version.txt)" bash -c "<command>"
 - > docker exec -it takserver-db-"\$(cat tak/version.txt)" bash -c "<command>"
- Tail takserver logs
 - > tail -f tak/logs/takserver-messaging.log
 - > tail -f tak/logs/takserver-api.log
- Restart TAK server

- > docker exec -d takserver-"\$(cat tak/version.txt)" bash -c "cd /opt/tak/ &&./configureInDocker.sh"
- Start/Stop container:
 - > docker <start/stop> takserver-"\$(cat tak/version.txt)"
 - > docker <start/stop> takserver-db-"\$(cat tak/version.txt)"
- Remove container:
 - > docker rm -f takserver-"\$(cat tak/version.txt)"
 - > docker rm -f takserver-db-"\$(cat tak/version.txt)"

4.7 Configure System Firewall

One of the most common problems people have is the system default firewall blocking their traffic.

The full procedure for configuring the firewall is complex and beyond the scope of this guide, and is an important concern for system configuration. Consult your network administrator and/or the firewalld documentation at https://fedoraproject.org/wiki/FirewallD.

The following tips will get you started for lab/field environments.

4.7.1 RHEL, Rocky Linux, and CentOS

To verify whether a firewall is running, use the command:

```
> sudo systemctl status firewalld.service
```

To see what zones are running:

```
> sudo firewall-cmd --get-active-zones
```

If you are working from a fresh OS install, the only active zone is 'public'.

For each each zone, you'll want to enable TCP (and possibly UDP) ports for the inputs in your CoreConfig.xml file, plus the web server's port. For example,

```
> sudo firewall-cmd --zone=public --add-port 8089/tcp -permanent
```

```
> sudo firewall-cmd --zone=public --add-port 8443/tcp --permanent
```

The ports you'll need to open for the default configuration are 8089 and 8443.

Finally, enable your new firewall rules:

```
> sudo firewall-cmd -reload
```

4.7.2 Ubuntu and Rasapberry Pi

UFW (Uncomplicated Firewall) is a utility for managing firewalls. If is not installed on your server. Install with the following:

```
> sudo apt install ufw
```

IMPORTANT: *Raspberry Pi* installs, please reboot your device after installing ufw.

To check the status of the firewall service with current port rules:

```
> sudo ufw status
```

Perform the following commands to set initial rules for your firewall:

```
> sudo ufw default deny incoming
> sudo ufw default allow outgoing
> sudo ufw allow ssh
```

Turn on the firewall:

> sudo ufw enable

Add default configuration TAK Server ports:

```
> sudo ufw allow 8089
> sudo ufw allow 8443
```

4.8 Software Installation Location

The RPM installer places the TAK server software and configuration in the directory **/opt/tak**. It creates a user named **tak** who is the owner of the files in that directory tree. **Always use this tak user when editing CoreConfig.xml or generating certificates. You can become the tak user by entering:**

sudo su tak

5 Configuration

Configuration is primarily done through the web interface. Changes made in the interface will be reflected in the /opt/tak/CoreConfig.xml file. If that file does not exist (e.g. on a fresh install), then when TAK Server starts up it will copy /opt/tak/CoreConfig.example.xml. The example has many commented out options. Notable configuration options:

- inputs: In the <network> section there are a series of <input> elements. These define ports the server will listen on. Protocol options are as follows:
 - udp: standard CoT udp protocol; unencrypted

- mcast: like udp, but has additional configuration option for multicast group
- tcp: publish-only port; standard CoT tcp protocol; unencrypted
- stcp: streaming/bi-directional; this is for ATAK to connect to. Unencrypted, for testing only
- tls: TCP+TLS streaming/bi-directional for encrypted communication with TAK clients
- <auth>: you can use either a flat file or an LDAP backend for group filtering support
- <security>: here you specify the keystore files to use for the secure port(s)

5.1 Configuring Security through Web UI (Certificates/TLS) Security Configuration

Keystore File: /home/nick/takserver/takserver/src/takserver-core/scripts/certs/files/testServer.jks **Truststore File:** /home/nick/takserver/takserver/src/takserver-core/scripts/certs/files/truststore-root.jks

TLS Version: TLSv1.2 x509 Groups: true

x509 Add Anonymous: true

Edit Security

Security Configuration Web interface

Security and authentication options for TAK Server can be set up using a web interface. To access this page in the menu bar go to Configuration > Manage Security and Authentication Configuration. This page will contain both Security and Authentication configuration current values. To modify the Security Configuration click "Edit Security". This will allow changes to the server's certificates, the version of TLS used, x509 Groups settings and x509 Add Anonymous settings. Note: Changes made here will only take effect after a server restart.

5.2 Group Filtering

TAK Server has the ability to segment users so they only see a subset of the other users on the system. This is achieved by assigning groups to individual connections. If ATAK-A shares common group membership in at least one group with ATAK-B, they share data with each other. If not otherwise specified, all connections default to being in the special "__ANON__" group (note 2 underscores as prefix and postfix). There are three ways to assign groups to a connection:

- Assigning <filtergroup> elements to <inputs>: this is simple, but provides no access control if you have multiple ports configured on the same server.
- Active Directory / LDAP / Flat file with additional authentication message
- Active Directory / LDAP / Flat file without additional authentication messages (uses certificatebased identification)

Details on the three options:

5.3 Group Assignment by Input

<inputs> can drive group filtering, even without authentication messages. Version 1.3.0 added group filtering based on LDAP groups. This necessitated a new authentication message from ATAK. This worked for the streaming connections, but wouldn't work for the connection-less UDP traffic.

We added an additional configuration option for inputs to allow the connection-less traffic to be routed according to the group filtering. An input definition like this:

would have the effect of making every CoT event that came into the 'stdudp' input be associated with the "TEST1" group *instead of* the anonymous group. If there is no filtergroup specified, the default is the old behavior, which is a special anonymous group. The anonymous group has a name "__ANON__" that can be used to explicitly add it back in if needed. The filtergroup option can be used with the streaming input protocols as well (stcp, tls), the effect of which is that any subscriptions made by connecting to that port inherit the filter group from the input. <filtergroup> cannot be used in conjunction with the "auth" attribute on the same input. You can however use them on separate inputs, for example:

Note that when trying to interact with LDAP groups, you need to use the fully qualified group name that LDAP/ActiveDirectory reports.

5.3.1 Input Configuration UI

Inputs can be dynamically added, modified and deleted in the TAK Server user interface, under the menu heading **Configuration** \rightarrow **Input Definitions**. The UI also shows activity for each input, in terms of number of reads and messages. For the streaming protocols (stcp, tls), the activity is the sum for *all* connections made using that particular input port.

5.4 Group Assignment Using Authentication Messages

If ATAK or another TAK client is configured to send an authentication message after establishing a connection to TAK Server, the username and password credentials contained in that message will be used, in conjunction with an authentication backend, to determine the group membership of a user. TAK Server will then filter messages according to common group membership, in a similar fashion to filtering configured by <filtergroups> for a given <input>.

TAK Server can be configured at the input level to expect authentication messages with each new client connection. If the authentication message is not sent, or is invalid, the client will be disconnected. The "auth" attribute on the input indicates which authentication strategy will be used when processing authentication messages. A value of "file" tells TAK Server to validate authentication credentials using the flat-file backend. A value of "ldap" indicates that an Active Directory or LDAP server should be used to validate the credentials.

For example, this input definition specifies streaming TCP, encrypted with TLS, authenticating the user with a client certificate and also requiring an authentication message, and using the LDAP authentication backend:

```
<input _name="ldapssl" protocol="tls" port="8091"
auth="ldap"/>
```

5.5 Group Assignment Using Client Certificates

TAK Server can be configured to use only the information contained in a client certificate, when looking up group membership for a user. In this case, the TAK client is configured to use TLS and a client certificate when connecting to TAK server, but does not send an authentication message. This eliminates the requirement to cache credentials on the device, or enter credentials prior to establishment of each new connection. TAK Server will then filter messages according to common group membership, in a similar fashion to input-level filtering with filter groups. When analyzing the X.509 client certificate presented by the TAK client, TAK Server will look at the DN attribute in the certificate, extract the CN value from the DN (if present). The CN is regarded as the username, and is used to look up group membership in authentication backends. For example, consider this DN in a client certificate:

```
CN=jkirk, O=TAK, C=US
```

The CN value **jkirk** will be used as the username. The process for deciding which authentication backend to use depends on whether or not an Active Directory (AD) LDAP configuration is present in CoreConfig.xml. Valid service account credentials must be configured in CoreConfig.. If AD authentication is configured, the user account is matched by the **sAMAccountName** LDAP attribute. At client authentication time, if groups are found in AD for the user, those groups are used by TAK Server. If no groups are found, the flat-file authentication backend is searched for a match on the username. If no groups are found for the user in either repository, the user is assigned to the __ANON__ group.

When configuring the input, a TLS input with an auth type of **x509** directs TAK Server to use the client certificate for both authentication and group assignment. On the input configuration, the on or example, this input definition specifies streaming TCP encrypted with TLS, authenticating the user with a client certificate and also requiring an authentication message, and using the LDAP authentication backend:

```
<input _name="ldapssl" protocol="tls" port="8091"
auth="x509"/>
```

5.6 Authentication Backends

5.6.1 File-Based

There is now a flat-file option available to inputs. Previously the only valid value for the <input> "auth" attribute was "ldap". "file" is now another valid value. The example configuration file (CoreConfig.example.xml) contains an example of how to configure the File-based backend.

A utility for creating and maintaining that flat file is included in the release. Run sudo java -jar /opt/tak/utils/UserManager.jar

and look at the various options for the 'offlineFileAuth'

5.6.2 Active Directory (AD) / LDAP

TAK Server can be configured to use an Active Directory or LDAP server to authenticate users, and assign groups. LDAP configuration for TAK Server varies depending on the configuration of the AD or LDAP server. Here is an example. Note that it contains credentials for a service account. This is required for group membership lookup using a client cert:

```
<auth>
<ldap url="ldap://a.b.com/ou=MyUserOU,DC=a,DC=b,DC=com"
    userstring="{username}@MYDOMAIN" updateinterval="60000" style="AD"
    serviceAccountDN="mysearchuser@MYDOMAIN"
    serviceAccountCredential="password"
/>
</auth>
```

5.6.3 Configuring LDAP through Web Interface

Authentication Configuration (LDAP)

LDAP is not currently defined in configuration.

To define LDAP edit the configuration and restart the server

URL:
User String:
Update Interval:
Group Prefix:
Service Account DN:
Group Base RDN:

Figure 1: Authentication Configuration Web interface

The LDAP configuration can be changed through an easy to use web page. To access this go to Configuration > Manage Security and Authentication. Under the Authentication heading will be the current LDAP configuration (the values will be empty if LDAP is not configured yet). Click on "Edit Authentication" to be directed to a form to enter desired LDAP settings. Note: Changes made here will only take effect after a server restart.

Messaging Configuration

Latest SA: 🗹

Repository Settings

Database Connections: 32

Archive: false

Database URL: jdbc:postgresql://127.0.0.1:5432/cot

Database Username: martiuser

Edit Configuration

Messaging Configuration Web interface

Messaging/Repository settings configuration can be done through the input definitions page. To get there go to Configuration > Input Definitions in the menu bar. This page displays the current input definitions at the top and at the bottom the current configuration of Messaging and Repository settings are displayed. To edit these setting click "Edit Configuration". Note: Changes made here will only take effect after a server restart.

5.7 Configuring Messaging and Repository Settings through Web UI

5.8 Optionally Disabling UI and WebTAK on HTTPS Ports

TAK Server can be configured to optionally disable the Admin UI, non-admin UI or WebTAK on any HTTPS connector (port). These options can be used to fine-tune the security profile for each HTTPS connector. For example, the admin web interface can be moved to an alternate port that is protected by a firewall from access on the public Internet.

In the CoreConfig.xml, the *enableAdminUI*, *enableWebtak*, and *enableNonAdminUI* attributes on each <connector> can be used to optionally disable access to any of these three functions for a given HTTPS connector port. The default value for each of these attributes is *true*, so by default these functions are available.

Usage Examples:

Disable webtak on port 8443:

<connector port="8443" name="https" enableWebtak="false" />

On port 8452, disable admin UI, but enable WebTAK and non-admin UI:


<connector port="8452" name="https" enableAdminUI="false" />

Disable WebTAK on OAuth port 8446:


<connector port="8446" clientAuth="false" _name="cert_https" enableWebtak="false"/>

5.9 VBM Admin Configuration

TAK Server can allow for additional filtering of cot messages recieved from inputs (server ports) and data feeds by using the VBM Configuration page in the Admin UI. To navigate there, go to Administrative > VBM Configuration as shown below.



You will then see the following options.




To modify the VBM configurations select the checkbox next to the desired option and when you're finished click "Save changes".

NOTE: "Disable SA Sharing" and "Disable Chat Sharing" will only be used if "Enable VBM" is selected.

The VBM options have the following impact:

If "Enable VBM" is selected, messages recieved on a data feed are only brokered to clients which are subscribed to the mission if the message falls within the bounding box specified by the mission. For example, the message represented by the blue dot would be passed on while the message represented by the green dot would be filtered out for the mission with the displayed bounding box only if "Enable VBM" is turned on.



The second two options are only activated if "Enable VBM" is on and they refer to messages recieved from inputs (server ports). These options filter messages based on whether they are chat messages. Chat messages in this context are cot messages which have a type set to "b-t-f".

If "Disable SA Sharing" is selected, messages recieved from inputs are passed on if the message is a chat message as defined above.

If "Disable Chat Sharing" is selected, messages recieved from inputs are passed on if the messages is **NOT** a chat message as defined above.

These options are not mutually exclusive. Therefore, having both selected will filter out all messages recieved on inputs.

6 WebTAK

The WebTAK front-end application is bundled with TAK Server. The WebTAK back-end WebSockets networking channel and APIs are provided by TAK Server. WebTAK must be accessed using https.

WebTAK can be accessed either with X.509 client certificates (default https port 8443), or by username-password access using OAuth (https port 8446).

In either case, TAK Server must be configured with a server certificate and truststore (see Appendix B).

In the Admin UI menu, use **Situation Awareness** -> **WebTAK** to access WebTAK.

7 Device Profiles

TAK Server can now assist in provisioning ATAK devices through Device Profiles. The Device Profile Manager (under Administrative Menu, Device Profiles) allows administrators to build profiles that can be applied to clients when enrolling for certificates, and when connecting to TAK server. The Profile consists of a sets of files, which can include settings and data in any file format that is supported by TAK Mission Packages. Profiles can be made public or restricted to individual Groups.

When an ATAK device enrolls for client certificate, or optionally after connecting to TAK server, TAK server will return all profiles that need to be applied to the device. The TAK server administrator can also push a profile to a connected user by clicking the Send link within the Device Profile Manager.

8 Federation

Federation will allow subsets of ATAK users who are connected to different servers to work together, even though each TAK server instance (hereafter refered to as 'federates') may be run by independent organizations / administrative domains. It brings some of the following benefits/restrictions:

- 1. Each administrative domain does not need to share anything about their internal structure (e.g. LDAP/Active Directory information / users) with the other administrative domain.
- 2. Each administrative domain has control over what data they share with the other domain, but has no control over what the other administrative domain does with data that is shared.
- 3. It requires no reconfiguration of ATAKs connected to either TAK Server, and the mechanism for connecting the TAK Servers does not allow direct connections of ATAK devices from the other administrative domain.

8.1 Enable Federation

The first step is to enable federation on your TAK server. To do this, first go the Configuration > Manage Federates page. If federation is not yet enabled, click on the Edit Configuration button. This is also where you can pick the ports for each federation protocol.



Do not forget to restart the server after changing the federation configuration in order for the changes to take effect!

8.2 Upload Federate Certificate

In order for the federate servers to trust each other and their ATAK clients, they must share each others certificate authorities (CAs) in order to create a separate federate trust-store. One of the key components to how TAK Server satisfies all the restrictions is that we use one trust-store for local users, and one for Federates. The trust-store contains all the valid CAs that you will allow client certificates from. By having separate trust-stores, we can have the Federation channels allow connections with certificates from "outside" CAs, while not allowing ATAKs with certs from those "outside" CAs to make direct connections to our server.



Federation Certificate Authorities


Upload Federate Certificate Authority

Issuer	Subject	Serial Number		
CN=bendeCert, OU=BBN, O=TAK, L=Cambridge, ST=MA, C=US	CN=bendeCert, OU=BBN, O=TAK, L=Cambridge, ST=MA, C=US	16032541280287273000	Delete	Manage CA Groups
CN=thirdTry, OU=BBN, O=BENDE, L=CAMBRIDGE, ST=MA, C=US	CN=thirdTry, OU=BBN, O=BENDE, L=CAMBRIDGE, ST=MA, C=US	16445567435884347000	Delete	Manage CA Groups

Generally, we share the public CA, which you can find at /opt/tak/cert/files/ca.pem, via some third channel such as email or a USB drive. Once you have traded CAs, go the the Manage Federate Certifate Authorities page and upload the CA of the federate you want to connect to.

8.3 Make the Connection

Now that we have enabled federation and shared our CA with the other TAK server authority, we are ready to make the connection and start sharing. For this step, only ONE of the servers creates an outgoing connection to the other. If you are starting the connection, go back to the Manage Federates page where you enabled federation from step 1. You will now see three sections, Active Connections, Outgoing Connection Configuration, and Federate Configuration. To create an outgoing connection, click on the corresponding link, and enter in the address and port of the destination server. You can also pick the protocol version (make sure it is the right protocol for the port you are connecting to!), reconnection interval (how long between retries if the connection is lost), and whether or not the connection will be enabled on creation.



Now that you have created and started a connection, you will notice that no information is yet flowing between federates. This is because you and your fellow federate must specify which filtering groups you will allow to flow out of and into your server. To manage this, click on the Manage Groups link in the corresponding row of the Federate Configuration section. Here you can specify the groups, including the special __ANON__ group if you want. Once both servers have configured the groups, traffic will start to flow. A server restart is not necessary for these changes to take effect.





Federate Groups


You are configuring groups for federate: thirdServer:thirdTry

A federate is another TAK installation with which you wish to share events.

When events arrive from this federate, you may direct them to devices in the local inbound groups you configure below. Similarly, you may send events to this federate from devices in the outbound groups you configure.

Note: Adding and Removing groups affects the runtime environment immediately, and changes are saved to the configuration file. This configuration is associated with connections based on the certificate provided when the TLS connection is initiated. What is stored in the configuration file is the SHA256 fingerprint of the certificate.

You must select at least one inbound or outbound group to effectively activate this federate.



Groups configured for this federate:

Group	Direction	
ANON	INBOUND	Remove
ANON	OUTBOUND	Remove

Back To Federates

51

8.4 Federated Group Mapping

The flow of traffic between Federates may be directed using end-to-end group mapping. The **Federated Group Mapping** section is on the **Federate Groups** page.


Groups are exchanged during active connections between Federates. The *remote* groups will appear in the 'Remote Group List' drop down in the **Federated Group Mapping** section. Connected Federates must have Federated Group Mapping enabled in order for the Federates to exchange their respective *remote* groups. This parameter is in the **Federation Configuration** section in the Configuration > Manage Federates page.

To configure the end-to-end mapping, select a remote group and map it to a local Federate group. Remote groups may also be entered directly in the 'Remote Group' field. A single remote group can be mapped to many local groups. Additionally, multiple end-to-end group mappings may be defined. With a group mapping configured, traffic from the remote group will only flow to the mapped local group(s). Note: if no incoming traffic matches the remote groups configured, the federation traffic will fall back to the **Federate Group** scheme described previously.

Federate Groups			
You are configuring groups	for federate: takserver:ralph1	L	
A federate is another TAK ir	nstallation with which you wish	to share events.	
When events arrive from thi from devices in the outboun		m to devices in the local inbound g	oups you configure below. Similarly, you may send events to this federate
Note: Adding and Removing connections based on the c	g groups affects the runtime er ertificate provided when the T	nvironment immediately, a <mark>nd c</mark> hang LS connection is initiated. What is s	es are saved to the configuration file. This configuration is associated with tored in the configuration file is the SHA256 fingerprint of the certificate.
You must select at least one	e inbound or outbound group to	o effectively activate this federate.	
Group			
Огоар			
		Search LDAP	
Direction	Both (Inbound/Outbound)	•	
		Add Group	
Groups configured for this for	ederate:		
Group	Direction	n	
Eagle	OUTBOUN	ID	Remove
Dagger	OUTBOUN	ID .	Remove
			Remove
Add remote group and mag	o to local group of this federate remote group may be mapped Select Group Select Group Alpha	e. The Remote Group List will only I to many local groups.	De populated when the federate is connected. Manual entry can be added Remote groups from connected Federate B
Add remote group and mag the Remote Group field. A Remote Group List	o to local group of this federate remote group may be mapped Select Group Select Group	e. The Remote Group List will only to many local groups.	be populated when the federate is connected. Manual entry can be added Remote groups from connected
the Remote Group field. A Remote Group List Remote Group	o to local group of this federate remote group may be mapped Select Group Select Group Alpha	e. The Remote Group List will only to many local groups.	Remote groups from connected Federate B
Add remote group and mag the Remote Group field. A i Remote Group List Remote Group Local Group	o to local group of this federate remote group may be mapped Select Group Select Group Alpha Bravo	to many local groups.	Remote groups from connected Federate B
Add remote group and mag the Remote Group field. A i Remote Group List Remote Group Local Group	or to local group of this federate remote group may be mapped Select Group Select Group Alpha Bravo	to many local groups.	Remote groups from connected Federate B
Add remote group and may the Remote Group field. A Remote Group List Remote Group Local Group	or to local group of this federate remote group may be mapped Select Group Select Group Alpha Bravo for this federate:	to many local groups. Map Group	Remote groups from connected Federate B

8.5 Mission Federation Disruption Tolerance

Traffic between federated servers may be disrupted, and updates to missions could happen during that disruption. Mission federation disruption tolerance will update each server with changes to federated missions that occured during the disruption. To enable this feature, check the box in the Federation Configuration page:




Sending all the changes that occured between disruptions could potentially take a lot of bandwidth, so by default, we limit the changes to those that occured within the last 2 days. For example, if a disruption lasted 3 weeks, we would only send the changes from the previous 2 days. However, if the disruption only lasted a few hours, only the changes since the last disruption would be sent. If the Unlimited checkbox is checked, then all changes since the last disruption would be sent. The 2 day limit can be changed to any length with the Send Changes Newer Than setting, and the period can be selected as days, hours, or seconds.

It is also possible to override the global setting for a particular mission, if so desired.

Unlimited: Send Changes Newer Tha	an'	□ 2			Days	~		
Mission Specific Settings								
Mission: Mission:	mission_2 v	12	Days		llimited: □ llimited: □			
Mission:	mission_4 v	2	Days	√ Un	limited: 🗹	-	+	

For example, in the above image, we see that mission_2 will send updates up to over the last 10 days, mission_2 only over the last 12 hours, and mission_4 will send all updates since the last disruption. Any mission that is not listed, and any subsequently added mission, will follow the global setting of 2 days, as set above.

Federation Configuration



Edit Configuration

The Clear Federation Events button will reset the disruption history for federation. This means that on the next reconnection, the server will send the max allowed mission changes according to the Mission Federation Disruption Tolerance settings. In the above case, that would be 10 days for mission_2, 12 hours for mission_3, and the entire change history for mission_4. For all other missions this would be 2 days worth of mission changes.

8.6 Data Package and Mission File Blocker

Data packages, mission packages, and missions can be federated between servers and their respective ATAK clients. These packages may contain configuration files such as ATAK .pref files that can result in the distribution of unwanted configuration changes to ATAK devices. A filter can be enabled to block files by file-type. To enable this feature, check the Data Package and Mission File Blocker box in the Federation Configuration page. The default file extension value is 'pref'. This can be changed by entering a new file type, clicking on the 'Add' button to add the entry, and clicking on the 'Save' buton at the bottom of the Federation Configuration page.

Data Package and Mission File Filter				
Enable Data Package and Mission File Filter: 🗸				
File Extension: pref				
Add File Extension:	Add	The default extension is .pref.		
Enter the extension of the file type to block in federated data packages and missions.				

8.7 Federation Example

The figure below shows a connectivity graph of two distinct administrative domains. Each administrative domain has multiple sub-groups (e.g. "CN=Alpha") utilizing the group-filtering. The color coding indicates the CA that is used to sign the certificate used for connections. Enclave 1's CA signs ATAK client certs and a server certificate. Enclave 2's CA also signs ATAK client certs and a server cert. The trust-store listing the allowed CAs for the "User Port" only contains a single CA (i.e. *Enclave 1 CA* for Enclave 1). To federate the servers, Enclave 1 and Enclave 2 send each other the "public" CA cert. Those certificates are put in a separate trust store that is used only for federation connections. The "Fed. Port" is configured with this separate trust-store.

The server cert from each administrative domain can now be used to connect to the "Fed. Port" of the other domain.




Figure 1: Federation Example

8.8 Alternate Configuration

The first example had each federate using the same CA and server certificate for local and federate connections. If you are very paranoid, or don't want to share anything about the crypto being used for local clients, you can have a wholly separate CA+server certificate chain that is used for federation. Figure 5 shows how this would work.

This adds some complexity, but can be used if you don't want to expose your 'internal' CA to the organizations that you are federating with.




Figure 2: Alternate Federation Example

9 Metrics

The TAK Server Metrics Dashboard is available in the Monitoring menu. The dashboard continuously renders the following information:

<u>Server Start Time and Server Up Time</u>: This tell you when the server was turned on and how long it has been operating.

<u>Clients Connected</u>: This tells you how many connections your client is currently servicing. This corresponds to the number of clients that are displayed in the client dashboard.

<u>Heap Usage</u>: TAK server runs inside one or more Java Virtual Machines (JVM). Heap Committed is how much heap memory in MB is allocated to the API process for TAK Server, and Heap Used is how much of that is currently being used.

<u>Network I/O and Reads/Writes</u>: This tells you how much TCP and UDP traffic the server is currently handling, as well as a brief history.

<u>CPU Usage</u>: How much of the CPU of the machine the server is running on is currently being used.




Figure 3: Metrics Dashboard

10 Logging

TAK Server provides several log files to provide information about relevant events that happen during execution. The log files are located in the /opt/tak/logs directory. This table shows the name of the log files, and their function.

Name of Log File	Purpose
takserver-messaging.log	Execution-level information about the messaging process, including client connection events, error messages and warnings.
takserver-api.log	Execution-level information about the API process, including error messages and warnings.
takserver-messaging-console.log	Java Virtual Machine (JVM) informational messages and errors, for the messaging process.
takserver-api-console.log	Java Virtual Machine (JVM) informational messages and errors, for the API process.

11 Group Filtering for Multicast Networks

The proxy attribute on the CoreConfig input element (<input ... proxy="true" ... />) was removed in TAK Server 4.1. The intent of the proxy attribute was to control bridging of multicast networks and federating multicast data. As TAK Server's group filtering capabilities have evolved, having a dedicated proxy attribute is no longer needed. Using filtergroup on the mcast input you can achieve greater control over multicast traffic.

The default behavior in TAK Server 4.1 and higher is to put multicast traffic in the __ANON__ group. You can use a filtergroup on the mcast input to put your mcast traffic into a dedicated multicast group, for example:

Then add the __MCAST__ group as a filtergroup on any other inputs you wanted to share multicast traffic with. For example, to share multicast traffic with the tls/8089, configure your input filtergroups as follows:

This same approach works for federations. You can __MCAST__ as an outboundGroup on any federates that you wanted to share multicast traffic with. Using the filtergroup approach allows for creation of input specific multicast groups, allowing control of how messages from multicast networks are routed.

12 OAuth2 Authentication

TAK Server provides OAuth2 Authorization and Resource server capabilities using the OAuth2 Password authentication flow. OAuth2 integration works with existing authentication back ends, allowing TAK Server to issue tokens backed by the File or LDAP authenticators. TAK Server issues JSON Web Tokens (JWT) signed by the server certificate, allowing external systems to validate tokens against the server's trust chain. The OAuth2 token endpoint is available at https://<takserver>:8446/oauth/token.

13 User Management UI

Overview


The User Management UI provides an intuitive drag-and-drop mechanisms for managing TAK user accounts. The tool is integrated within TAK Server and can be accessed from the TAK main menu, under Administrative >> Manage Users. Users need to have an admin role to access the tool. Currently the User Management UI supports only file-based users and not LDAP/AD users.

The tool allows TAK administrators to create, manage, inspect and delete TAK user accounts. More specifically, the tool allows TAK administrators to:


- View, filter and search for existing user accounts and groups.
- View a list of users in each group.
- Change password for each user account.
- View and update groups (IN group, OUT group and both) for each user account.
- Delete user accounts.
- Create a new user account with a specified password and groups. Password complexity is checked to confirm compliance.
- Create new user accounts in bulk with username following a pattern. System uses password generation mechanism to create passwords that meet TAK password complexity requirements. System produces output file with user/password combos as a one-time downloadable item, after which system forgets the un-hashed passwords.
- Create new groups.

Usage


The below figure shows the main page of the User Management UI. The left panel lists all user accounts, which can be filtered using the Search box on the top. The right panel lists all existing groups, which can be filtered using the Search box on the top.



To change user's password, click on the arrow right next to the username and select "Change password".




To view/edit groups for a user account, click on the arrow right next to the username and select "View/Edit groups". You can drag the groups from the right panel and drop to one of the three boxes in the middle panel. Click on "Reset" button to bring the UI back to showing the current groups of the user. Click on "Update" button to update the groups of the user.




To delete an account, click on the arrow right next to the username and select "Delete User". You will be prompted to either confirm or cancel the action.


To list all users in a group, click on the arrow right next to the group name and click on "List users".



To create a new user, click on "Add User" on the menu bar.



To create new users in bulk, click on "Add Users" on the menu bar.



14 Data Retention Tool

Information regarding the use of the Data Retention Tool is available on the tak.gov wiki: https://wiki.tak.gov/display/TPC/Data+Retention+Tool

Appendix A: Acronyms and Abbreviations

ATAK – Android Team Awareness Kit

CA – Certificate Authority (for digital certificates)

CN – Common Name (of a digital certificate)

CoT – Cursor-on-Target, an XML-based data interchange format

CRL – Certificate Revocation List

DoD – Department of Defense (United States)

DISA – Defense Information Systems Agency

ESAPI – Enterprise Security Application Programming Interface

EPL – Evaluated Products List

HTTP – Hypertext Transfer Protocol

IA – Information Assurance

IP – Internet Protocol

IPv4 – Internet Protocol, version 4. The commonly-used version of IP, in which addresses consist of four integers from zero to 255 (inclusive), separated by periods, such as 192.168.123.4

JCE – Java Cryptography Extensions

JDK – Java Development Kit, a JRE with additional tools and libraries.

JKS – Java Key Store

JRE – Java Runtime Environment

KML – Keyhole Markup Language, the XML-based data format used by Google Earth

OS – Operating System

OWASP – Open Web Application Security Project

NIAP – National Information Assurance Partnership

PKCS12 – Public-Key Cryptography Standard #12

TCP - Transmission Control Protocol

RHEL – Red Hat Enterprise Linux

UDP – User Datagram Protocol

SSL – Secure Sockets Layer

TAK – Team Awareness Kit, a mobile or desktop application that sends and receives real-time information through TAK Server.

TLS – Transport Layer Security, a newer and more-secure protocol derived from SSL. The terms SSL and TLS are often used interchangeably. Technically, TLS provides a superset of SSL's capabilities and should always be preferred.

XML – Extensible Markup Language

Appendix B: Certificate Generation

TAK Server includes scripts for generating a private security enclave, which will create a Certificate Authority (CA) as well as server and client certificates.

First, figure out how many client certificates you are going to need. Ideally you should have a different client cert for each ATAK device on your network.

Become the tak user: sudo su tak

Edit the certificate-generation configuration file, at this location:

/opt/tak/certs/cert-metadata.sh

Set options for country, state, city, organization, and organizational_unit.

Change directory:

> cd /opt/tak/certs

Create a certificate authority (CA):

> ./makeRootCa.sh

Follow the prompt to name the CA.

Create a server certificate:

>./makeCert.sh server takserver

this command will result in a server certificate named /opt/tak/certs/files/takserver.jks

Create one or more client certificates. You should use a different client cert for each ATAK device on your network. This username will be provisioned in the certificate as the CN (Common Name). When using certs on devices that are connected to an input that is configured for group filtering without authentication messages, this username will be used by TAK Server to look up group membership information in an authentication repository, such as Active Directory (AD). This command will create a cert for the username user:

> ./makeCert.sh client user

Generate another cert, named **admin** to access the admin UI:

> ./makeCert.sh client admin

The generated CA truststores and certs will be located here:

/opt/tak/certs/files

Follow the instruction on "Configure TAK Server Certificate" to set up the server to use the generated certs and to authenticate users on a TLS port. If using the default configuration, TLS will be correctly set up on 8443.

Become a normal user:

> exit

Restart the TAK Server:

> sudo systemctl restart takserver

Authorize the **admin** cert to perform administrative functions using the UI:

> sudo java -jar /opt/tak/utils/UserManager.jar certmod -A
/opt/tak/certs/files/admin.pem

1 Configure TAK Server Certificate

In /opt/tak, check the following settings in CoreConfig.xml:

- 1. In the <tls> element, the keystoreFile attribute should be set to the server keystore that was generated with makeCerts.sh, above. If you followed the instructions verbatim, the server keystore is /opt/tak/certs/files/takserver.jks.
- 2. Also in the <tls> element, the truststoreFile attribute should be set to the trust store that was generated with makeCerts.sh, above. If you used the default arguments, your trust store file is /opt/tak/certs/files/truststore-root.jks.
- 3. In the <network> element, add a TLS input, specifying group-based filtering without requiring an authentication message:

```
<input _name="stdssl" protocol="tls" port="8089" auth="x509"/>
You can change the port number if you want.
```

Example:

```
<network multicastTTL="5">
      <!-- <input name="stdtcp" protocol="tcp" port="8087"/> -->
     <!-- <input name="stdudp" protocol="udp" port="8087"/> -->
     <input _name="stdssl" protocol="tls" port="8089" auth="x509"/>
     <!-- <input name="streamtcp" protocol="stcp" port="8088"/> -->
      <!-- <input name="SAproxy" protocol="mcast" group="239.2.3.1" port="6969"
proxy="true"/> -->
     <!-- <input name="GeoChatproxy" protocol="mcast" group="224.10.10.1"
port="17012" proxy="true"/> -->
      <!--<announce enable="true" uid="Marti1" group="239.2.3.1" port="6969"
interval="1" ip="192.168.1.137" />-->
</network>
<security>
  <tls context="TLSv1"
         keymanager="SunX509"
         keystore="JKS"
     keystoreFile="certs/files/takserver.jks" keystorePass="atakatak"
      truststore="JKS"
      truststoreFile="certs/files/truststore-root.jks" truststorePass="atakatak">
```

```
(Uncomment the following if you are using a CRL)

<!-- <crl _name="Marti CA" crlFile="certs/ca.crl"/> -->

</tls>
</security>
```

Then (re)start the TAK Server as normal.

2 Installing Client Certificates

Take the truststore-root.p12 and user.p12 files and copy them to your Android device. In ATAK, open Settings->General Settings->Network Settings

and set the SSL/TLS Truststore and Client Certificate preferences to point to those .p12 files.

Repeat the proceedure described above for creating a new server connection, but be sure to select **SSL** as the protocol.

These same .p12 files can be installed in a browser, and used to access the Web UI (for admin use) and WebTAK (for normal users or admins). The process to install these files varies by browser and operating system, but can generally be configured by going to the browser preferences, and the security or certificates section.

Appendix C: Certificate Signing

TAK Clients can enroll for new client certificates by submitting a Certificate Signing Request (CSR) to TAK Server. The Certificate Signing endpoint resides on port 8446 and requires HTTP Basic Authentication backed by either File or LDAP authentication. Ensure that the tomcat connector for port 8446 is active within tomcat-home/conf/server.xml.

The CertificateSigning section in CoreConfig.xml specifies how CSRs are processed. TAK Server can be configured to sign certificates directly, or proxy CSRs to a Microsoft CA instance running Certificate Enrollment Services. To configure TAK Server to sign certificates, set the CA attribute to "TAKServer". To configure TAK Server to proxy the CSR to MS CA, set the CA attribute to "MicrosoftCA".

```
<certificateSigning CA="{TAKServer | MicrosoftCA}">
     <certificateConfig>
           <nameEntries>
                  <nameEntry name="0" value="Test Org Name"/>
                  <nameEntry name="OU" value="Test Org Unit Name"/>
           </nameEntries>
     </certificateConfig>
      <TAKServerCAConfig
           keystore="JKS"
           keystoreFile="../certs/files intCA/intermediate-ca-signing.jks"
           keystorePass="atakatak"
           validityDays="30"
           signatureAlg="SHA256WithRSA" />
     <MicrosoftCAConfig
           username="{MS CA Username}"
           password="{MS CA Password}"
            truststore="/opt/tak/certs/files MSCA/keystore.jks"
            truststorePass="atakatak"
           svcUrl="https://win-kbtud3n1hjl.tak.net/tak-WIN-KBTUD3N1HJL-
CA CES UsernamePassword/service.svc"
            templateName="Copy of User"/>
</certificateSigning>
```

Prior to submitting a CSR, Clients query TAK Server for Relative Distinguished Names (RDNs) that need to go into the CSR. The nameEntries element in CoreConfig.xml specifies the required RDNs, giving the administrator control over generated certificates. The CN value in the CSR will be equal to the HTTP username. TAK Server validates all required fields in the CSR prior to signing.

The extra step of having client query TAK Server for RDNs wouldn't be required if TAK Server were signing certificates exclusively, since TAK Server could just add these names to the certificate.

However, when proxying the CSR to an external CA, this allows additional flexibility in controlling the subject name within the certificate.

The TAKServerCAConfig element specifies the keystore that TAK Server will use for signing certificates. The keystore must hold the CA's private key along with it's full trust chain. The makeCert.sh script will produce a signing keystore when generating an intermediate CA certificate. Certificates signed by TAK Server will be valid for the specified validityDays, and will be signed using the algorithm specified by signatureAlg.

The MicrosoftCAConfig element defines how TAK Server will connect to the Certificate Enrollment Services (CES) endpoint. The CES endpoint is defined by the svcUrl attribute. The CES endpoint must be configured to use Username/Password authentication, and by default will include 'UsernamePassword' in the URL. The username and password attributes refer to an account configured on the MS CA Server to access the the CES endpoint. The truststore and truststorePass attributes point to a Java keystore (.jks) file that contains the trust chain for the svcUrl endpoint. Lastly, the templateName defines the certificate template that will be used to sign CSRs sent from TAK Server.

Appendix D: PostgreSQL TLS Configuration

1 Configure PostgreSQL server to use TLS

- Follow the steps in Appendix B (Certificate Generation) to generate CA keys and certificates if not already done so.
- Generate PostgreSQL server keys and certificates:
- >> cd /opt/tak/certs
- >> sudo su tak
- >> ./makeCert.sh server takdb

Become a normal user

- >> *exit*
- >> sudo chown postgres /opt/tak/certs/files/takdb.key
- Update postgresql.conf. The file location can be different depending on your PostgreSQL installation:

>> sudo vim /var/lib/pgsql/15/data/postgresql.conf

ssl = on

ssl_ca_file = '/opt/tak/certs/files/ca.pem'

ssl_cert_file = '/opt/tak/certs/files/takdb.pem'

ssl_key_file = '/opt/tak/certs/files/takdb.key'

Make sure to update the next line to use the correct passphrase as configured in cert-metadata.sh.

ssl_passphrase_command = 'echo "atakatak"'

ssl_passphrase_command_supports_reload = on

- Update pg_hba.conf. The file location can be different depending on your PostgreSQL installation:

>> sudo vim /var/lib/pgsql/15/data/pg_hba.conf

Add this new line:

hostssl all all cert

Comment out the following lines if you also require SSL authentication for IPv4/IPv6 local connections

host all all 127.0.0.1/32 trust # host all all ::1/128 trust

- Restart PostgreSQL server. Make sure it starts successfully.

RHEL, Rocky Linux, and CentOS installations:

- >> sudo systemctl restart postgresql-15
- >> sudo systemctl status postgresql-15

Ubuntu and Raspberry Pi installations:

- >> sudo systemctl restart postgresql
- >> sudo systemctl status postgresql

2 Generate Client keys and certificates

- Generate client keys and certificates:
- >> cd /opt/tak/certs
- >> sudo su tak
- >> ./makeCert.sh dbclient

Client keys and certificates named "martiuser" (by default) will be created in the "files" directory.

- Test SSL connection using the generated client certificate:
- >> psql "host=127.0.0.1 port=5432 user=martiuser dbname=cot sslmode=verify-ca sslcert=files/martiuser.pem sslkey=files/martiuser.key sslrootcert=files/ca.pem"

If you don't want to verify the server's credential:

>> psql "host=127.0.0.1 port=5432 user=martiuser dbname=cot sslmode=require sslcert=files/martiuser.pem sslkey=files/martiuser.key"

The sslmode "verify-ca" means "I want to be sure that I connect to a server that I trust." The sslmode "require" means "I trust that the network will make sure I always connect to the server I want."

More information on the sslmode can be found here: https://www.postgresql.org/docs/current/libpq-ssl.html

- Test database permission from the psql prompt:

select count(*) from cot_router;

NOTE: If you want to use a different name for certificates, you would also need to add a new user to the PostgreSQL database and grant permissions for the user. For example, following these steps to create a certificate named "takdbuser"

>> ./makeCert.sh dbclient takdbuser

>> sudo su - postgres

Connect to Postgres:

>> psql -d cot

List all users/roles:

\du

SELECT * FROM pg_roles;

Create a new user ("takdbuser") and grant the user necessary roles ("martiuser"). The name of the user must match the CN in the client certificate.

CREATE USER takdbuser;

grant martiuser to takdbuser;

Optional: Double check using \du and "SELECT * FROM pg_roles;"

3 Configure TAK Server to use SSL

- Note that when you created a database client certificate (./makeCert.sh dbclient), an additional private key file in PKCS#8 format was created. Use this file for the param sslkey in CoreConfig.xml instead of using the files with .key extension.
- Update CoreConfig.xml:

Update the <connection> tag in <repository> (Remember to use a correct hostname/IP)

<connection url="jdbc:postgresql://127.0.0.1:5432/cot" username="martiuser" sslEnabled="true"
sslMode="verify-ca" sslCert="certs/files/martiuser.pem" sslKey="certs/files/martiuser.key.pk8"
sslRootCert="certs/files/ca.pem"/>

If you don't want to verify the server's credential (not recommended in production):

<connection url="jdbc:postgresql://127.0.0.1:5432/cot" username="martiuser" sslEnabled="true"
sslMode="require" sslCert="certs/files/martiuser.pem" sslKey="certs/files/martiuser.key.pk8" />

- Start/Restart TAK server.
- >> sudo systemctl restart takserver