
Vector field analysis at endpoints
Angle x
Angle y
Angle z
Vector size (mm)
pos y (mm)
pos x (mm)
pos z (mm)
pos x (mm)
pos z (mm)
pos y (mm)

Tramp adaptations analysis. Beam: 0







Tramp adaptations analysis. Beam: 1







Tramp adaptations analysis. Beam: 2







Tramp adaptations analysis. Beam: 3