


# E300 ASSEMBLY


## STEP BY STEP INSTRUCTION

### Step 1: Screw 04 fan screws out



Unscrew to remove the metal plate of the box

## Step 2: Put FPGAs into the box shell




#### **Notice:**

E300 miner uses two types of heatsink: 20 mm heatsink and 27.6 heatsink

- FGPA0 & FPGA1 use 27.6mm heatsink
- FPGA2 use 20mm heatsink


## Step 3: Screw 04 fan screws in







Screw 4 screws back to close the box

# Step 4: Plug the cables from FPGAs to zynq board and fans to zynq board





## STEP 5: Connect FPGAs to Power Supply Unit (PSU)



- Power supply for FPGA cards is 12V
- For safety reason, two PCIE 6 pin power of each board should come from the same PSU source.



#### **SUPPORT AND SERVICE**

- Email: support@ospreyelectronics.io
- Phone: +1 (469) 409-2818
- Website: Ospreyelectronics.io