

Intro to DeepStream NVIDIA JETSON



Content



- Review DeepStream pipeline
- Introduction to RTSP
- Introduction to ONVIF
 - RTSP Structure
 - DeepStream-app config file RTSP example



Connection string example

rtsp://USERNAME:PASSWORD@192.168.1.5/cam/realmonitor?



Connection string example

rtsp://USERNAME:PASSWORD@192.168.1.5/cam/realmonitor?

Protocol



Connection string example

rtsp://USERNAME:PASSWORD@192.168.1.5/cam/realmonitor?

Protocol

Camera/

Camera/

DVR/NVR

DVR/NVR

Username

Password



Connection string example

rtsp://USERNAME**:**PASSWORD**@**192.168.1.5**/**cam/realmonitor?

Protocol

Camera/

Camera/

Camera/

DVR/NVR

DVR/NVR

DVR/NVR

Username

Password

ΙP



Connection string example

rtsp://USERNAME:PASSWORD@192.168.1.5/cam/realmonitor?

Protocol

Camera/

DVR/NVR

Username

Camera/

DVR/NVR

Password

Camera/

DVR/NVR

ΙP

Default real-time stream



Connection string example: additional commands

rtsp://USERNAME:PASSWORD@192.168.1.5/cam/realmonitor?channel=1&subtype=0

Camera number (DVR/NVR) Stream quality (HD/SD)



Common alternatives

- rtsp://admin:12345@192.168.1.210:554/cam/realmonitor?channel=1&subtype=1
- rtsp://admin:12345@192.168.1.210/unicast/c2/s2/live
 - rtsp://admin:12345@192.168.1.210/media/video2
 - rtsp://admin:12345@192.168.1.210:554/Streaming/Channels/101
 - rtsp://192.168.1.210:554/Streaming/Channels/101



DeepStream-app


config_infer_primary.txt

```
6  [source1]
7  enable=1
8  type=4
9  uri=rtsp://admin:12345@192.168.1.210:554/cam/realmonitor?channel=1&subtype=1
10
11  [source2]
12  enable=1
13  type=4
14  uri=rtsp://admin:12345@192.168.1.210:554/cam/realmonitor?channel=2&subtype=1
```



DeepStream-app

Tip: first test RTSP stream with VLC





Thank You