## Note:

Sometimes, Pytorch and torchvision installation with pip commands, not works on some projects. Therefore, in these cases, we will need to install specific packages first. For that type of installations, you can visit <u>link</u>

