
Storage Instructions for Power Grid

Important: Always store the Wind Turbine in the case with the **blades up.** Handle this model with utmost care

- 1. Unplug the USB B cable from the Power Grid and your computer and twist tie the cable.
- 2. Unplug the 5 volt DC power from the Power Grid case twist-tie the cable.
- 3. Unplug each USB C cable from the Power Grid case but leave connected to the model.
- 4. Remove each model from the metal surface by tipping it slightly and then lifting it up.
- 5. Unplug each USB C cable from the model.
- 6. Twist-tie the 5 USB C cables together.
- 7. Open the Power Grid case and place each model in its corresponding compartment.
 - a. Important: Store the wind turbine with the blades facing up. Do not force them down into the foam. When storing the Wind Turbine, the model's blades should be facing up
 - b. The Power Plant should be stored in the Left-Front square hole with the cooling tower laying down.
- 8. Place the power supply in its corresponding compartment on the left side and its cable in the opening in the back left.
- 9. Place the 5 USB C cables and the 1 USB B cable in the compartment in the back.
- 10. Close the cover of the Power Grid case and snap the clasps closed. Be sure these are securely closed.



Store Wind Turbine Blades Up

Plant with **Cooling Tower** laying down

Store the Power Grid components as in the picture above