

# How the wrist band decides: REST · MOVE · TREMOR

No maths needed to run the demo — the band just checks two things every 2 seconds, then lights up one of three states.

**Do this first (set-up):** Hold your wrist *still* and press **button A**. The band learns *your* normal resting hand, so the “line” it compares against is personal to you. (Until you do, the ring glows dim **white** = “not calibrated yet”.)

Every 2 seconds, it measures two things about your wrist:

## 1. Arm movement

Big, slow motion — reaching, waving, walking. “Are you using your hand *on purpose*?”

## 2. Tremor shake

A fast, fine, *rhythmic* shake while the hand is otherwise still — the Parkinson’s resting tremor.

Then it picks one of three — checked in this order:

### 1 MOVE

#### Arm is moving about.



You’re doing something on purpose. A resting tremor only shows *at rest*, so the band stays quiet — no false alarms on normal activity.

**You’ll see:** dim **teal** ring · screen says *moving*

### 2 TREMOR

#### Still, but shaking past your line.



Hand at rest *and* trembling more than your calibrated normal — so it flags a tremor. Stronger shake → more lights fill the ring.

**You’ll see:** **amber** bar (length = strength) · screen says *TREMOR present*

### 3 REST

#### Still and calm.



No big movement, no tremor shake — nothing going on. All clear. The default whenever the other two aren’t true.

**You’ll see:** soft **green** ring · screen says *no tremor*

**Show it in three moves:** 1. Hold still → **REST** (green). 2. Wave your hand around → **MOVE** (teal). 3. Rest your hand and shake it fast → **TREMOR** (amber).

**If someone asks “how does it know?”** — the one-line answer: “*It measures how strongly the hand shakes at a tremor’s rhythm, and whether you’re otherwise still.*” (Under the hood that’s the strength of 4–6 Hz shaking, and it waits for two readings in a row before switching — but you don’t need to say any of that to run the demo.)