
Uninstalling Orbbec Depth Sensor Windows Driver

1. Try Removing the Driver with the Control Pannel


If the driver was installed as a Windows Driver Package, please remove it with "Control Pannel" -> "Programs and Features" -> "Uninstall or change a program" utility.




Note: you may get an error for this, please ignore it and continue with the following steps

2. Uninstall the device/driver from Device Manager

Connect Orbbec Astra(and HP Orion Module if the driver for it has been installed) to the computer, then open the Device Manager within the Computer Management utility, trigger the popup menu on "Orbbec Depth Sensor", and select "Uninstall". In the following "Confirm Device Uninstall" box mark the checkbox of "Delete the driver software for this device", and then confirm the uninstall






3. Cleanup the Registry

Run regedit.exe, navigate to and delete the following entries if any of them exists: ©2015, ORBBEC Co., Ltd.

- "HKLM\SYSTEM\CurrentControlSet\services\obdrv4"
- "HKLM\SYSTEM\CurrentControlSet\services\obdrv"
- HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\Class\{07B55A11-9E 3D-4584-B13B-4DBF3DA3ADD6}
- HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\Class\{0B784744-EA75-463B-B28B-80F5A0C7FB6B}



2a9fe532-0cdc-44 3163C566-D381-4

Computer\HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\Class\{07b55a11-9e3d-4584-b13b-4dbf3da3add6}