


SAFE WORK METHOD STATEMENT

Persons responsible for supervising, inspecting work, work methods, plant & equipment and tools	Supervisor/Foreman: _____	Date: _____
High Risk Construction Work:	WATER JETTING – SAFE OPERATION	Project: _____
SWMS prepared by Patrick Monaghan - Paneltec Group - Operations Manager and in consultation with management and workers – 2025. SWMS Review Date: August 2026 unless required earlier		Location: _____
Approval to use this SWMS: "I certify that the attached SWMS has been reviewed by me, is endorsed for compliance with WorkSafe guidelines and is approved for use"		
<u>John Guy</u> Name	<u>Director - Paneltec Pty Ltd</u> Position	<u>0408 449 023</u> Phone
 Signature		<u>22/08/2025 – V12.0</u> Date

RISK MATRIX

Level	Description of Consequence or Impact	Consequence	Likelihood / Probability		
			L Likely	M Moderate	U Unlikely
H (1) (High level of harm)	Potential death, permanent disability or major structural failure/damage. Off-site environmental discharge/release not contained and significant long-term environmental harm.	H (1) (High)	1	1	2
M (2) (Medium level of harm)	Potential temporary disability or minor structural failure/damage. On-site environmental discharge/release contained, minor remediation required, short-term environmental harm.	M (2) (Medium)	1	2	3
L (3) (Low level of harm)	Incident that has the potential to cause persons to require first aid. On-site environmental discharge/release immediately contained, minor level clean up with no short-term environmental harm.	L (3) (Low)	2	3	3
Level	Likelihood / Probability				
Likely	Could happen frequently				
Moderate	Could happen occasionally				
Unlikely	May occur only in exceptional circumstances				

HIERARCHY OF RISK CONTROL

The hierarchy of controls must be applied in the order below for all identified hazards.

Level 1 Eliminate the hazard
Level 2 Substitute the hazard with something safer.
Level 3 Isolate the hazard from people. Reduce the risks through engineering controls.
Level 4 Reduce exposure to the hazard using administrative actions.
Level 5 Use personal protective equipment The control measures that you put in place should be reviewed regularly to make sure they work as planned

ACTIVITY ANALYSIS

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
Training and skill.	Un-trained persons could cause injury to themselves and others. Possible property damage.	2	1. All persons on site must have a 'Construction Induction Card'. 2. All persons shall be inducted with the customer where and if necessary, a site-specific induction shall be completed (i.e. TasWater, Tas Gas Induction Card) 3. All persons working on site must be suitably licensed, trained and competent in the work they are to perform. 4. Type A Water Jetting Accreditation must be held by the jetting operator and the jetting operation must be <5600 BLPM 5. All Water Jetting and any Non-Destructive Digging (NDD) operations shall be in accordance with the operating manual for the particular Vacuum Truck and the employee's training provided.	Management Operators	3
Personal Protective Clothing & Equipment (PPE)	Personal injury from high water pressure. Particles flicking up from ground surface. Getting wet.	2	1. Minimum PPE to be worn on site is: • High visibility work attire/cotton clothing - full length sleeves and pants • Safety boots/gumboots • Hard hat • UV skin protection • Hearing protection • Eye protection – Safety Glasses & or Face Shield • Rubber/Latex Gloves • Waterproof disposable coveralls	Operators	3
Site Specific Risk Assessment (SSRA)	Hazardous site specific and environmental parameters affecting the capacity for employees to adhere to these SWMS in a safe working manner.	2	1. Conduct Tailgate Meeting with all on-site concerned with the jetting or NDD works including Traffic Controllers 2. Complete Construction-Excavation SSRA within the Lucidity Platform 3. List any site-specific hazards that may be prevalent and introduce control measures to mitigate all inherent risk to as low a reasonably practicable. 4. Reference Paneltec SWMS applicable to the site in the SSRA 5. Ensure all workers are signed onto the SSRA and submit.	Lead Operator	3
Setting up work area	Slips, Trips & Falls	2	1. Cover protruding objects with a Traffic Cone to prevent slips trips & falls. 2. Check work area for additional hazards (low points,	Operator	3

			boggy areas) and note controls implemented within the Lucidity SSRA.		
	Injury to public	2	1. Place two 'Danger' High Pressure Water Jetting Signs at either end of the jetting area 2. Prevent pedestrian access to the site using traffic cones and extendable tiger tailed barriers where necessary.	Operator	3
Pre-start checks	Damage, injury	2	1. Conduct relevant Vacuum truck Pre-start in Lucidity 2. Check emergency stops for correct operation. 3. Ensure all safety interlocks are in place and effective on the truck and any additional remote control 4. Ensure the correct size nozzle is fitted to the lance for the size of the truck, FX60 =0.55, FXT50 = 0.45 ect 5. Check the high-pressure pump and lance for security integrity - check for cracks on welded sections examine lance for damage/defects and loose bolts and or nuts 6. Inspect jetting hose for any obvious signs of damage/abrasion or wear and tear – do not proceed with the jetting project if the hose is deemed to be unsafe, return to the depot and tag out the truck. 7. Have precautions been taken to protect any exposed electrical equipment (electrical isolations/ interlocks etc.) 8. Check water tank and filter- be sure to fill water tank before commencement of work. 9. Only operators are to be in the vicinity of water jetting operation. 10. Complete Vacuum Excavation permit if undertaking NDD works	Operator	3
Operation of Water jetting equipment	Personal Injury	2	1. Release the pressure from handgun - depress the trigger for short period of time allowing the trapped air in the system to escape. This will assist in the prevention of a kick at the start of operation. 2. Prepare vacuum hose in accordance with vacuum truck SWMS. 3. All further jetting operations are to be undertaken in accordance with the manufactures operating instructions for the truck in operation. 4. Ensure that the pressure does not exceed 2000Kpa when jetting upon any underground assets 5. High pressure water jetting must <u>not be</u> carried out on asbestos or asbestos containing material	Operator	3

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
Start the equipment	Damage, injury	2	1. Ensure all moving parts are free of loose clothing, hoses and body parts. 2. Be aware there may be a kick at the start.	Operator	3
Commence Operation	Damage, injury Repetitive movement	2	1. Position yourself in a non-slippery area and use your legs for support. 2. Do 5 minutes of water jetting and then clean up area. 3. No horseplay.	Operator	3
	Entanglement in hose	2	Maintain tidy work area.	Operator	3
Water jetting & excavation increases in dept and size that would allow a person into the excavation	Falls, excavation becomes a deep excavation (greater than 1500mm)	1	4. Be aware that after the depth increases to greater than 1500mm, the Vacuum & Mechanical Excavation Permit MUST be completed	Operator	2
After completion shutdown the motor	Damage, injury	1	1. Ensure ignition key for water pump is switched off. Release the remaining water pressure in the system.	Operator	2

NEVER:

- Never point the nozzle of the gun close to any parts of your body or to somebody else / Never point the nozzle of the gun closer to any breakable or fragile parts of the equipment
- Never use when there are leaks in the hose or fittings / Never spray when you are not in a good position to hold the gun properly
- Never spray when the water tank is run dry

ALWAYS:

- Always keep your balance - support your body with your legs / Always grip the handle of the gun firmly before pulling the trigger
- Always counteract the high pressure spray force by securely positioning your hand and feet / Always stop spraying when you feel fatigue and unsure of what you are doing
- Always keep a distance from you to your work / Always wear a full face shield or eye protection

ENVIRONMENTAL RISK ASSESSMENT & CONTROL MEASURES THAT MAY BE REQUIRED ON SITE DEPENDING ON THE ACTIVITY					
Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Emergencies	Accident/ Incident Fire Spill	1	1. Personnel have been advised at toolbox meeting and are prepared in the event of an incident occurring. 2. Emergency numbers available on site. 3. Fire Extinguishers/First Aid Kits/Spill Kits on site.	Supervisor All	2
Air Quality	Exhaust Fumes Dust	2	1. Control exhaust emissions eg. Regular maintenance, replace old machinery, fit appropriate emission control measures. 2. Dampen milled surface with water cart. 3. Use water cart where required.	Supervisor All	3
Community Relations	Inconvenience as a result of works/traffic management	2	1. Identify from the list of potentially impacted parties who may be impacted by the work being undertaken. 2. Letter drops could be considered (unless specifically required) to notify residents/businesses etc. about works to be undertaken and if it has an effect on them.	Supervisor All	3
Flora & Fauna	Some works may require the removal of vegetation. Native fauna may be at risk from excavation works	2	1. Assess work area for significant vegetation: size of trees, faunal habitat - define work and exclusion areas using fencing and signage. 2. Machinery is to be thoroughly washed down prior to leaving site where noxious weeds are present.	Supervisor All	3
Heritage & Archaeology	Unmonitored excavation at significant sites can lead to loss or destruction of valuable artifacts/relics, and disturbance of historical sites. including cultural heritage and/or archaeological significance	1	1. Undertake a survey of the site to identify any areas of significance. The client's representative may undertake this. Government bodies may be able to assist. 2. Develop a project specific procedure based on the findings and recommendations. 3. Installation of exclusion fencing and signage if required.	Supervisor All	2
Noise Pollution, Community Relations & Vibration	Sensitivity to noise - to public & fauna	1	1. Work undertaken during "normal" hours where possible. 2. Affected residents notified in person or in writing. 3. Plant and equipment regularly serviced & fitted with efficient mufflers. 4. Magnitude of vibration reduced by using smaller plant etc.	Supervisor All	2

Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Soil Management & Water Quality	Soil needs to be managed to ensure that; there are no off-site impacts. Damage to stockpile areas (not prepared properly). Mud deposited onto roadways.	2	1. Wash down machinery in only nominated areas. 2. Not within 20 metres of water courses. 3. Use only approved and nominated stockpile areas. 4. Build bund wall out of material available on site. 5. Drivers to check vehicle tyres/bodies for build up of mud when leaving stockpile sites and remove if necessary.	Supervisor All	3
Fuels and Chemicals	Contamination of waterways due to spillages of oil, degreasers, diesel, etc.	1	1. Store fuel and chemicals in accordance with relevant standards/guidelines. 2. Minimise storage on site and locate storage facilities away from drains and waterways. 3. All containers clearly labelled and Safety Data Sheets are available on site. 4. All drums stored securely and in a bunded area. 5. Spill kits or alternative spill containment materials available on site. 6. Regular maintenance of plant hoses. 7. Use correct refuelling equipment.	Supervisor All	2
Visual Impact Litter and Amenities Waste Management	Litter such as paper, plastic, and other refuse as well as being a possible safety risk may be carried off-site or washed into waterways resulting in pollution and danger to native fauna. Litter is also visually obtrusive. Production generated lighting, litter, mud, dirt and dust may also impact residents.	2	1. Use site induction to communicate the requirement for a tidy site. Also stress consideration for local residents. 2. If as a result of our works, dirt, mud, or litter affects a resident, then we will rectify this problem immediately. 3. Inspect the site frequently and insist on tidiness. Ensure public roads are free of dirt/mud from the work site. 4. Broken-out paved surfaces shall be repaired as soon as possible. 5. Remove all rubbish from site each day. 6. Waste products will be recycled where possible.	Supervisor All	3

Personal Protective Equipment						
All site personnel must wear the required PPE specified in the controls above, such as:						
Safety Hi-vis Vests/Shirts	Safety Boots	Sunscreen	Broad Brimmed Sun Hat	Sunglasses	Gloves specific to the task	White reflective overalls/night
Hard Hat where required	Safety Glasses	Hearing protection where required	Long clothing	Dust masks	Respiratory equipment if required	
Workers may require Task Specific Training depending on activity each worker will be required to fulfill.						
All workers shall hold a current Construction Induction Card						
- If required Client Site Induction - Activity Induction (SWMS & SWP's)		Vehicle Licences (Car or Truck depending on class of vehicle or mobile plant driven)		Plant Operators licences or competency assessments where required		Competencies for Work Zone Traffic Management
First Aid certificate training		Manual Handling training		Fire Extinguisher training		Fatigue Management Training
A Site Specific Induction & Toolbox Meeting will be held each day prior to the start of each job.						
Legislation & Codes of Practice (refer to company Legislation register for applicable Australian Standards applicable to works)						
Work Health & Safety Act 2012 and Work Health & Safety Regulations 2022						
Codes of Practice						
Confined Spaces - 2020	Hazardous Manual Tasks - 2020		Managing Noise & Preventing Hearing Loss at Work-2020		Managing Risks of Plant in the Workplace - 2020	
Construction Work - 2020	How to Manage WH&S Risks - 2018		Managing Risk of Falls at Workplaces - 2020		Managing Electrical Risks in the Workplace -2019	
Excavation Work - 2020	First Aid in the Workplace - 2018		Managing Work Environment & Facilities - 2020		WHS Consultation Co-operation & Co-ordination - 2018	
Welding Processes - 2021	How to Safely Remove Asbestos - 2020		Managing Risk of Hazardous Chemicals - 2018		Safe Design of Structures - 2018	
Guide for managing risks	From High pressure water jetting 2020					
Plant & Equipment for this activity						
- All plant is inspected prior to sending out to site - Daily maintenance & service checks. - Daily pre-start checks are conducted on all plant and trucks by the operators and daily checklist filled out. - Regular servicing at 250hr intervals or as per manufactures specifications. Service History available on request to the office.						

WORK ACTIVITY BRIEFING

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.