



SAFE WORK METHOD STATEMENT

Persons responsible for supervising, inspecting work, work methods, plant & equipment and tools	Supervisor/Foreman	Date:	
High Risk Construction Work:	CONCRETE PLACEMENT	Project:	
SWMS prepared by Patrick Monaghan - Paneltec Group -Operations Manager and in consultation with management and workers – 2025 SWMS Review Date: August 2026 unless required earlier		Location:	
Signature: _____ 			
Approval to use this SWMS: "I certify that the attached SWMS has been reviewed by me, is endorsed for compliance with WorkSafe guidelines and is approved for use"			
<u>John Guy</u> Name	<u>Director - Paneltec Pty Ltd</u> Position	<u>0408 449 023</u> Phone	<u></u> Signature
			<u>31/08/2025 – V12.0</u> Date

RISK MATRIX

Level	Description of Consequence or Impact	Consequence	Likelihood / Probability		
			L <i>Likely</i>	M <i>Moderate</i>	U <i>Unlikely</i>
H (1) <i>(High level of harm)</i>	Potential death, permanent disability or major structural failure/damage. Off-site environmental discharge/release not contained and significant long-term environmental harm.	H (1) <i>(High)</i>	1	1	2
M (2) <i>(Medium level of harm)</i>	Potential temporary disability or minor structural failure/damage. On-site environmental discharge/release contained, minor remediation required, short-term environmental harm.	M (2) <i>(Medium)</i>	1	2	3
L (3) <i>(Low level of harm)</i>	Incident that has the potential to cause persons to require first aid. On-site environmental discharge/release immediately contained, minor level clean up with no short-term environmental harm.	L (3) <i>(Low)</i>	2	3	3
Level	Likelihood / Probability				
Likely	Could happen frequently				
Moderate	Could happen occasionally				
Unlikely	May occur only in exceptional circumstances				

HIERARCHY OF RISK CONTROL

The hierarchy of controls must be applied in the order below for all identified hazards.

Level 1 Eliminate the hazard
Level 2 Substitute the hazard with something safer.
Level 3 Isolate the hazard from people. Reduce the risks through engineering controls.
Level 4 Reduce exposure to the hazard using administrative actions.
Level 5 Use personal protective equipment The control measures that you put in place should be reviewed regularly to make sure they work as planned

ACTIVITY ANALYSIS

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
Training	To prevent injuries or illness to workers	1	1. Machinery operators will have the necessary current licence for the equipment they will operate. 2. All persons will have a current construction induction card.	Supervisor All	2
Arriving on site	Entry unsafe or unauthorised areas	1	1. Report to site office for site induction if required. 2. Risk assessment of site conditions and Site specific induction & toolbox meeting to be conducted. 3. Consider all environmental protection issues and the impact caused by entry to site.	All Supervisor	2
General planning	Task specific injuries due to inexperience, inadequate consultation or failure to provide appropriate equipment.	2	1. Workers to be have sufficient skills and are competent to complete concreting tasks. 2. Adequate consultation required between supervisor and workers on task to be undertaken. 3. Workers completing works to be adequately supervised. 4. Appropriate concreting equipment to be supplied for use by workers. 5. Workers not to improvise with inappropriate equipment.	Supervisor	3
	Slips, trips, falls, abrasions, strains and sprains; manual handling injuries such as back damage.	2	1. There should be a clear space of a min. 550mm wide around the work area. 2. Access ways to be suitably defined (there needs to be a clear access for concreters and their equipment). 3. Access to work area not to be cluttered – good housekeeping (keep stored materials and rubbish out of work area).	Supervisor Workers	3
Site Access	Potential physical injury to workers, truck drivers or the general public. Electrocution	1	1. Ensure all planning and site preparation takes into account how concrete will be placed allowing room for trucks, ramps for wheelbarrows, space for a pump etc. 2. Clear access must be provided to transport the concrete. 3. If concrete is to be delivered by trucks make sure they have unrestricted access to the site in all weather conditions. 4. A spotter (traffic controller) to be provided where required to assist in conditions involving reversing, low clearance (eg powerlines), obstacles, tight access, high vehicle, concrete pump and/or pedestrian traffic.	Supervisor	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
			5. Traffic control to be provided where necessary on public roads by competent personnel. 6. There needs to be a safe route to the unloading point (including adequate signage). 7. Stable ground surface (freshly filled ground can present a problem for heavy trucks). 8. Delivery point to be clear of any building rubbish or materials. 9. There needs to be a safe exit from site ensuring a safe area is selected to pull off the road and that no road rules are breached if road side delivery is required.		
Laying Concrete	Skin cancer; sunburn, eye damage. Skin rash or allergy/dermatitis. Concrete splashed in eye. Short or long term health affect, e.g rash, allergy, Dehydration & dizziness.	2	1. Workers on the site should always wear protective clothing, strong boots and, if required, helmets or eye protection. (AS rated sunglasses to be worn). 2. Always avoid direct contact with cement and never kneel in or touch the concrete mix directly. 3. Wear gloves or use barrier creams. 4. Refer to Safety Alerts on "Working Safely with Wet Concrete and Working Safely with Dry Concrete Materials" 5. Ensure that anyone using heavy equipment, such as screeds or vibrators, has been properly trained. 6. Water to be made available to flush concrete from eyes. 7. Eye protection to be worn for tasks where splashing occurs, e.g. vibrating. 8. Barrier cream to be made available for use and used as required by workers. 9. SDS to be available on site. 10. All Safety instructions to be followed. 11. Adequate supply of cold drinking water provided to the work area.	Workers	3
Pumping Concrete	Violent ejection of concrete from hose at first moment of delivery. Struck by concrete which may cause body injuries;	1	1. Warning to be given prior to starting or re-commencing the pour. 2. Make sure there is no air in hose due to: a blockage; a change of supply; a poor mix – too bony; or delays in the pour. 3. Make sure the delivery hose is not damaged.	Delivery Operator	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
	Delivery pipe/joint failure. -Struck by concrete or piece of pipe, which may cause body injuries;		- Competent person in control of Tbar at end of hose. - Make sure all connecting pipes are adequately secured, e.g. no safety pins for lever couplings. - Make sure joint or pipe section brackets are not fixed too far apart causing excessive movement. - Ensure pipe operating pressure is not exceeded and the correct diameter pipe is used.		
Person holding "Tbar" placing concrete & person behind holding "J" hook	Manual handling injuries Strains and sprains; injuries such as back damage.	2	"Tbar" & "J" hook operators to be well coordinated to ensure hose can be manoeuvred with ease. "Tbar operator to be experienced- work with recoil and not against it. - Supervisor to ensure enough workers allocated to assist with tasks. - Correct manual handling techniques to be employed when lifting and moving hose around. - Rotate jobs.	Operators Supervisor Operators Supervisor	3
Access	Walking on deck during pour-slip on wet ply or reinforcement and fall; trip or twist ankle or knee. Sharp edges penetrations or steps in the deck, e.g. deep beams Cuts from reinforcement bar ends or tie wire. Fall through penetration or into deep beam.	2	- Persons should walk forward and not backwards during delivery. - Persons to watch where they are stepping so as not to get boots caught between steel reinforcement – different sized reinforcement occurs over the work area. - Ensure there are enough ties or chairs to prevent steel reinforcement sagging or giving way. - Make sure Tbar doesn't slip off the end of the hose. - Make sure there are caps on the ends of reinforcement bar/s, e.g. column starter bars. - Make sure Tie wire is turned down into reinforcement cage. - Be aware that Tie wire can puncture boots. - Planks need to be provided to cover deep beams. - Penetrations need to be covered and covers secured.	Persons on site	3
Vibrator and Operator	Hearing damage from continuous noise over a long period Splashes in eye. Explosion	2	- Equipment that has a high noise level should be quietened where possible. - Hearing protection should be worn where equipment has a noise level above 85dBA.	Supervisor Workers	3

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
	and/or fire; burns; rashes or allergies from contact with bare skin. Illness; breathing difficulties – overcome by fumes. Electric shock or electrocution. Slip on wet ply or Reinforcement and fall; trip or twist ankle or knee. Strains and sprains; injuries such as back damage.		3. Eye protection to be worn. 4. Sufficient water to be made available in work area for first aid treatment eg to flush concrete from eye/s. 5. Fuel should be stored in appropriate fuel containers. 6. Funnel to be made available for refueling. 7. No Smoking near fuel. 8. Equipment to be switched off and cool prior to refuelling. 9. Correct PPE to be worn when refuelling. 10. When electric vibrator used an Earth Leakage switch to be installed on mains supply or portable generator. 11. Equipment to be checked prior to use to ensure it is not faulty or damaged. 12. Extension leads to be checked prior to use to ensure they are not damaged. 13. Extension lead to be secured above work area – so it is not lying in water. 14. All electrical gear used on site should have a current test tag. 15. Operator not to walk backwards while operating vibrator.		
Shoveling	Manual handling injuries. Strains and sprains; injuries such as back damage. Slip on wet ply or Reinforcement and fall; trip or twist ankle or knee.	2	1. Workers should be given sufficient rest periods between jobs. 2. Rotate jobs -repetitious twisting and shoveling, or raking can cause injuries. 3. Make sure concrete not too dry – this will make it difficult to work with and may cause injuries. 4. Workers not to walk backwards while shoveling. 5. Workers to be aware of there surroundings when getting in and out of concrete to make sure they don't slip or fall or get their boots caught between steel reinforcement.	Supervisor Workers	3
Screeding	Manual handling injuries Strains and sprains; injuries such as back damage. Hearing damage from continuous noise over a long period.	2	1. Mechanised screed to be used where practicable. 2. Sufficient rest periods between jobs. 3. Job rotation to prevent repetitious twisting and shoveling, or raking. 4. Clear access around the perimeter of the work area (min. 550 mm wide).	Supervisor Workers	3

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
Bull float	Strains and sprains; injuries such as back damage. Trip on float and fall onto the deck, onto rubbish or building materials.	2	1. Sufficient rest periods between jobs to prevent repetitious arm and wrist movement. 2. Rotate jobs where possible. 3. Need to have clear access around the perimeter of the work area where access is not cluttered with stored materials and/or rubbish which leave no room to pull the float straight back. 4. Need to watch out for the float when walking behind the operator. 5. Operator needs to swap hand frequently.	Supervisor Workers	3
Hand trowelling	Slips, trips	2	1. Need to have clear access around the perimeter of the work area (min. 550 mm wide). 2. Area around work area not to be cluttered with stored materials and/or rubbish.	Supervisor Workers	3
Helicopter float	Loss of control resulting in a strain or sprain or serious cut. Blade strikes body part causing a serious cut. Strains and sprains; injuries such as back damage. Explosion and/or fire; burns; Illness; breathing difficulties – overcome by fumes. Hearing damage from continuous noise over a long period.	1	1. Operator to be trained and competent in the use of the helicopter float. 2. Operator is to watch what they are doing at all times. 3. Make sure there are no objects are protruding from the slab, e.g. reinforcement or stressing duct, that can stop the blade or catch on the guards. 4. Operator to be aware that the momentum may throw the operator. 5. Machine to be checked prior to operation to ensure it is in good condition. 6. Machine maintenance needs to be up to date 7. Machine guards need to be in place prior to the start of the job. 8. Make sure the Pin securing the machine blade is not loose or worn which could result in blade falling off. 9. Make sure the extension carry bar is in place and not too short. 10. Use a crane where possible to lift the machine. 11. Fuel should be stored in appropriate fuel containers. 12. Funnel to be made available for refueling.	Supervisor Workers	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls In Place
			13. No Smoking near fuel. 14. Equipment to be switched off and cool prior to refuelling. 15. Correct PPE to be worn when refuelling. 16. Make sure there is a scrubber, or catalytic converter fitted to exhaust. 17. Year hearing protection where equipment signed.		
Sealing concrete curing	Sprayed sealing compound may cause skin rashes and/or allergies	2	1. Correct PPE- protective clothing, gloves, boots, eye goggles and face masks to be supplied and worn when using sealing compound. 2. Workers to be careful not to breath in fumes from chemicals. 3. If chemicals come in contact with skin or eyes wash area with plenty of cool water and seek doctors advice. 4. Always read the safety directions on the label (or SDS) of any chemical container prior to use. 5. Take note of wind direction when spraying compound and warn other workers of potential drift.	Supervisor Worker	3

ENVIRONMENTAL RISK ASSESSMENT & CONTROL MEASURES THAT MAY BE REQUIRED ON SITE DEPENDING ON THE ACTIVITY					
Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Emergencies	Accident/ Incident Fire Spill	1	1. Personnel have been advised at toolbox meeting and are prepared in the event of an incident occurring. 2. Emergency numbers available on site. 3. Fire Extinguishers/First Aid Kits/Spill Kits on site.	Supervisor All	2
Air Quality	Exhaust Fumes Dust	2	1. Control exhaust emissions eg. Regular maintenance, replace old machinery, fit appropriate emission control measures. 2. Dampen milled surface with water cart. 3. Use water cart where required.	Supervisor All	3
Wet Concrete	During heavy rain, recently placed concrete could emulsify and wash into surrounding waterways.	1	1. Plan concrete operation so that it is conducted during fine weather. 2. Have material available to clean up a spill if it occurs and dispose of contaminated material accordingly. 3. Protect storm drains during and after application to prevent pollution - have spill clean-up materials available.	Supervisor All	2
Community Relations	Inconvenience as a result of works/traffic management	2	1. Identify from the list of potentially impacted parties who may be impacted by the work being undertaken. 2. Letter drops could be considered (unless specifically required) to notify residents/businesses etc. about works to be undertaken and if it has an effect on them.	Supervisor All	3
Flora & Fauna	Some works may require the removal of vegetation. Native fauna may be at risk from excavation works	2	1. Assess work area for significant vegetation: size of trees, faunal habitat - define work and exclusion areas using fencing and signage. 2. Machinery is to be thoroughly washed down prior to leaving site where noxious weeds are present.	Supervisor All	3
Heritage & Archaeology	Unmonitored excavation at significant sites can lead to loss or destruction of valuable artifacts/relics, and disturbance of historical sites. including cultural heritage and/or archaeological significance	1	1. Undertake a survey of the site to identify any areas of significance. The client's representative may undertake this. Government bodies may be able to assist. 2. Develop a project specific procedure based on the findings and recommendations. 3. Installation of exclusion fencing and signage if required.	Supervisor All	2

Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Noise Pollution, Community Relations & Vibration	Sensitivity to noise - to public & fauna	1	1. Work undertaken during “normal” hours where possible. 2. Affected residents notified in person or in writing. 3. Plant and equipment regularly serviced & fitted with efficient mufflers. 4. Magnitude of vibration reduced by using smaller plant etc.	Supervisor All	2
Soil Management & Water Quality	Soil needs to be managed to ensure that; there are no off-site impacts. Damage to stockpile areas (not prepared properly). Mud deposited onto roadways.	2	1. Wash down machinery in only nominated areas. 2. Not within 20 metres of water courses. 3. Use only approved and nominated stockpile areas. 4. Build bund wall out of material available on site. 5. Drivers to check vehicle tyres/bodies for build up of mud when leaving stockpile sites and remove if necessary.	Supervisor All	3
Fuels and Chemicals	Contamination of waterways due to spillages of oil, degreasers, diesel, etc.	1	1. Store fuel and chemicals in accordance with relevant standards/guidelines. 2. Minimise storage on site and locate storage facilities away from drains and waterways. 3. All containers clearly labelled and Safety Data Sheets are available on site. 4. All drums stored securely and in a bunded area. 5. Spill kits or alternative spill containment materials available on site. 6. Regular maintenance of plant hoses. 7. Use correct refuelling equipment.	Supervisor All	2
Visual Impact Litter and Amenities Waste Management	Litter such as paper, plastic, and other refuse as well as being a possible safety risk may be carried off-site or washed into waterways resulting in pollution and danger to native fauna. Litter is also visually obtrusive. Production generated lighting, litter, mud, dirt and dust may also impact residents.	2	1. Use site induction to communicate the requirement for a tidy site. Also stress consideration for local residents. 2. If as a result of our works, dirt, mud, or litter affects a resident, then we will rectify this problem immediately. 3. Inspect the site frequently and insist on tidiness. Ensure public roads are free of dirt/mud from the work site. 4. Broken-out paved surfaces shall be repaired as soon as possible. 5. Remove all rubbish from site each day. 6. Waste products will be recycled where possible.	Supervisor All	3

Personal Protective Equipment						
All site personnel must wear the required PPE specified in the controls above, such as:						
Safety Hi-vis Vests/Shirts	Safety Boots	Sunscreen	Broad Brimmed Sun Hat	Sunglasses	Gloves specific to the task	White reflective overalls/night
Hard Hat where required	Safety Glasses	Hearing protection where required	Long clothing	Dust masks	Respiratory equipment if required	

Workers may require Task Specific Training depending on activity each worker will be required to fulfill.				
All workers shall hold a current Construction Induction Card				
- If required Client Site Induction - Activity Induction (SWMS & SWP's)	Vehicle Licences (Car or Truck depending on class of vehicle or mobile plant driven)	Plant Operators licences or competency assessments where required	Competencies for Work Zone Traffic Management	
First Aid certificate training	Manual Handling training	Fire Extinguisher training	Fatigue Management Training	

A Site Specific Induction & Toolbox Meeting will be held each day prior to the start of each job.

Legislation & Codes of Practice (refer to company Legislation register for applicable Australian Standards applicable to works)			
Work Health & Safety Act 2012 and Work Health & Safety Regulations 2022			
Codes of Practice			
Confined Spaces - 2020	Hazardous Manual Tasks - 2020	Managing Noise & Preventing Hearing Loss at Work-2020	Managing Risks of Plant in the Workplace - 2018
Construction Work - 2020	How to Manage WH&S Risks - 2018	Managing Risk of Falls at Workplaces - 2020	Managing Electrical Risks in the Workplace -2019
Excavation Work - 2020	First Aid in the Workplace - 2018	Managing Work Environment & Facilities - 2020	WHS Consultation Co-operation & Co-ordination - 2018
Welding Processes - 2021	How to Safely Remove Asbestos - 2020	Managing Risk of Hazardous Chemicals - 2018	Safe Design of Structures - 2018

Plant & Equipment for this activity
- All plant is inspected prior to sending out to site - Daily maintenance & service checks. - Daily pre-start checks are conducted on all plant and trucks by the operators and daily checklist filled out. - Regular servicing at 250hr intervals or as per manufactures specifications. Service History available on request to the office.

List of plant for this Activity
Engineering details/certificates/regulatory approvals/permits/electrical isolation (if applicable):

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.