


SAFE WORK METHOD STATEMENT

Persons responsible for supervising, inspecting work, work methods, plant & equipment and tools	Supervisor/Foreman	Date:	
High Risk Construction Work:	PROFILING - SAFE OPERATION	Project:	
SWMS prepared by Patrick Monaghan - Paneltec Group - Operations Manager and in consultation with management and workers – 2025. SWMS Review Date: August 2026 unless required earlier		Location:	
Approval to use this SWMS: "I certify that the attached SWMS has been reviewed by me, is endorsed for compliance with WorkSafe guidelines and is approved for use"			
<u>John Guy</u> Name	<u>Director - Paneltec Pty Ltd</u> Position	<u>0408 449 023</u> 	 Signature
			<u>31/08/2025 – V12.0</u> Date

RISK MATRIX

Level	Description of Consequence or Impact	Consequence	Likelihood / Probability		
			L <i>Likely</i>	M <i>Moderate</i>	U <i>Unlikely</i>
H (1) <i>(High level of harm)</i>	Potential death, permanent disability or major structural failure/damage. Off-site environmental discharge/release not contained and significant long-term environmental harm.	H (1) <i>(High)</i>	1	1	2
M (2) <i>(Medium level of harm)</i>	Potential temporary disability or minor structural failure/damage. On-site environmental discharge/release contained, minor remediation required, short-term environmental harm.	M (2) <i>(Medium)</i>	1	2	3
L (3) <i>(Low level of harm)</i>	Incident that has the potential to cause persons to require first aid. On-site environmental discharge/release immediately contained, minor level clean up with no short-term environmental harm.	L (3) <i>(Low)</i>	2	3	3
Level	Likelihood / Probability				
Likely	Could happen frequently				
Moderate	Could happen occasionally				
Unlikely	May occur only in exceptional circumstances				

HIERARCHY OF RISK CONTROL

The hierarchy of controls must be applied in the order below for all identified hazards.

Level 1 Eliminate the hazard
Level 2 Substitute the hazard with something safer.
Level 3 Isolate the hazard from people. Reduce the risks through engineering controls.
Level 4 Reduce exposure to the hazard using administrative actions.
Level 5 Use personal protective equipment The control measures that you put in place should be reviewed regularly to make sure they work as planned

ACTIVITY ANALYSIS

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
Training and skill.	Un-trained persons could cause injury to themselves and others. Possible property damage.	1	1. All persons on site must carry with them a current 'Construction Induction Card'. 2. All persons working on site must be suitably licensed, trained and competent in the work they are to perform. 3. No person shall operate profiler without appropriate training competency assessment in the safe use of the particular profiler they are to operate, and they have read and understood the operation manual for the profiler they are to operate. 4. All work is carried out as directed by the Supervisor, Foreman or customer representative.	Management	2
General safety precautions.	Injuries could vary from minor to death if safe work practices are not adhered to.	1	1. Only competently trained persons to operate or work around the profiler. 2. Before starting the profiler, know your equipment and its limitations read and follow the manufacturer's operating instructions. 3. Pay special attention to the warning and caution labels on the profiler itself. 4. DO NOT operate profiler while under the influence of alcohol, medication or other substances or while fatigued. 5. Check the layout of the land and watch for hidden objects, ditches, embankments and depressions, especially when the edge is unstable or slippery conditions prevail. 6. Wear appropriate PPE – Protective clothing, footwear including a hard hat. 7. Never wear loose, torn or bulky clothing around profiler. 8. No person should be allowed to stand or walk beside a machine when it is being operated. 9. DO NOT allow any bystanders around or near profiler during operation. 10. DO NOT allow passengers. 11. DO NOT get on and off profiler when it is in operation.	Supervisor or Foreman Operator	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
			12. Only stand in the operator protected area when operating the profiler. 13. NEVER complete maintenance work when profiler is switch on-move machine to safe area away from traffic and lockout & tag first.		
Personal Protective Clothing & Equipment (PPE)	Personal injury.	1	1. Minimum PPE to be worn on site is: • Hi visibility vests/clothing • Steel toe-capped boots • UV skin protection minimum 15+ UV sunscreen • Head protection as applicable • Long pants and long sleeves. • Hard Hat as required.	Truck driver	2
Setting out Traffic Control; cones and or signs	Being run over by vehicular traffic	1	1. Workers wear high visibility safety vests/clothing at all times. 2. Traffic control set out vehicles to display flashing amber lights. 3. Traffic Control set out as per Traffic Management Plan and in compliance with SWMS-Traffic Management and the Department of State Growth-Transport Traffic Control for Work on Roads-2014 guidance notes.	All Foreman	2
	Night works	1	1. Use lighting towers (daymakers) for nightwork to light work areas and the traffic controller positions. 2. White reflective overalls.		2
Site Inspection and toolbox meeting	Various hazards	1	1. Prior to the daily tool box meeting the Foreman and or workers will walk the work site and identify potential hazards. 2. The management of these hazards will be discussed at the toolbox meeting and documented on the 'Site Induction/Toolbox meeting record' form. 3. Inspect the job for services or obstacles and mark accordingly.	Foreman	2
Pre Start Check of Profiler	Unsafe equipment Potential for accident	1	1. Pre start checklist forms filled out & defects documented, supervisor notified. 2. Check brakes, clutch and other mechanical parts for faulty adjustment. 3. Faulty equipment must not be used. Report suspect machinery immediately to Supervisor. 4. Ensure that all lights and warning devices are operational.	Operator	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
Operation of Profiler	Possibility of entanglement.	1	- When profiler is in operation the operator should always remain a good distance from milling drum. - Never try and remove anything from drum unless drum has stopped also keys removed from machine and locked out & tagged.	Operator	2
	Flying Debris	2	While machine is milling roadway at times pieces of asphalt/bitumen etc will be flying objects so all workers should wear safety goggles and hard hat at all times when working in vicinity of profiler.	Operator Spotter All in vicinity	3
	Striking vehicles of persons.	1	Milling works should not begin until traffic is under traffic control.	Supervisor or Foreman Operator	2
Zero levels on profiling machine and dial in required depth/slope	Equipment Pedestrians	1	- Ensure trained competent operator. - Ground man to ensure operation within designated work area.	Supervisor Operator Ground Man	2
Lower machine to correct depth for cutting	Dust Equipment Noise	2	- Dampen using water on machine - Wear AS dust mask if required - Ensure pre start check complete - Hearing protection to be worn	Operator Ground Man	3
Proceed with profiling operation	Traffic and plant Trips, falls Trees / awnings Manholes / Pits	1	- Flashing lights and reversing beepers to be functional - Observe location of kerb, gutters and drainage points - Ensure these are identified during Risk Assessment and work around them. Communicate. - Cover & barricade and communicate to all where they are.	Operator Supervisor	2
Loading of truck with spoil from conveyor	Struck by falling material Struck by reversing vehicle	1	- Wear safety helmet - A spotter should be nominated on site to communicate with driver of profiler and to direct trucks back to the profiler. - Spotter to maintain truck position. - Driver of truck not to reverse unless under guidance of spotter and to stop if he cannot see spotter. - Reversing alarms on trucks and trailers to be operational. - All persons on site wear hi vis clothing/vests.	All Supervisor Spotter Truck drivers	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
	Damage to underground services	1	1. Always check with dial before you dig before starting to dig patches. 2. Also have a spotter on site when digging.	Supervisor or Foreman Operator	2
	Inhalation of Dust	3	1. Workers to wear face protection where required.	Supervisor or Foreman Operator	3
	Equipment Refueling	2	1. To occur off site.	Operator	3
	Exposure to Noise levels above 85dBA for extended periods may cause Hearing damage.	2	1. Noise risk assessments of all plant & equipment as per 'Noise Control' procedure. 2. Where plant/equipment is signed hearing protection must be worn by workers. 3. Plant/Equipment to be maintained in good working order and noise excessive equipment to be modified where practicable to reduce noise levels. 4. Hearing protection must be worn by all workers when milling is in progress.	Supervisor or Foreman Operator	3
	Potential for injury if guarding not in place.	1	1. Machine guarding is provided on plant & equipment as per 'Plant & Equipment' procedure. 2. All guards to be checked on pre-start. 3. Warning stickers provided.	Supervisor or Foreman Operator	2
Monitoring of depth	Noise Dust Struck by profiler Struck by truck being loaded Slips & trips	1	1. Watch foot landing area. 2. Wear hi vis clothing/vest. 3. Wear PPE as above. 4. Take measurements only behind machine, not inside cutting area	Operator Crew	2
At completion of cutting, park machine in a safe area inside work zone for daily maintenance.	Noise Debris Cutting drum Refuelling	1	1. Hearing protection to be worn 2. Eye protection to be worn 3. Both operators to ensure automatic lock out system for milling drum is operational prior to entering drum area. Turn off engine. 4. No smoking during refuelling and ensure refuelling operation is observed at all times. DO NOT LEAVE UNATTENDED.	Operator	2

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
Clean up excess material manually	Strains & sprains Personnel struck by machine.	2	1. Use correct manual handling techniques when using shovels. 2. No person is to conduct clean up until profiler has stopped.	All	3
Clean up excess material with bobcat	Personnel struck by machine	1	1. Wear high visibility clothing 2. Reversing alarms operational 3. Enforce mobile plant clearance to personnel of 3m front & rear and 1m to each side.	Bobcat Operator	2
Finishing Off	Potential hazards to cyclists, vehicles & pedestrians	1	1. When the profiling work is open to the traffic the following actions are necessary. a. Ensure that edges are suitably ramped. b. Any change in level greater than about 30 mm should have a wedge of asphalt placed so that longitudinal edges have a maximum slope of about 1 in 5, and so that transverse edges have a maximum slope of 1 in 10 on low speed roads, increasing to 1 in 20 for roads with traffic speeds over 75 km/h. c. Place suitable signs warning of uneven surface. d. Planed surfaces can be hazardous to cycles, including motor cycles.	Supervisor or Foreman Operator	2
Relocate the profile planer	Personnel struck by machine	1	1. Profiler is moved safely between work sites, observing relevant codes and traffic management requirements 2. Profiler is prepared for relocation in accordance with the manufacturers' specifications.	Operator	2
Environmental	Dust generation Pollute waterways	2	1. Areas where dust maybe generated, control methods are to be in place to reduce dust from leaving site. 2. Water cart to be used where large areas of exposed material may cause dust. 3. Sediment controls to remain in place and if damaged they are to be repaired.	Supervisor or Foreman	3

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class After Controls in Place
Carry out profile planer operator maintenance	Personal injury	2	1. Profiler is safely parked, prepared for maintenance and shut down as per manufacturers' manual and locked out & tagged. 2. Inspection and fault finding are conducted in accordance with manufacturers' specifications. 3. Defective parts are removed and replaced safely and effectively according to manufacturers' manual. 4. Regular programmed maintenances tasks are carried out in accordance with manufacturers requirements	Supervisor or Foreman Maintenance person	3
Clean up	Personal injury	2	1. Work area is cleared and materials disposed of or recycled in accordance with project environmental management plan. 2. Profiler tools and equipment are cleaned, checked, maintained and stored in accordance with manufacturers' recommendations and standard work practices.	All	3
Identifying additional daily hazards	Could be Various	Vary 1 to 3	Prior to the daily tool box meeting the Foreman and or workers will walk the work site and identify potential hazards. The management of these hazards will be discussed at the toolbox meeting and documented on the 'Site Induction/Toolbox meeting record' form.	Supervisor or Foreman	2-3

ENVIRONMENTAL RISK ASSESSMENT & CONTROL MEASURES THAT MAY BE REQUIRED ON SITE DEPENDING ON THE ACTIVITY					
Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Emergencies	Accident/ Incident Fire Spill	1	1. Personnel have been advised at toolbox meeting and are prepared in the event of an incident occurring. 2. Emergency numbers available on site. 3. Fire Extinguishers/First Aid Kits/Spill Kits on site.	Supervisor All	2
Air Quality	Exhaust Fumes Dust	2	1. Control exhaust emissions eg. Regular maintenance, replace old machinery, fit appropriate emission control measures. 2. Dampen milled surface with water cart. 3. Use water cart where required.	Supervisor All	3
Bitumen/Prime	During heavy rain, recently placed prime or bitumen could emulsify and wash into surrounding waterways.	1	1. Plan prime or bitumen operation so that it is conducted during fine weather. 2. Have material available to clean up a spill if it occurs and dispose of contaminated material accordingly. 3. Protect storm drains during and after application to prevent pollution - have spill clean-up materials available.	Supervisor All	2
Community Relations	Inconvenience as a result of works/traffic management	2	1. Identify from the list of potentially impacted parties who may be impacted by the work being undertaken. 2. Letter drops could be considered (unless specifically required) to notify residents/businesses etc. about works to be undertaken and if it has an effect on them.	Supervisor All	3
Flora & Fauna	Some works may require the removal of vegetation. Native fauna may be at risk from excavation works	2	1. Assess work area for significant vegetation: size of trees, faunal habitat - define work and exclusion areas using fencing and signage. 2. Machinery is to be thoroughly washed down prior to leaving site where noxious weeds are present.	Supervisor All	3
Heritage & Archaeology	Unmonitored excavation at significant sites can lead to loss or destruction of valuable artifacts/relics, and disturbance of historical sites. including cultural heritage and/or archaeological significance	1	1. Undertake a survey of the site to identify any areas of significance. The client's representative may undertake this. Government bodies may be able to assist. 2. Develop a project specific procedure based on the findings and recommendations. 3. Installation of exclusion fencing and signage if required.	Supervisor All	2

Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Noise Pollution, Community Relations & Vibration	Sensitivity to noise - to public & fauna	1	1. Work undertaken during “normal” hours where possible. 2. Affected residents notified in person or in writing. 3. Plant and equipment regularly serviced & fitted with efficient mufflers. 4. Magnitude of vibration reduced by using smaller plant etc.	Supervisor All	2
Soil Management & Water Quality	Soil needs to be managed to ensure that; there are no off-site impacts. Damage to stockpile areas (not prepared properly). Mud deposited onto roadways.	2	1. Wash down machinery in only nominated areas. 2. Not within 20 metres of water courses. 3. Use only approved and nominated stockpile areas. 4. Build bund wall out of material available on site. 5. Drivers to check vehicle tyres/bodies for build up of mud when leaving stockpile sites and remove if necessary.	Supervisor All	3
Fuels and Chemicals	Contamination of waterways due to spillages of oil, degreasers, diesel, etc.	1	1. Store fuel and chemicals in accordance with relevant standards/guidelines. 2. Minimise storage on site and locate storage facilities away from drains and waterways. 3. All containers clearly labelled and Safety Data Sheets are available on site. 4. All drums stored securely and in a bunded area. 5. Spill kits or alternative spill containment materials available on site. 6. Regular maintenance of plant hoses. 7. Use correct refuelling equipment.	Supervisor All	2
Visual Impact Litter and Amenities Waste Management	Litter such as paper, plastic, and other refuse as well as being a possible safety risk may be carried off-site or washed into waterways resulting in pollution and danger to native fauna. Litter is also visually obtrusive. Production generated lighting, litter, mud, dirt and dust may also impact residents.	2	1. Use site induction to communicate the requirement for a tidy site. Also stress consideration for local residents. 2. If as a result of our works, dirt, mud, or litter affects a resident, then we will rectify this problem immediately. 3. Inspect the site frequently and insist on tidiness. Ensure public roads are free of dirt/mud from the work site. 4. Broken-out paved surfaces shall be repaired as soon as possible. 5. Remove all rubbish from site each day. 6. Waste asphalt will be recycled where possible.	Supervisor All	3

Personal Protective Equipment						
All site personnel must wear the required PPE specified in the controls above, such as:						
Safety Hi-vis Vests/Shirts	Safety Boots	Sunscreen	Broad Brimmed Sun Hat	Sunglasses	Gloves specific to the task	White reflective overalls/night
Hard Hat where required	Safety Glasses	Hearing protection where required	Long clothing	Dust masks	Respiratory equipment if required	
Workers may require Task Specific Training depending on activity each worker will be required to fulfill.						
All workers shall hold a current Construction Induction Card						
- If required Client Site Induction - Activity Induction (SWMS & SWP's)	Vehicle Licences (Car or Truck depending on class of vehicle or mobile plant driven)		Plant Operators licences or competency assessments where required		Competencies for Work Zone Traffic Management	
First Aid certificate training	Manual Handling training		Fire Extinguisher training		Fatigue Management Training	
A Site Specific Induction & Toolbox Meeting will be held each day prior to the start of each job.						
Legislation & Codes of Practice (refer to company Legislation register for applicable Australian Standards applicable to works)						
Work Health & Safety Act 2012 and Work Health & Safety Regulations 2022						
Codes of Practice						
Confined Spaces - 2020	Hazardous Manual Tasks - 2020	Managing Noise & Preventing Hearing Loss at Work-2020		Managing Risks of Plant in the Workplace - 2018		
Construction Work - 2020	How to Manage WH&S Risks - 2018	Managing Risk of Falls at Workplaces - 2020		Managing Electrical Risks in the Workplace -2019		
Excavation Work - 2020	First Aid in the Workplace - 2018	Managing Work Environment & Facilities - 2020		WHS Consultation Co-operation & Co-ordination - 2018		
Welding Processes - 2021	How to Safely Remove Asbestos - 2020	Managing Risk of Hazardous Chemicals - 2018		Safe Design of Structures - 2018		
Plant & Equipment for this activity						
- All plant is inspected prior to sending out to site - Daily maintenance & service checks. - Daily pre-start checks are conducted on all plant and trucks by the operators and daily checklist filled out. - Regular servicing at 250hr intervals or as per manufactures specifications. Service History available on request to the office.						
List of plant for this Activity						
Engineering details/certificates/regulatory approvals/permits/electrical isolation (if applicable):						

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.