

- 1. Place boat on starboard tack either close hauled or heave to;
- 2. Ease main sheeet, cunningham & boomvang;
- 3. Harden topping lift to take the weight of the boom;
- 4. Lower the mainsail until the 1st luff reefing cringle reaches the gooseneck;
- 5. Harden luff reefing line or place reefing cringle on hook;
- 6. Harden halyard and re-establish luff tension;
- 7. Harden leech reefing line, being careful not to pinch the sail;
- 8. Harden mainsheet
- 9. Tie in reef points
- 10. For second or third reef, repeat steps 1 9 above.

