

## Cloud, APIs and Alerts > Interfacing Sensor over VPS

## Sending an SMS when Temperature Crosses Threshold

In the previous lesson, we learned about Twilio and how to create an account on Twilio. Now we will write a code which will fetch the temperature data collected by Bolt and send SMS if the temperature value crosses a certain threshold.

Step 1: Connect the temperature monitoring circuit as we have done in the previous lesson -Hardware connections for temperature monitor.

Step 2: Login into the putty by entering the IP address of your digital ocean droplet.

Step 3: After successful login, create a file named conf.py which will store all the credentials related to Twilio. To create a new file type sudo nano conf.py in the putty. After that write below code to save all the credentials in a single file.

```
SSID = 'You can find SSID in your Twilio Dashboard'
AUTH TOKEN = 'You can find on your Twilio Dashboard'
FROM NUMBER = 'This is the no. generated by Twilio. You can find this on
your Twilio Dashboard'
TO NUMBER = 'This is your number. Make sure you are adding +91 in
beginning'
API KEY = 'This is your Bolt Cloud accout API key'
DEVICE ID = 'This is the ID of your Bolt device'
```

Note: You have to replace all the above value with your credentials. You can find the first four value in Twilio dashboard and the last two in Bolt Cloud dashboard.

We store all the credentials in a separate file since it is sensitive data which should not be shared with anyone. Hence it is a good practice to avoid using credentials in code directly. After replacing all the values, save the file using CTRL+X.

**Step 4:** Now create one more file named temp sms.py. To do so you have to type sudo nano temp sms.pyin the terminal. Now we will write main code to collect the data from the Bolt and send SMS if it crosses the threshold.

We have to import our conf file which has all the credentials, json and time.



import conf, json, time

Now we will import our Bolt python library which will let us fetch the data stored in Bolt Cloud and then based on value send SMS. To do so write

```
from boltiot import Sms, Bolt
```

In the above code, we are importing 2 things. First one is SMS which will be used to send alerts and the other one is Bolt which will be used to fetch the temp. data.

Now we will initialize two variables which will store min. and max. threshold value. You can initialize any min. and max. limits to them.

```
minimum limit = 300
maximum limit = 600
```

Now to fetch the data from Bolt Cloud, we will create an object of the same.

```
mybolt = Bolt(conf.API_KEY, conf.DEVICE_ID)
```

The above code will automatically fetch your API key and Device ID that you have initialized in conf.py file.

Now to send SMS, we will create an object of the same.

```
sms = Sms(conf.SSID, conf.AUTH TOKEN, conf.TO NUMBER, conf.FROM NUMBER)
```

The above code will automatically fetch your SSID, AUTH\_TOKEN, TO\_NUMBER and FROM\_NUMBER that you have initialized in conf.py file. Make sure you have passed correct value in conf.py file.

Now we will continuously fetch the temperature value using `analogRead`. Then we will compare the value with our threshold, if it didn't fall in the range then SMS will be sent.

```
while True:
    response = mybolt.analogRead('A0')
```



```
data = json.loads(response)
  print (data['value'])
  try:
     sensor_value = int(data['value'])
     print (sensor_value)
     if sensor_value > maximum_limit or sensor_value < minimum_limit:
         response = sms.send_sms("The Current temperature sensor value
is " +str(sensor_value))
  except Exception as e:
     print ("Error",e)
  time.sleep(10)</pre>
```

In the above code, we are fetching the data every 10sec. You can change the value but ideally, it should be good if the time interval between 2 data points is more than 10sec.

## Below is the complete code:

```
import conf, json, time
from boltiot import Sms, Bolt

minimum_limit = 300
maximum_limit = 600

mybolt = Bolt(conf.API_KEY, conf.DEVICE_ID)
sms = Sms(conf.SSID, conf.AUTH_TOKEN, conf.TO_NUMBER, conf.FROM_NUMBER)

while True:
    response = mybolt.analogRead('A0')
    data = json.loads(response)
    print (data['value'])
```



```
try:
        sensor value = int(data['value'])
        print (sensor value)
        if sensor_value > maximum_limit or sensor_value < minimum limit:</pre>
            response = sms.send sms("The Current temperature sensor value
is " +str(sensor value))
    except Exception as e:
        print ("Error",e)
    time.sleep(10)
```

Note: The above "sensor value" is the raw temperature reading, obtained from the LM35 sensor. In case you want to convert this value to the temperature in degree Celsius, use the formula:

```
Temperature=(100*sensor value)/1024
```

Where sensor\_value = Data obtained from the LM35 sensor. The accuracy of this value obtained can be improved using an advanced calibrated technique.

Save the file. Time to run the code. To do so type `sudo python3 temp\_sms.py` in terminal

Since we have written couple of print statement in the code. So the temperature data will get printed on the terminal. If that value falls outside the threshold range then SMS will be sent to your registered number. The screenshot for the SMS sent is given below:





How was the lesson? Isn't it easy? Thanks to Bolt Library which makes this lesson very easy to collect the data and send SMS. In the next lesson, we will learn how we can do the same thing by sending an email instead of SMS.