Equipment inventory

Spare labels are stored beside the front desk.

Emergency cooling procedure

Switch off the pump before removing a blocked filter.

Wear gloves and allow the housing to cool.

Maintenance code CLG-57260.