




GPX10Pro I2s-tmbuffer- aon-ww-cnn

Confidentiality Statement

This document contains highly confidential and proprietary information and data of Ambient Scientific and its affiliates. This document is provided, on the express condition that such information and data will not be used, disclosed, or reproduced in any form, in whole or in part, for any purpose (other than solely for evaluation purposes by authorized representatives with a need to know), without the express written approval of Ambient Scientific. The right to use, disclose, and reproduce such information and data shall be governed by the service agreement between the client and Ambient Scientific.

Warnings and Disclaimer

The information provided is on an as is basis. Every effort has been made to make this book as complete and as accurate as possible, but no warranty or fitness is implied. The authors and the publisher shall have neither liability nor responsibility to any person or entity with respect to any loss or damages arising from the information contained in this book. Screenshots and data used within are for illustration purpose and may vary from the actual application.

Ambient Scientific – All rights reserved.

Document Change History Log

Version No.	Date	Author / Editor	Details of Change
1.0	20/01/2026	Ambient Scientific	First version

CONTENTS

1	Introduction	6
1.1	Purpose & Scope	6
1.2	Open Points.....	6
1.3	Definitions, Acronyms & Abbreviations	6
2	System.....	7
2.1	Hardware	7
2.2	Software.....	7
2.3	Application Pipeline	8
2.4	Application Flow	8
3	Loading Workspace	9
4	Application.....	10
4.1	Description:.....	10
4.2	Execution and Run	11
5	Retraining the Model with Custom Wake Word	14
5.1	Collect Audio Samples from DVK Board:.....	14
5.2	Organize Audio Files:.....	14
5.3	Extract Features from Audio Samples:.....	15
5.4	Train the Model:.....	15
5.5	Changing the Model Configuration.....	16
5.6	Use the Trained Model:	17
6	Build and Run	21
6.1	General Debug	21

6.2	Change in Model Architecture/Model Rename.....	24
6.2.1	Use the Trained Model:	24

1 Introduction

1.1 Purpose & Scope

This document describes “i2s-tmbuffer-aon-alexa-ww-cnn” application details. It is reference document for engineering, marketing team & AI’s Customers.

1.2 Open Points

- None

1.3 Definitions, Acronyms & Abbreviations

Definitions:

Acronyms:

Ambient Scientific: - AS

S9 Chip set: - AI chip set

Abbreviations:

AI: - Artificial Intelligence

BT: - Bluetooth

HW: - Hardware


SDK: - Software Development Kit

SW: - Software

2 System

2.1 Hardware


- DVK board on with I2S mic.
- JTAG and POWER cable for connection of DVK board.




2.2 Software

- Eclipse IDE
- Command prompt
- GPX10 PRO compiler

2.3 Application Pipeline



2.4 Application Flow



3 Loading Workspace

Please refer to "GPX10Pro_General_Application_notes" this document in this path
"C:\AmbientScientific\setup\chip\fw\applications"

4 Application


4.1 Description:

- The application involves detecting the wake-word spoken by user. It captures speaking word by I2S mic and detects the word and display the same on serial console.
- LED (GPIO_PIN_1) will indicate I2S Mic ON.
- 30*16 features generated by CMD block from 1 sec data of I2S Mic.
- 30*16 is input to the model which will give the result.
- Input: - Speak the word in front of I2S mic.
- Output: - Console prints (KEYWORD DETECTED) on serial consol.
- The application runs by eclipse and Command prompt. By default, the application runs Live mode.


4.2 Execution and Run

- Import application from here:


"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaw-cnn"




- Right click on project for **Clean and Build**




- Serial Terminal will appear, Run the application



- Observe the initial output on serial terminal



- Speak the word Alexa, if the detection happens, the following output appears




- LED (GPIO_PIN_1) will indicate I2S Mic ON.
- LED (GPIO_PIN_1, GPIO_PIN_2, GPIO_PIN_3) will indicate when keyword will be detected

5 Retraining the Model with Custom Wake Word

5.1 Collect Audio Samples from DVK Board:

- Navigate to the application directory:
C:\EdgeSphere and invoke Edge Sphere Application and refer to the document "EdgeSphere_Tool_Guide".



5.2 Organize Audio Files:


- You will find the .wav files in the following directory:
C:\Edgesphere\Collected_Data\Audio
- Create a folder named dataset in:
C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexa-ww-cnn\training_tool_chain\python
- Inside the dataset folder, create two subfolders:
 - wake-word: Paste the .wav files corresponding to wake word samples (Collected via edge sphere tool).
 - not-wake-word: Paste .wav files of non-wake-word audio samples for training

5.3 Extract Features from Audio Samples:

Navigate

`"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\training_tool_chain\python"`

- Now open cmd prompt




```

C:\Windows\System32\cmd.e  x  +  v
Microsoft Windows [Version 10.0.26200.8246]
(c) Microsoft Corporation. All rights reserved.

C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\training_tool_chain\python>

```

- Run command: **ambient**



```

C:\Windows\System32\cmd.e  x  +  v
=====
AMBIENT SDK GPX10PRO 1.0.0
GUI Version 1.0.0
=====
--- ENVIRONMENT VERIFIED ---
Python 3.10.11
-----
WORKSTATION ACTIVE (ISOLATION ON)
-----
Current Directory: C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\training_tool_chain\python
(ambient_env) C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\training_tool_chain\python>

```


- Run the following command to extract features from the audio samples and generate .npv files:
python Feature-Extraction.py

5.4 Train the Model:

Navigate

`"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\training_tool_chain\python"`

- Now open cmd prompt




```

C:\Windows\System32\cmd.e x + v
Microsoft Windows [Version 10.0.26200.8246]
(c) Microsoft Corporation. All rights reserved.

C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexa-ww-cnn\training_tool_chain\python>

```

- Run command: **ambient**



```

C:\Windows\System32\cmd.e x + v
=====
AMBIENT SDK GPX10PRO 1.0.0
GUI Version 1.0.0
=====
--- ENVIRONMENT VERIFIED ---
Python 3.10.11
-----
WORKSTATION ACTIVE (ISOLATION ON)
-----
Current Directory: C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexa-ww-cnn\training_tool_chain\python
-----
(ambient_env) C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexa-ww-cnn\training_tool_chain\python>

```

- Run the following command to train the model:
python wake-word-model-training.py
- After execution, you will have the following model files:
 - keras model (.h5): wake-word-model.h5
 - TFLite model (.tflite): wake-word-model-quantized.tflite

5.5 Changing the Model Configuration

- Save the <model_name...>.h5 here

"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\test"

- Navigate "C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\test\ModelRefresh.ps1"

Can change the model name as per the user's requirement.

```
# Model refresh for Eclipse Debug_ModelReferesh prebuild.
# Single script: SDK path setup (ambient / ambient_env) + gpxCLITool run.
# Console: minimal status.  model_log.txt: full gpxCLITool output from cmd redirect.
#
# Optional env (or test\local-env.ps1): AMBIENT_SETUP, AMBIENT_PYTHON, AMBIENT_ARM_GCC_BIN


# --- User settings (edit for your project) ---
$modelName = "wake-word-model.h5"
$gpxProfile = "5"
$modelOutDir = "../i2s-tmbuffer-aon-alexaww-cnn/"

# gpxCLITool -p
# gpxCLITool -d
```

5.6 Use the Trained Model:

- Copy the .h5 model to the following directory:
C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\test
- Go to eclipse
- Right click on project


- Go to *Build Configurations* and Select “**Debug_ModelRefresh**” under “*Set Active*” Option



- Perform a **Clean and Build**

The model name can be verified in the console output.

- Wait until model deployment to GPX-Hw is complete




- ```

[0m[92m //! BUILD SUCCESS!!. [0m[93m[45m//! Target image i2s-tmbuffer-aon-alexa-wv-cnn-project.elf successfully generated...

[0m[44m[93m//! RUNNING THE TARGET...
[0m[33m //! Invoking JLINK_GDB_SERVER PROCESS (JLinkGDBServerCL.exe) ...[0m[92m //! SUCCESS!
[0m[33m //! Invoking GDB_CLIENT PROCESS ...[0m[92m //! SUCCESS!
[0m[44m[93m
//! RUNNING THE GENERATED TASK ON TARGET & GETTING RESULTS...
[0m[33m //! Opening serial terminal with COM-3 PORT, BAUD_RATE: 9600... [0m[92m //! SUCCESS!
[0m[95m//! PRESS 0 to EXIT... Please wait...
[0m[33m //! Closing Serial COM-3 port ...
[0m[92m //! SUCCESS!
[0m[33m //! Invoking GDB_CLIENT PROCESS ...[0m[92m //! SUCCESS!
[0m[33m //! Triggered quit command...Please Wait...
[0m[91m//! Gracefully, Terminating the child processes...Please Wait...
[0m[34m****/
[0m

```

- Run the application




- Speak the word, if the detection happens, the following output appears


## 6 Build and Run

### 6.1 General Debug


- Import application from here:  
"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexawww-cnn"
- Right click on project for **Clean and Build**




- Serial Terminal will appear, Run the application



- Observe the initial output on serial terminal



- Speak the word Alexa, if the detection happens, the following output appears




- LED (GPIO\_PIN\_1) will indicate I2S Mic ON.
- LED (GPIO\_PIN\_1, GPIO\_PIN\_2, GPIO\_PIN\_3) will indicate when keyword will be detected

## 6.2 Change in Model Architecture/Model Rename

### 6.2.1 Use the Trained Model:


- Copy the .h5 model to the following directory:  
C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alex-ww-cnn\test
- Go to eclipse
- Right click on project
- Go to *Build Configurations* and Select **“Debug\_ModelRefresh”** under *“Set Active” Option*





- Perform a **Clean and Build**

The model name can be verified in the console output.




```

CDT Build Console [i2s-tmbuffer-aon-alexaww-cnn-project]
12:37:51 **** Build of configuration Debug_ModelRefresh for project i2s-tmbuffer-aon-alexaww-cnn-project ****
make all
make --no-print-directory pre-build
powershell -NoProfile -ExecutionPolicy Bypass -File "C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\test\ModelRefresh.ps1"
[MODEL_REFRESH_START]
[MODEL_NAME] wake-word-model.h5
[MODEL_REFRESH_GPXCLI] gpxCLITool.exe -m wake-word-model.h5 -d ../i2s-tmbuffer-aon-alexaww-cnn-project/ -p 3 -w 16 -o 16 -s ArmShift

```

- Debug statements will appear in **model\_log.txt** for observation navigate to  
"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\test\model\_log.txt"



```


[0m[92m /// BUILD SUCCESS!!. [0m[93m[45m/// Target image i2s-tmbuffer-aon-alexaww-cnn-project.elf successfully generated...

[0m[44m[93m/// RUNNING THE TARGET...
[0m[33m /// Invoking JLINK GDB_SERVER PROCESS (JLinkGDBServerCL.exe) ...[0m[92m /// SUCCESS!
[0m[33m /// Invoking GDB_CLIENT PROCESS ...[0m[92m /// SUCCESS!
[0m[44m[93m
/// RUNNING THE GENERATED TASK ON TARGET & GETTING RESULTS...
[0m[33m /// Opening serial terminal with COM-3 PORT, BAUD_RATE: 9600... [0m[92m /// SUCCESS!
[0m[95m/// PRESS 0 to EXIT... Please wait...
[0m[33m /// Closing Serial COM-3 port ...
[0m[92m /// SUCCESS!
[0m[33m /// Invoking GDB_CLIENT PROCESS ...[0m[92m /// SUCCESS!
[0m[33m /// Triggered quit command...Please Wait...
[0m[91m/// Gracefully, Terminating the child processes...Please Wait...
[0m[34m****/
[0m

```

- Return to the Eclipse IDE and switch the build configuration, **Debug\_ModelRefresh** to **Debug**
- Find the .elf file in the  
"C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexaww-cnn\i2s-tmbuffer-aon-alexaww-cnn-project\Debug\i2s-tmbuffer-aon-alexaww-cnn-project.elf"


- Run the application



- Speak the word, if the detection happens, the following output appears

## Static mode: (optional)

To run the static data, delete "SENSOR\_SIM\_DEMO" from project paths and symbols setting as shown below.



This flag will be set to 1 by default when removed "SENSOR\_SIM\_DEMO" from properties as shown below

```
#ifndef SENSOR_SIM_DEMO
#define ENABLE_WAKE_WORD_STATIC_DATA 1
#else
#define ENABLE_WAKE_WORD_STATIC_DATA 0
#endif

/*****
```

To load the static data input when running application in static mode (optional) add -i ./input.txt please prefer cmds.txt "C:\AmbientScientific\setup\chip\fw\applications\i2s-tmbuffer-aon-alexa-ww-cnn\test"

```
$toolExe = $paths.ToolExe
$args = "-m $modelName -d $modelOutDir -p $gpxProfile -w 16 -o 16 -s ArmShift"

gpxCLITool prompts for "0" to continue/end (often after build). Piping (echo 0) only
feeds stdin at start; use a stdin file so each prompt reads the next "0" automatically.
$stdinFile = Join-Path $paths.WorkDir "gpx_stdin.txt"
$modelLog = Join-Path $paths.WorkDir "model_log.txt"
1..30 | ForEach-Object { "0" } | Set-Content -Path $stdinFile -Encoding ASCII
$cmd = "set ""PATH=$pathPrefix;%PATH%"" && ""$toolExe"" $args < ""$stdinFile"" > ""$modelLog"" 2>&1"
```