
StaticsM Examples, Methods

All rights reserved by Mark C. Bourland. August 25, 1998

Example: Axial loading and displacement relationships



$$P = 170 \text{ kN}$$


u = horizontal displacement

$$E = 211 \text{ GPa}$$

$$A = 645 \text{ mm}^2$$

$$Y = 253 \text{ MPa}$$

$$\epsilon_y = \frac{Y}{E} = \frac{253 \text{ MPa}}{211 \text{ GPa}} = 0.0012$$




Free body

$$[A] = \begin{bmatrix} -.6 & .6 \\ .8 & .8 \end{bmatrix}$$

$$[S] = \begin{bmatrix} \frac{A_1 E}{L_1} & 0\\ 0 & \frac{A_2 E}{L_2} \end{bmatrix} = \begin{bmatrix} 45365000 & 0\\ 0 & 45365000 \end{bmatrix}$$

$$\{P\} = \begin{bmatrix} P_1 \\ P_2 \end{bmatrix} = \begin{bmatrix} 0 \\ 170 \end{bmatrix} kN$$



$$[A][S][A]^T]^{-1}\{P\} = \{X\} \qquad \text{From Hooke's law}$$

$$P = \{X\}$$
 From Hooke's law

$$[S][A]^T \{X\} = \{F\}$$

$$[A]^T \{X\} = \{e\}$$

$$[K]{X} = {P}; [K]^{-1}{P} = {X}$$

→ From load-displacement relation.


$$e = \frac{PL}{AE}$$
 ; [S]{e} = {F}


$$\{X\} = \begin{bmatrix} X_1 \\ X_2 \end{bmatrix} = \begin{bmatrix} 0 \\ 2.92774E-6 \end{bmatrix}$$
m ; $u = X_2 = 2.92774E-6$ m

$$\{F\} = \begin{bmatrix} F_1 \\ F_2 \end{bmatrix} = \begin{bmatrix} 106.25 \\ 106.25 \end{bmatrix} kN$$

$$\{e\} = \begin{bmatrix} e_1 \\ e_2 \end{bmatrix} = \begin{bmatrix} 2.342E-6 \\ 2.342E-6 \end{bmatrix}$$
 m ; $e = elongation of bar$

Example: Indeterminate truss; load-displacement relationships. Matrix Displacement Method





$$[A] = \begin{bmatrix} \text{-.6 1 0 0 0 0.6 0} \\ \text{.8 0 0 0 1 .8 0} \\ \text{0 0 1 0 0 0 0.8} \\ \text{0 -1 0 0 0 0 0 -.6} \\ \text{0 0 0 -1 0 -.6 0} \end{bmatrix}; \quad \{P\} = \begin{bmatrix} P_1 \\ P_2 \\ P_3 \\ P_4 \\ P_5 \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \\ 0 \\ -10 \\ 0 \end{bmatrix} kN$$

$$[S] = \begin{bmatrix} \frac{A_1E}{L_1} & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & \frac{A_2E}{L_2} & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & \frac{A_3E}{L_3} & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{A_4E}{L_4} & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{A_5E}{L_5} & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{A_6E}{L_6} & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & \frac{A_7E}{L_7} \end{bmatrix} = \begin{bmatrix} \frac{1}{5} & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & \frac{1}{3} & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & \frac{1}{3} & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1}{3} & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1}{3} & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1}{4} & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1}{5} & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1}{5} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1}{5} & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1}{5} & 0 \end{bmatrix}$$


AE here is set equal to 1. If interested in displacements


$$\begin{bmatrix} \frac{1}{5} & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & \frac{1}{3} & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & \frac{1}{4} & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & \frac{1}{3} & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & \frac{1}{4} & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & \frac{1}{5} & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & \frac{1}{5} \end{bmatrix}$$

and elongations, we can use a real $[A][S][A]^T^{-1}{P} = {X}$ set of AE factors.

$$\begin{bmatrix} [S][A]^T \end{bmatrix} \{X\} = \{F\} \\ \{X\} = \begin{bmatrix} X_1 \\ X_2 \\ X_3 \\ X_4 \\ X_5 \end{bmatrix} = \begin{bmatrix} -50.7907 \\ -1.7922 \\ -17.9534 \\ -70.6919 \\ -9.4465 \end{bmatrix}; \quad \{F\} = \begin{bmatrix} F_1 \\ F_2 \\ F_3 \\ F_4 \\ F_5 \\ F_6 \\ F_7 \end{bmatrix} = \begin{bmatrix} 5.80813 \\ 6.6337 \\ -4.4883 \\ 3.1488 \\ -.44805 \\ -5.24806 \\ 5.61046 \end{bmatrix}$$

Example: Indeterminate beam; load-displacement relationships. **Matrix Slope-Deflection Method**





M₁, through M₄ are "fixed-end moments." P₁ is the only "possible"; it's the only possible displacement (A and C are fixed).

Free body (of joints)

(For reference, see "Slope-Deflection Equations.")


$$\{P\} = \begin{bmatrix} P_1 \end{bmatrix} = \begin{bmatrix} -(M_2 + M_3) \end{bmatrix} = \begin{bmatrix} +30.408 \end{bmatrix} kN \bullet m$$


$$[S] = \begin{bmatrix} \frac{4EI_1}{L_1} & \frac{2EI_1}{L_1} & 0 & 0 \\ \frac{2EI_1}{L_1} & \frac{4EI_1}{L_1} & 0 & 0 \\ 0 & 0 & \frac{4EI_2}{L_2} & \frac{2EI_2}{L_2} \\ 0 & 0 & \frac{2EI_2}{L_2} & \frac{4EI_2}{L_2} \end{bmatrix} = \begin{bmatrix} \frac{4}{3} & \frac{2}{3} & 0 & 0 \\ \frac{2}{3} & \frac{3}{3} & 0 & 0 \\ \frac{2}{3} & \frac{3}{3} & 0 & 0 \\ 0 & 0 & \frac{4}{7} & \frac{2}{7} & \frac{2}{7} \\ 0 & 0 & \frac{2}{7} & \frac{4}{7} & \frac{2}{7} \end{bmatrix}$$
 EI here is set equal to 1. If we are interested in displacements or rotations, we can use a real set of flexural rigidities

$$\begin{bmatrix} [A] [S] [A]^T \end{bmatrix}^{-1} \{P\} = \{X\} \\ \begin{bmatrix} [S] [A]^T \end{bmatrix} \{X\} = \{F\} \\ \end{bmatrix} \begin{cases} \{X\} = \begin{bmatrix} X_1 \end{bmatrix} = \begin{bmatrix} 15.9642 \end{bmatrix} \\ \{F\} = \begin{bmatrix} F_1 \\ F_2 \\ F_3 \\ F_4 \end{bmatrix} = \begin{bmatrix} 10.6428 \\ 21.2856 \\ 9.1224 \\ 4.5612 \end{bmatrix} kN \bullet m$$

$$\{M'\} = \begin{bmatrix} M'_1 \\ M'_2 \\ M'_3 \\ M'_4 \end{bmatrix} = \begin{bmatrix} F_1 \\ F_2 \\ F_3 \\ F_4 \end{bmatrix} + \begin{bmatrix} M_1 \\ M_2 \\ M_3 \\ M_4 \end{bmatrix} = \begin{bmatrix} 10.6428 \\ 21.2856 \\ 9.1224 \\ 4.5612 \end{bmatrix} + \begin{bmatrix} -2.25 \\ 2.25 \\ -32.658 \\ 63.27 \end{bmatrix} = \begin{bmatrix} 8.3928 \\ 23.5356 \\ -23.5356 \\ 67.8312 \end{bmatrix} kN \bullet m$$

Example: Indeterminate frame; load-displacement relationships. Matrix Slope-Deflection Method





Free body (of joints)

$$[A] = \begin{array}{c|cccc} & M_1 & M_2 & M_3 & M_4 \\ P_1 & 0 & 1 & 1 & 0 \\ P_2 & 0 & 0 & 0 & 1 \\ P_3 & 0 & 0 & -1/6 & -1/6 \end{array}] = \begin{bmatrix} 0 & 1 & 1 & 0 \\ 0 & 0 & 0 & 1 \\ 0 & 0 & -1/6 & -1/6 \end{bmatrix}$$

$$\{P\} = \begin{bmatrix} P_1 \\ P_2 \\ P_3 \end{bmatrix} = \begin{bmatrix} -(M_2 + M_3) \\ -(M_4) \\ 1 \end{bmatrix} = \begin{bmatrix} -52.5 \\ -1.5 \\ 1 \end{bmatrix} \text{ kN} \bullet \text{m}$$

$$[S] = \begin{bmatrix} \frac{4EI_1}{9} & \frac{2EI_1}{9} & 0 & 0 \\ \frac{2EI_1}{9} & \frac{4EI_1}{9} & 0 & 0 \\ 0 & 0 & \frac{4EI_2}{6} & \frac{2EI_2}{6} \\ 0 & 0 & \frac{2EI_2}{6} & \frac{4EI_2}{6} \end{bmatrix} = \begin{bmatrix} 111.111*10^6 & 55.555*10^6 & 0 & 0 \\ 55.555*10^6 & 111.111*10^6 & 0 & 0 \\ 0 & 0 & 83.333*10^6 & 41.666*10^6 \\ 0 & 0 & 41.666*10^6 & 83.333*10^6 \end{bmatrix}$$

$$\begin{bmatrix} [A] [S] [A]^T \end{bmatrix}^{-1} \{P\} = \{X\}$$

$$\begin{bmatrix} [S] [A]^T \end{bmatrix} \{X\} = \{F\}$$

$$\begin{cases} X_1 \\ X_2 \\ X_3 \end{bmatrix} = \begin{bmatrix} -4.32 \text{E-}7 \\ -3.6 \text{E-}7 \\ -2.232 \text{E-}6 \end{bmatrix} \text{ radians (+, clockwise)}$$

$$\text{meters}$$

$$\begin{cases} F_1 \\ F_2 \\ F_3 \\ F_4 \end{bmatrix} = \begin{bmatrix} -24 \\ -48 \\ -4.5 \\ -1.5 \end{bmatrix} \text{ kN•m}$$

$$\{M'\} = \begin{bmatrix} M'_1 \\ M'_2 \\ M'_3 \\ M'_4 \end{bmatrix} = \begin{bmatrix} F_1 \\ F_2 \\ F_3 \\ F_4 \end{bmatrix} + \begin{bmatrix} M_1 \\ M_2 \\ M_3 \\ M_4 \end{bmatrix} = \begin{bmatrix} -24 \\ -48 \\ -4.5 \\ -1.5 \end{bmatrix} + \begin{bmatrix} -54 \\ 54 \\ -1.5 \\ 1.5 \end{bmatrix} = \begin{bmatrix} -78 \\ 6 \\ -6 \\ 0 \end{bmatrix} \text{ kN•m}$$

Stiffness Matrix

For Trusses

$$[S] = \begin{bmatrix} e_1 & e_2 & e_3 & e_4 & e_5 & \dots & e_n \\ \hline F_1 & A_1E & 0 & 0 & 0 & 0 & 0 & 0 \\ \hline I_1 & A_2E & 0 & 0 & 0 & 0 & 0 \\ \hline I_2 & 0 & A_2E & 0 & 0 & 0 & 0 & 0 \\ \hline I_3 & 0 & 0 & A_3E & 0 & 0 & 0 & 0 \\ \hline I_4 & 0 & 0 & 0 & A_4E & 0 & 0 & 0 \\ \hline I_5 & 0 & 0 & 0 & 0 & A_5E & 0 & 0 \\ \hline I_5 & 0 & 0 & 0 & 0 & 0 & \vdots & 0 \\ \hline I_6 & 0 & 0 & 0 & 0 & 0 & 0 & \frac{A_nE}{L_n} \end{bmatrix}$$

For Beams and Frames

$$[S] = \begin{bmatrix} \theta_1 & \theta_2 & \theta_3 & \theta_4 & \dots & \dots \\ M_1 & \frac{4EI_1}{L_1} & \frac{2EI_1}{L_1} & 0 & 0 & \dots & \dots \\ M_2 & \frac{2EI_1}{L_1} & \frac{4EI_1}{L_1} & 0 & 0 & \dots & \dots \\ M_3 & 0 & 0 & \frac{4EI_2}{L_2} & \frac{2EI_2}{L_2} & \dots & \dots \\ M_4 & 0 & 0 & \frac{2EI_2}{L_2} & \frac{4EI_2}{L_2} & \dots & \dots \\ \vdots & \dots & \dots & \dots & \dots & \dots \\ \vdots & \dots & \dots & \dots & \dots & \dots \end{bmatrix}$$

Reference:

Wang, C. K., Introductory Structural Analysis with Matrix Methods, (1973)

McMinn, S. J., Matrices for Structural Analysis, (1962)

Hibbeler, R. C., Structural Analysis, (1997)

Wang, C. K., Structural Analysis on Microcomputers, (1986)

Wang, C. K., Intermediate Structural Analysis, (1983)

This is Page 8

Click here to go to page 1.