

- 1. Open Input Section door.
- 2. Remove 1/4-20 bolts from Transformer Front-Access Panel using 9-16 socket wrench.
- 3. Remove main section of Transformer Front-Access Panel.





- 4. Slide out small section of Transformer Front-Access Panel.
- 5. Transformer can be accessed for front-IR scans.

