Pt100 schematic for factory wiring to bottom of terminal block.

