

Open Source 2 and lock OFF:

- 1. Open (turn OFF) Source 2 MCCB.
- 2. Lock Source 2: Turn **S2 key** to extend locking bar on the breaker.

Source 2 is now locked OFF, but Source 1 is active.



3. Remove **S2 Key** from Source 2 lock.

Insert **S2 Key** in **S2 key position** in dead front panel Kirk-Key blocks.