

Subfeed CTs are hung in the PDU in groups of three (3). CTs must be installed over the correct load cables when cables are attached to subfeed breakers.

Each CT is labeled to show the corresponding load cable (subfeed number-phase).

When installed over a phase power cable, the **arrow** on the label should point *towards* the load.

† CT2-B

Subfeed number

Subfeed phase

## Left Column Odd Numbers

## Right Column Even Numbers

1 Subfeed Breaker		2 Subfeed Breaker
3 Subfeed Breaker	Bus Bars	4 Subfeed Breaker
5 Subfeed Breaker		6 Subfeed Breaker
7 Subfeed Breaker		8 Subfeed Breaker