
Chapter 1 Monitoring Connections

Each single-phase reactor has Qty. (6) Pt100 temperature sensors installed in reactor windings.

Sensors wires are terminated to the terminal block in the Reactor controls compartment, which provides an interface between the Reactor and an external customer-provided monitoring system.

Remove the cover of the controls compartment to expose the terminal block. External monitoring system connections are made to the top of the terminal block and are provided by others.

Figure 1. Controls Compartment



_


Connect wires from the switchgear monitoring system to the top of the terminal block in the reactor controls compartment. Wiring is performed by others.

| The transfer is to be by the section finites: this section finit

Figure 2. Terminal Block for Sensor Wiring

2 —

Figure 3. Pt100 Sensor Wire Schematic



_

3