For front bottom access, phase cables are landed to staggered busbars allowing 2-hole compression or mechanical lugs.

Front bottom access is most often used with forward-facing transformer taps (shown).

Customer makes own cable entry cutouts in bottom front solid plate.

