

Attach the BCMS Connector for a CT set to the corresponding socket on the Resistor Board.

A copy of the above "Resistor Board" label is placed in the I-Line section.

\*The face of each CT has an "H1" imprint that should face towards the breaker. The arrow label on the CT side should point towards the load.

