

4. Turn **Bypass S1 Key** to extend bar and lock Kirk Keys in dead front panel.

Extending the locking bar prevents removing the **Bypass Source 2 Key**, preventing bypass cross-connect.

5. Remove **Bypass S1 Key** from dead-front panel lock.

Insert **Bypass S1 Key** into Bypass Source 1 MCCB lock.

6. **Unlock Bypass Source 1** MCCB, moving blocking bar to the right.

Close (Turn ON) MCCB Bypass Source 1.