Screen headers show counts of outstanding alarms and warnings. Green check mark indicates no alarms or warnings outstanding.

Go to the ALARM screen to see alarm details.

| ALARMS | 5 | PDI DISPLAY | PDI |
| WARNINGS | 0 | | smiths power |

HOME | ALARM | DEVICES | SETUP | HELP

BCMS Over Volt Main
-- 4/22/2013 15:13:16

BCMS Over Volt Main
-- 4/22/2013 15:13:20

BCMS KW Under Volt Main
-- 4/22/2013 15:13:24

CLEAR ALL

SILENCE HORN