2. There are (5) ABCNG cables from inside cam-loks to bus bars.

Disconnect wires to CTs on these cables.

Disconnect all (5) cables at both ends (at bus bars and cam-loks).

Remove all (5) cables along with any CTs on these cables.

