

Standard Operating Procedure

KTES (Kantech Telephone Entry System) Factory Default & Configuration Procedure

Document No.	SOP-LV-011
Revision	1.0
Effective Date	2026-07-22
Review Cycle	Annual
Applies To	Field Technicians, Installers
Jurisdiction	Ontario / Manitoba
Owner	Apex – Operations
Approved By	_____

NOTE ON THIS DOCUMENT:

The factory default steps below are drawn directly from Kantech's official KTES Installation Manual (DN1769). Full VUI configuration menu steps are not reproduced here — technicians must reference the Kantech KTES Programming Manual (DN1770) for the complete configuration walkthrough. Do not attempt configuration from memory alone.

1. Purpose

This procedure defines the standard method for resetting a Kantech KTES (Telephone Entry System) door entry unit to factory default and configuring it for use on an Apex-installed access control system, ensuring consistent commissioning across sites.

2. Scope

Applies to all Apex technicians installing, replacing, or troubleshooting Kantech KTES door entry / telephone entry units.

3. Regulatory & Reference Standards

- Ontario Occupational Health and Safety Act (OHSA) and O. Reg. 213/91 – Construction Projects
- Manitoba Workplace Safety and Health Act
- CSA C22.1 – Canadian Electrical Code, low-voltage wiring practices
- Manufacturer reference: Kantech Telephone Entry System (KTES) Installation Manual, document DN1769
- Manufacturer reference: Kantech KTES Programming Manual, document DN1770 (required for full VUI configuration steps)

4. Tools & Materials Required

- KTES cabinet key (required to open the unit)
- Small flathead or Phillips screwdriver, as required for the jumper header
- VUI (Kantech's on-unit programming interface) access, or laptop with appropriate Kantech software per the Programming Manual
- Site IP addressing scheme / network configuration sheet, if the KTES is network-connected
- PPE per SOP-LV-004

5. Before You Start

Confirm you are able to:

- Open the KTES cabinet with the key
- Locate the reset button (SW1) and the two jumpers, JP1 and JP2, on the main board
- Observe the blue Heartbeat LED on the board

6. Factory Default Reset – KTES

KTES factory default uses jumpers JP1/JP2 in combination with the reset button (SW1).

- 1. Remove the JP1 and JP2 jumpers (Factory Default position — confirm jumper position against the manufacturer's Table 4 in the Installation Manual before removing, as jumper position tables vary by firmware revision).
- 2. Press the reset button (SW1).
- 3. Check the blue Heartbeat LED pattern. Factory Default is confirmed by continuous long pulses — do not proceed until this pattern is observed.
- 4. Put the JP1 and JP2 jumpers back in their normal operating position, then close and lock the KTES cabinet.
- 5. Configure the KTES using the VUI, following the Kantech KTES Programming Manual (DN1770) for the full menu walkthrough.

NOTE:

The Soft Reset and Hard Reset options can also be performed directly from the VUI without opening the KTES cabinet — refer to the KTES Programming Manual (DN1770) for those procedures if a full factory default is not required.

7. Configuration

Full configuration (phone number programming, relay timing, access codes, and integration with EntraPass or a third-party controller) is performed through the VUI per the Kantech KTES Programming Manual (DN1770). Do not attempt to configure a KTES from memory or by trial-and-error — incorrect relay or door-release timing settings can create a security or life-safety issue at an occupied site. Keep a copy of the current Programming Manual accessible in the field (digital or printed) when commissioning a KTES.

8. Verification

- Confirm the KTES powers up and displays normal (non-fault) status after reconfiguration
- Test the door release / relay function at least once before leaving site
- Confirm intercom/telephone entry function operates as expected, where applicable
- Confirm event/access logs are reaching EntraPass or the connected controller, where applicable
- Record the unit's configuration details (phone number, relay settings, connected controller) on the site network/access configuration sheet

9. Notes

If a KTES does not respond as expected after a factory default and reconfiguration attempt, do not repeat the jumper/reset sequence speculatively — stop and consult the Kantech KTES Installation Manual (DN1769) Troubleshooting section, or escalate to the Site Supervisor before continuing.

References

- Kantech Telephone Entry System (KTES) Installation Manual, DN1769
- Kantech KTES Programming Manual, DN1770
- SOP-LV-004 — Power Tools Safety (PPE reference)
- SOP-LV-010 — KT-1/KT-2/KT-4/KT-400 Controller Default & Configuration