

Standard Operating Procedure

Credential Enrollment Procedure

Document No.	SOP-LV-022
Related Documents	SOP-LV-017, SOP-LV-021
Revision	1.0
Effective Date	2026-07-23
Review Cycle	Annual
Applies To	Field Technicians, Installers, System Administrators
Jurisdiction	Ontario / Manitoba
Owner	Apex – Operations
Approved By	_____

1. Purpose

This procedure establishes a consistent method for enrolling, assigning, and deactivating access control credentials (cards, fobs, mobile credentials), reducing the risk of orphaned credentials, incorrect access level assignment, or unauthorized access.

2. Scope

Applies to Apex technicians and system administrators enrolling credentials into a Kantech EntraPass system, whether for initial system commissioning or ongoing cardholder management.

3. Authorization Before Enrollment

- Do not enroll a credential or assign an access level without confirmation from an authorized site contact (the client's designated system administrator or manager) — credential issuance is an access decision, not a technical one, and Apex technicians should not be making that call unilaterally.
- Confirm which access level(s) the site contact wants assigned before enrollment — do not default to the broadest access level as a convenience, and do not guess at what a new cardholder “probably needs.”

4. Enrollment Process

- Collect the cardholder's required identifying information per the site's data collection policy (name, department, badge/employee number, etc.) — confirm what fields the client requires before starting, since this varies by site.
- Present or scan the physical credential to enroll its card number into EntraPass, following the current EntraPass Administration Guide's cardholder enrollment workflow for the specific edition/version in use.
- Assign the confirmed access level(s) (Section 3) to the cardholder record.
- Set an activation date and, where the site requires it, an expiration date for the credential (e.g., contractor or temporary access) — do not leave a temporary credential open-ended by default.
- Where photo ID or additional cardholder fields are part of the site's standard, complete them at enrollment time rather than leaving them for later — incomplete cardholder records are difficult to clean up after the fact.

5. Testing the Credential

- Test the newly enrolled credential at a representative door before considering enrollment complete — confirm it grants access where expected and is denied where it should be (a door outside its assigned access level).
- Confirm the credential read produces a correctly identified event in the EntraPass message desktop (correct cardholder name, correct door) — not just that the door unlocked.

6. Deactivation & Return

- Deactivate a credential in EntraPass immediately upon notification that it should no longer have access (termination, lost card, role change) — do not batch these changes or delay pending a convenient time.

- Distinguish between deactivating a credential (removing its access while preserving the historical record) and deleting a cardholder record entirely — confirm with the site contact which action they want, since deleting removes historical audit trail that may be needed later.
- Where physical cards are returned, follow the site's policy for physical disposition (destroy, reissue, or retain) — this is a site policy decision, not a default Apex practice.

7. Audit & Recordkeeping

- Periodically reconcile the EntraPass cardholder list against the site's active personnel/tenant list where this is part of the service agreement — orphaned active credentials for people who have left are a real security gap, not just administrative untidiness.
- Record credential enrollment and deactivation actions per the site's audit requirements — some sites (institutional, government, healthcare) may require a formal change log beyond what EntraPass captures automatically.

8. References

- Current Kantech EntraPass Administration Guide for the specific edition/version in use (governs over this SOP for menu-level steps)
- SOP-LV-017 — Card Reader Installation & Wiring
- SOP-LV-021 — EntraPass Server & Software Setup