# ARM-Embedded-Path CMSIS-Basics

Pavel Pys

October 24, 2025

### **Overview**

Introduction

• ARM-Architecture

Practice

## **Introduction**What is the target of this journey?

In these slides, I want to document my learning progress in handling ARM microcontrollers, in my case from the company ST-Microelectronics. Ultimately, this slide set should become a reference work. - Hanover 21.10.2025

### Introduction What is the ARM architecture?

- A microprocessor architecture developed by the British computer company Acorn in 1983. Initially, ARM stood for Acorn RISC Machine, and was later changed to Advanced RISC Machines.
- The company does not manufacture the chips itself, but instead grants different licenses to semiconductor development companies, which then manufacture based on this architecture.

### Introduction What is the ARM architecture?

Today, many renowned chip manufacturers build their chips on the ARM architecture.

#### Notable manufacturers:

- Apple
- Qualcomm Inc.
- Samsung Electronics
- Huawei Technologies Co. Ltd.
- ST-Microelectronics
- ...

## **Introduction**Market share of ARM chips

The market share of ARM-based chips is very large, but depends on the system. In mobile phones, it was already about 98% in 2005 (at least one ARM processor).

In data and server centers, ARM is currently growing rapidly, though its goal of reaching 50% market share by the end of 2025 is considered ambitious by some analysts.

## **Introduction**What are the advantages of ARM?

The ARM architecture offers several advantages:

- ARM uses the RISC principle.
- ARM cores are small and can be easily combined.
- Low costs and licensing flexibility.
- Large ecosystem.
- High performance per watt (efficiency).
- Good security features.
- Wide range of applications.

## **ARM**What is a Microcontroller Architecture?


A microcontroller architecture describes the internal structure and functionality of a microcontroller meaning how the individual components on the chip are interconnected and how they work together.

The architecture consists of: CPU, memory, bus system, peripherals, clock source, and power supply as well as reset logic.

## **ARM**What is a Microcontroller Architecture?

In summary: A microcontroller architecture is the blueprint of how CPU, memory, peripherals, buses, and clock sources work together on a single chip to execute tasks efficiently.

### ARM RISC vs CISC



The graphic shows the pipelines of RISC and CISC. RISC processes instructions in parallel (one new instruction per clock cycle), while CISC processes longer and more complex instructions sequentially.

October 24, 2025

## ARM Architecture Structure

Register-based design (e.g., 16-32 registers) with a pipeline architecture for parallel instruction execution.

Harvard or Von Neumann structure depending on the type.

### Components:


- ALU (Arithmetic Logic Unit)
- Register set (R0-R15)
- Program Counter, Stack Pointer
- Interrupt Controller
- Bus interfaces (AHB, APB...)

## ARM Architecture Structure

Cortex-M microcontrollers typically implement a modified Harvard architecture, where instruction and data buses are separate internally, but share a unified memory space.

### ARM

### ARM - Cortex M Block-Diagram



October 24, 2025 Pavel Pys

### **ARM**

### WIC - Wake-up Interrupt Controller

In deep sleep (core clock and NVIC logic powered down), the WIC acts as a shadow interrupt latch, allowing selected IRQs to wake the system.

#### Control of WIC behavior through:

- NVIC->ISER (enable/disable interrupts)
- NVIC priorities and BASEPRI/PRIMASK (only unmasked and sufficiently prioritized IRQs can wake the system)
- Sleep depth via SCB->SCR.SLEEPDEEP (Deep Sleep vs. normal Sleep)
- WFI/WFE (how you enter sleep)
- Peripheral wake sources (EXTI edge, RTC alarm, USART-RX, IšC address match, etc.)

NVIC is tightly coupled to the Cortex-M core through the System Control Block (SCB), forming the Exception Model

## **ARM**NVIC - Nested Vector Interrupt Controller

The Nested Vector Interrupt Controller (NVIC) is the hardware block in the ARM Cortex-M core that:

- Accepts, prioritizes, nests, and forwards interrupts (IRQs) to the CPU,
- Can mask, enable, set/clear pending interrupts,
- Integrates exception handling (Reset, NMI, HardFault, SysTick, etc.) using the same mechanisms.

It is directly integrated into the core, not in the periphery, and coupled with the System Control Block (SCB).

## ARM Core

The ARM core is the actual processing core (CPU core) in the microcontroller - meaning the logical unit that executes code, performs arithmetic operations, processes interrupts, and communicates with memory and peripherals via buses.

In this case (STM32F103), this is an ARM Cortex-M3, based on the ARMv7-M architecture.

#### This means:

- 32-bit RISC processor
- Harvard architecture (separate buses for code and data)
- Pipeline design
- Thumb-2 instruction set (compact mix of 16- and 32-bit instructions)

### **ARM**

#### **ARM Core: Architectural Features**

Harvard Architecture:

Separate buses for code (I-Bus) and data (D-Bus) enables parallel reading of instructions and data

Thumb-2 Instruction Set:

 $\operatorname{Mix}$  of 16- and 32-bit instructions compact code with full functionality

**NVIC** Integration:

Interrupt handling directly in the core no external interrupt controllers needed

Sleep and Deep Sleep Modes:

Power saving functions via WFI/WFE instructions

### ARM Core: Architectural Features

#### Harvard Concept in Action:

- Instructions are fetched via the I-Bus from Flash memory
- Data (variables, peripheral registers) via the D-Bus
- System and debug accesses (DMA, DAP, Trace) via the System bus

This allows the Cortex-M3 to simultaneously read an instruction and access data.

### ARM Core: Conclusion

The ARM Cortex-M3 core is a 32-bit RISC processor with:

- Efficient pipeline design,
- Integrated interrupt controller,
- Memory protection (MPU),
- Integrated debug/trace architecture (CoreSight),
- And ideal for deterministic real-time and embedded applications (e.g., in your STM32F103).

It is the heart of the microcontroller - all other components (Flash, SRAM, Timer, UART, etc.) are built around it as peripherals.

## ARM DAP - Debug Access Port

The DAP (Debug Access Port) is the interface between your debugger (e.g., ST-Link, J-Link) and the internal debug and trace units of your ARM core.

The DAP acts as the "debug router" between the external world and the CoreSight internals.

The DAP consists of an AP (Access Port) and DP (Debug Port) interface e.g. SW-DP for SWD or JTAG-DP for JTAG.

# **ARM**MPU - Memory Protection Unit

The MPU (Memory Protection Unit) is a hardware unit in the ARM core that divides memory into regions and monitors access rights (read/write/execute) for each region.

It prevents your code from accidentally writing to "forbidden" areas or executing from unauthorized memory.

It is thus a mini memory protection system, similar to an MMU (Memory Management Unit) in a PC - but simpler and without virtual addresses.

## CMSIS vs HAL CMSIS (Cortex Microcontroller Software Interface Standard)

```
// Direct register access
RCC->APB2ENR |= RCC_APB2ENR_IOPCEN;  // Enable clock
GPIOC->BSRR = GPIO_BSRR_BR13;  // Set pin to LOW
```

- Vendor: ARM (Cortex-M standard)
- Abstraction level: Low (register-level via CMSIS-Device headers)
- What is it?: Standardized core intrinsics + device header mapping (names/addresses)

### CMSIS vs HAL HAL (Hardware Abstraction Layer)

- Vendor: STMicroelectronics (only for STM32)
- Abstraction level: High (hides registers)
- What is it?: Convenient function library

### CMSIS vs HAL

#### Turning LED on - Both approaches:

#### CMSIS:

```
RCC->APB2ENR |= RCC_APB2ENR_IOPCEN;
GPIOC->CRH &= ~(GPIO_CRH_CNF13 | GPIO_CRH_MODE13);
GPIOC->CRH |= GPIO_CRH_MODE13_1;
GPIOC->BSRR = GPIO_BSRR_BR13;
```

- 4 lines of code
- You need to understand registers
- Fast (direct)

### CMSIS vs HAL Turning LED on - Both approaches:

#### HAL:

- 7+ lines of code
- Readable and self-explanatory
- Slower (many function calls)

HAL typically requires more lines of code due to function calls and initializations.

### **CMSIS vs HAL**

Aspect	CMSIS / Register	HAL (STM32)
Performance Code size (blink)	typically 3–10 $\times$ faster* $\sim$ 3–6 KB	slower (wrapper calls) $\sim$ 15–25 KB
Learning curve Readability	steeper terse / technical	flatter very readable
Portability	vendor-agnostic concepts; device headers per family	portable within STM32 family
Debugging	transparent (no hidden layers)	black-boxy at times
Control	100%	limited by API

<sup>\*</sup> Can be much more in tight loops/ISRs, depends on inlining and wait states.

October 24, 2025

# CMSIS vs HAL Why should you learn CMSIS?

Understand how hardware REALLY works.

With CMSIS you understand that you're setting a specific bit in a hardware register. With HAL you're just calling a function.

### CMSIS vs HAL

### **Performance in Time-Critical Applications**

```
// HAL: ~50-100 CPU cycles
HAL_GPIO_WritePin(GPIOC, GPIO_PIN_13, GPIO_PIN_SET);
// CMSIS: ~2-3 CPU cycles
GPIOC->BSRR = GPIO_BSRR_BS13;
```

At 72 MHz: HAL takes 1.4 ts, CMSIS only 0.04 ts - 35x faster!

Important for: Fast PWM, Bit-banging (WS2812 LEDs, OneWire), Interrupt Service Routines and real-time protocols

Exact cycle counts depend on compiler optimization, inlining and bus wait states. Rule of thumb: CMSIS/register-level calls are typically an order of magnitude faster than HAL wrappers.

## CMSIS vs HAL Smaller Code = More Space for Your Program

STM32F103C6: 32 KB Flash

HAL project: HAL library 1525 KB Leaves ~717 KB for

your code

CMSIS project: CMSIS only 36 KB Leaves ~2629 KB for

your code

Note: The exact size depends on which HAL modules are linked. Even small HAL-based projects often use significantly more Flash due to abstraction layers and initialization code.

### CMSIS vs HAL Understanding Other MCUs

When you switch to other manufacturers (ESP32, Nordic nRF, Raspberry Pi Pico), there is no STM32 HAL. Each vendor provides its own SDK (e.g., ESP-IDF, nRF5). But the register-level principle remains the same.

```
// STM32 (CMSIS)

GPIOC->BSRR = GPIO_BSRR_BS13;

// ESP32 (IDF)

GPIO.out_w1ts = (1 << 13);

// nRF52 (Nordic)

NRF_GPIO->OUTSET = (1 << 13);
```

# CMSIS vs HAL Jobs and Industry

In industry among professional embedded developers:


HAL: 20% (prototyping, quick projects) CMSIS/Register-Level: 80% (production, performance)

### Why? Because:

- Firmware must be small (cheaper MCUs)
- Firmware must be fast (real-time requirements)
- Developers must understand hardware (troubleshooting)

### Practice Blink Test

Just as the "Hello World" project is commonly used in pure software programming, here a Blink project is described. This project makes an arbitrary LED blink using an ARM microcontroller. In my case, a **STM32F103C6T6A**.



October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 32/68


### Practice Blink Test

The program flow is simple: The LED is turned on, this state is maintained for 2 seconds, then the LED is turned off and the processor waits for 1 second before the LED turns on again. This sequence is then executed continuously through a loop.

In my case, the LED is controlled via pin PC13. Flashing and debugging is done using an ST-Link, therefore in CubeIDE the debug parameter must be set to Serial Wire.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 33/68


## Practice CubeIDE Configuration



The pin **PC13** is configured directly in the code.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 34/68

# Practice CubeIDE Configuration



October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 35/68

## Practice Useing HAL

Although HAL is not the main topic here, its interesting to see how the same project looks using the HAL library.

October 24, 2025

## Implementation with HAL

```
int main(void)
    {
        HAL_Init();
        SystemClock_Config();
        MX_GPIO_Init();
        while (1)
```

The GPIO configuration is implemented directly by the HAL library, whereas in CMSIS you have to configure the registers yourself.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 37/68

## Implementation with HAL


```
while (1)
        // LED ON for 2 seconds (active-low:
    GPIO PIN RESET)
        HAL GPIO WritePin(GPIOC, GPIO PIN 13,
    GPIO PIN RESET);
        HAL Delay(2000);
        // LED OFF for 1 second (active-high:
    GPIO PIN SET)
        HAL GPIO WritePin(GPIOC, GPIO PIN 13,
    GPIO PIN SET);
        HAL Delay(1000);
    }
```

Delay and WritePin functions are also provided by the HAL library, the code closely resembles Arduino code.

38/68

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice

For the LED to blink (toggle), the MCU must know exactly when it should be ON, how long it should be ON, and when the LED must be turned OFF. For this, a delay function implemented with the SysTick\_Handler is used.




**SysTick\_Handler:** The SysTick is a timer in the processor that triggers an interrupt at regular intervals (here every millisecond). It's like an alarm clock that rings every millisecond. When the alarm rings, the **SysTick\_Handler** function is called. This function does only one thing: it increments the counter **msTicks** by 1.

Interrupt: Imagine you are a teacher grading exams (that's your main program). Suddenly the telephone rings (that's the interrupt). You interrupt the grading, answer the phone and talk to the caller (that's the interrupt handler). When the call is finished, you return to grading and continue exactly where you left off.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 40/68

#### **Functional Architecture and Logic**



The system utilizes a delay function that waits for milliseconds. It is based on a global counter **msTicks** that is incremented every millisecond by the SysTick interrupt.

The function stores the current value of **msTicks** at the beginning (**startTicks**). It then waits in a loop until the difference between the current **msTicks** and **startTicks** becomes greater than or equal to the desired **ms** value.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 41/68

#### **Functional Architecture and Logic**

```
void delay_ms(uint32_t ms){
   uint32_t startTicks = msTicks;
   while ((msTicks - startTicks) < ms);
}</pre>
```

The msTicks counter overflows after approximately 49 days from 4,294,967,295 to 0, but the calculation (msTicks - startTicks) still functions correctly because subtraction with unsigned integers always produces the correct result.

This approach utilizes the hardware timer (not "estimated" waiting), ensuring that 1000ms are exactly 1000ms.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 42/68

Why uint32\_t:

**System independence**: If one uses int, the compiler might allocate different memory sizes (e.g., 2 bytes on a 16-bit system vs. 4 bytes on a 32-bit system). uint32\_t ensures that the data type is always exactly 32 bits, regardless of the architecture.

Hardware registers: When programming microcontrollers such as an STM32, one often needs to work with hardware registers that have a fixed bit width (e.g., 32 bits). uint32\_t fits perfectly and facilitates bit manipulation.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 43/68

#### **Functional Architecture and Logic**

This example utilizes the internal clock source.

```
void SystemClock_Config(void){
    RCC OscInitTypeDef RCC_OscInitStruct = {0};
    RCC_ClkInitTypeDef RCC_ClkInitStruct = {0};
    // HSI as oscillator
    RCC_OscInitStruct.OscillatorType =
   RCC OSCILLATORTYPE HSI;
    RCC OscInitStruct.HSIState = RCC HSI ON;
    // No PLL used
    RCC_OscInitStruct.PLL.PLLState = RCC_PLL_NONE;
}
```

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 44/68

- Configures the internal 8MHz oscillator (HSI)
- No clock division for buses
- Simplest clock configuration

```
SysTick_Config(SystemCoreClock / 1000);
```

Configures the SysTick timer for an interrupt every 1ms. SystemCoreClock / 1000 divides the CPU clock frequency by 1000 for 1ms intervals. During each interrupt, msTicks is incremented.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 45/68

What happens if the clock configuration is not performed or is performed incorrectly?

### SystemClock\_Config():

This function configures the system clock. Without it, the microcontroller runs with the default clock (e.g., internal HSI oscillator), but potentially not at the expected frequency.

Specifically, it enables the HSI (Internal High-Speed Clock) and sets the clock frequency for the CPU and peripherals.

Without clock configuration, the clock might be too slow or might not run at all, causing the microcontroller to malfunction.

### SysTick\_Config():

This function configures the SysTick timer, which is required for the delay\_ms function. Without it, msTicks is not incremented, and the delay function would wait indefinitely.

### GPIO\_LED\_Init():

This function activates the clock for GPIOC via RCC->APB2ENR |= RCC\_APB2ENR\_IOPCEN. For the GPIOC clock to be activated, the RCC (Reset and Clock Control) module itself must be properly clocked. This is ensured by SystemClock\_Config(). Without the system clock, setting the RCC\_APB2ENR\_IOPCEN bit might have no effect because the RCC module is not operational.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 47/68

### Summary

Without clock configuration, the microcontroller remains in a reset state or operates with an unconfigured clock, resulting in no peripherals (including GPIO) functioning. The GPIO initialization assumes that the system clock has already been configured.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 48/68

#### **Functional Architecture and Logic**

```
void GPIO LED Init(void){
// Enable clock
RCC->APB2ENR |= RCC APB2ENR IOPCEN;
// Configure pin
GPIOC->CRH &= ~(GPIO_CRH_CNF13 | GPIO_CRH_MODE13);
GPIOC->CRH |= GPIO_CRH_MODE13_1;
// Turn off LED initially
GPIOC->BSRR = GPIO BSRR BS13;
```

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 49/68

### Enable GPIOC clock (RCC\_APB2ENR)

RCC->APB2ENR |= RCC\_APB2ENR\_IOPCEN

Enables the peripheral clock for **GPIO port C**. The bit lives in the STM32 reference manual under *RCC\_APB2ENR APB2 peripheral clock enable register* (field **IOPCEN**).

The compound operator |= performs a readmodifywrite:

- 1. Read the current value of RCC->APB2ENR.
- 2. OR it with the mask RCC\_APB2ENR\_IOPCEN.
- 3. Write the result back to RCC->APB2ENR.

Note: RCC\_APB2ENR\_IOPCEN equals (1u  $\ll$  4) (i.e., only bit 4 set).

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 50/68

#### **Functional Architecture and Logic**

#### Why not use =?

The advantage of |= is that it sets exactly one bit and leaves all other bits untouched.

If you wrote RCC->APB2ENR = RCC\_APB2ENR\_IOPCEN you would:

- enable GPIOC,
- but clear every other bit in the register disabling any APB2 peripheral that was previously enabled (AFIO, GPIOA/B, ADC1, ...).

#### **Conclusion:**

- use |= to set bits,
- use &= ~mask to clear bits (e.g., RCC->APB2ENR &= ~RCC\_APB2ENR\_IOPCEN;).

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 51/68

**Functional Architecture and Logic** 

#### About the macro

RCC\_APB2ENR\_IOPCEN is a descriptive macro provided by STMicroelectronics in the device header. It expands to the bit mask ( $1u \ll 4$ ), i.e., only bit 4 is set.

Therefore the following are equivalent:

- RCC->APB2ENR  $\mid$  = (1u  $\ll$  4);
- RCC->APB2ENR |= RCC\_APB2ENR\_IOPCEN;

Using the named macro is **clearer** and often more **portable** across STM32 families, where bit positions may differ.

Good practice: enable the port clock before writing any GPIO registers for that port.

#### Bit-Masking: Clear Bits Operation

This is a "clear bits" step:

- GPIO\_CRH\_CNF13 | GPIO\_CRH\_MODE13 creates a mask covering all 4 bits of Pin 13 (CNF + MODE).
- ~(...) inverts the mask  $\rightarrow$  ones everywhere, except these 4 bits (there 0).
- &= with this inverted mask sets exactly these 4 bits to 0, leaving all other bits unchanged.

**Purpose:** Clear the 4 configuration bits of PC13 so no old state remains.

GPIOC->CRH &= 
$$\sim$$
 (0xFu  $\ll$  20);

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 53/68

Pin Configuration: CNF and MODE Bits

Each GPIO pin uses 4 bits: [CNF1 CNF0 MODE1 MODE0]

## MODE[1:0] (outputs speed / input select):

- 00 = Input mode
- 01 = Output 10 MHz
- 10 = Output 2 MHz
- 11 = Output 50 MHz

#### CNF[1:0] (depends on MODE):

- If MODE=00 (input): 00=Analog, 01=Floating, 10=Pull-up/Down, 11=Reserved
- If MODE≠00 (output): 00=General-Purpose Push-Pull, 01=General-Purpose Open-Drain, 10=Alternate-Function Push-Pull, 11=Alternate-Function Open-Drain

## Practice GPIO Reset State & Safe Pattern

#### After reset:

- All GPIOs: MODE=00 (Input), CNF=01 (Floating input)
- Debug pins (JTAG/SWD) are mapped to debug by default (free via AFIO\_MAPR)

#### Why this matters:

- Setting only MODE leaves CNF as-is.
- Example: MODE=10 with leftover CNF=01 ⇒ general-purpose open-drain output (not invalid, but often unintended for LEDs; cannot actively drive HIGH without pull-up).

### Safe approach (clean-then-set):

- GPIOC->CRH &= ~(0xFu « 20); // clear CNF:MODE for PC13
- GPIOC->CRH |= (0x2u ≪ 20); // CNF=00, MODE=10 ⇒ Output 2 MHz push-pull

**Key takeaway:** Always  $Clock \rightarrow Clear \rightarrow Set$ .

October 24, 2025

# Practice Setting MODE Bits Risky Approach

## Make PC13 an Output @ 2 MHz (keep CNF unchanged)

```
GPIOC->CRH |= GPIO_CRH_MODE13_1;
```

#### What this does:

- GPIO\_CRH\_MODE13\_1 = 0x00200000 sets bit 21
- Result: MODE13 = 10b Output 2 MHz
- Problem: CNF bits are NOT modified!

#### Why is this risky?

- After reset: CNF=01, MODE=00
- After this line: CNF=01, MODE=10 invalid config!

**Safe only if:** CNF was already set correctly before.

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 56/68

Best Practice: Clean-then-Set Pattern

### Recommended approach (always safe):

```
// Clear all 4 bits (CNF + MODE)
GPIOC->CRH &= ~(OxFu << 20);

// Set new configuration
GPIOC->CRH |= (Ox2u << 20);</pre>
```

#### What happens:

- $0xFu \ll 20 = 0x00F00000$  masks bits 23..20
- Clear these 4 bits, keep all others
- $0x2u \ll 20 = 0x00200000 \text{ sets CNF}=00, MODE=10$

**Calculation:** PC13 in CRH at  $(13 - 8) \times 4 = 20$ 

October 24, 2025

Complete Example: PC13 Configuration

## Configure PC13 as Output Push-Pull, 2 MHz

```
// 1. Enable GPIO Clock (CRITICAL!)

RCC->APB2ENR |= RCC_APB2ENR_IOPCEN;

// 2. Clear PC13 config (bits 23..20)

GPIOC->CRH &= ~(OxFu << 20);

// 3. Set: CNF=00, MODE=10 (2 MHz)

GPIOC->CRH |= (Ox2u << 20);
```

#### Three essential steps:

- 1. Enable Clock without this, writes are ignored!
- 2. Clear remove old configuration
- 3. Set apply new configuration

## Practice Bit Position Calculation

#### **General Formula:**

```
value = ((CNF « 2) | MODE) « offset
```

#### Offset Calculation:

- CRL (pins 0..7): offset = pin\_number \* 4
- CRH (pins 8..15): offset = (pin\_number 8) \* 4

#### **Examples:**

- PA3: CRL, offset =  $3 \times 4 = 12$
- PC13: CRH, offset =  $(13 8) \times 4 = 20$
- PB15: CRH, offset =  $(15 8) \times 4 = 28$

#### PA3 Output PP, 50 MHz:

```
GPIOA->CRL &= ~(0xFu « 12);
GPIOA->CRL |= (0x3u « 12);
```

## Reference Quick Reference

CNF	Output (MODE $\neq$ 00)	Input (MODE=00)
00	Push-Pull	Analog
01	Open-Drain	Floating
10	AF Push-Pull	Pull-up/-down
11	AF Open-Drain	Reserved

#### **Common Pitfalls:**

- Forgetting to enable GPIO clock
- Not clearing CNF+MODE before setting
- Assuming pins are in known state after reset

Key Takeaway: Always Clock Clear Set

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 60/68

## Practice GPIO Bit Set/Reset Register (BSRR)

#### What is BSRR?

- Bit Set/Reset Register
- 32-bit write-only register
- Allows atomic set and reset of GPIO pins
- No read-modify-write needed interrupt-safe!

### Register Layout (32 bits):

```
[BR15..BR0] [BS15..BS0]
[31....16] [15.....0]
```

#### Two sections:

- Bits 0-15 (BSy): Set bit y to HIGH (1)
- Bits 16-31 (BRy): Reset bit y to LOW (0)

October 24, 2025

## Practice BSRR Operation Principle

**Key concept:** Write 1 to trigger action, 0 is ignored

#### To SET a pin HIGH:

- Write 1 to corresponding BS bit (bits 0-15)
- Example: Set PC13 write 1 to bit 13

#### To RESET a pin LOW:

- Write 1 to corresponding BR bit (bits 16-31)
- Example: Reset PC13 write 1 to bit 29 (16+13)

#### Multiple pins simultaneously:

- Can set and reset different pins in same write
- Example: GPIOC->BSRR =  $(1 < 13) \mid (1 < (16+5));$

62/68

Sets PC13 HIGH, resets PC5 LOW atomically!

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice

## Practice Setting PC13 to HIGH

### Set PC13 to logical 1 (HIGH):

```
GPIOC->BSRR = GPIO_BSRR_BS13;
```

#### What happens:

- GPIO\_BSRR\_BS13 = 0x00002000 (bit 13 set)
- Writes 1 to bit 13 of BSRR
- Hardware sets PC13 output to HIGH
- All other pins remain unchanged

#### Bit calculation:

- Pin 13 BS13 bit position 13
- $2^{13} = 8192 = 0 \times 2000$
- Binary: 0000\_0000\_0000\_0000\_0010\_0000\_0000

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 63/68

## Practice Resetting PC13 to LOW

### Reset PC13 to logical 0 (LOW):

```
GPIOC->BSRR = GPIO_BSRR_BR13;
```

#### What happens:

- GPIO\_BSRR\_BR13 = 0x20000000 (bit 29 set)
- Writes 1 to bit 29 of BSRR (16 + 13)
- Hardware resets PC13 output to LOW
- All other pins remain unchanged

#### Bit calculation:

- Pin 13 BR13 bit position 16+13 = 29
- $2^{29} = 536870912 = 0 \times 20000000$
- Binary: 0010\_0000\_0000\_0000\_0000\_0000\_0000

October 24, 2025

## Practice BSRR vs ODR: Why use BSRR?

## Alternative: Using ODR (Output Data Register)

```
GPIOC->ODR |= (1 << 13);  // Set HIGH
GPIOC->ODR &= ~(1 << 13);  // Reset LOW</pre>
```

### Problem with ODR: Read-Modify-Write (RMW)

- Read Modify Write (3 steps)
- Not atomic race condition risk!

### Advantage of BSRR: Single write operation

- Atomic interrupt-safe
- Faster (1 instruction vs 3+)
- No critical section needed

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 65/68

# Practice Practical BSRR Examples

#### Toggle LED on PC13:

```
// LED ON (active-low)
GPIOC->BSRR = GPIO_BSRR_BR13;

// LED OFF
GPIOC->BSRR = GPIO_BSRR_BS13;
```

#### Multiple pins simultaneously:

```
// Set PC13 HIGH, reset PC14 LOW
GPIOC->BSRR = GPIO_BSRR_BS13 | GPIO_BSRR_BR14;
```

#### Why this is powerful:

- Both operations in single write cycle
- No intermediate states
- Perfect for synchronized outputs

October 24, 2025 Pavel Pys ARM-Embedded-Path Practice 66/68

#### Pattern 1: Simple pin control

Common BSRR Usage Patterns

```
#define LED_ON() GPIOC->BSRR = GPIO_BSRR_BR13
#define LED_OFF() GPIOC->BSRR = GPIO_BSRR_BS13
```

#### Pattern 2: Conditional set/reset

```
if (condition) {
    GPIOC->BSRR = GPIO_BSRR_BS13;
} else {
    GPIOC->BSRR = GPIO_BSRR_BR13;
}
```

#### Pattern 3: Clock pulse

```
GPIOC->BSRR = GPIO_BSRR_BS13; // HIGH
GPIOC->BSRR = GPIO_BSRR_BR13; // LOW
```

## Reference BSRR Quick Reference

#### **BSRR Bit Layout:**

Bits	Name	Function
0-15	BSy	Set pin y to HIGH (write 1)
16-31	BRy	Reset pin y to LOW (write 1)

#### **Quick formulas:**

- Set pin n HIGH: BSRR = (1 ≪ n)
- Reset pin n LOW: BSRR = (1 « (16+n))

#### **Best Practices:**

- Always prefer BSRR over ODR for pin control
- Use CMSIS macros (GPIO\_BSRR\_BSn/BRn) for clarity
- BSRR is write-only reading returns 0
- Setting both BS and BR for same pin: BR has priority

When to use ODR: Only when reading current output state is needed