

mooreVIEW

Site Admin, Login & Quick Start

Edge appliance · Cloud SaaS · Site pairing · User administration

A company powered by **The Purple Standard**
purple-standard.com

Suite version: 2.3.8

Document generated: 2026-08-17

Contents

- [Quick start — PC appliance](#)
- [Quick start — Cloud SaaS \(local dev\)](#)
- [Quick start — pair a site to cloud](#)
 - [On Cloud Studio \(/sites \)](#)
 - [On the edge appliance](#)
 - [Verify](#)
- [Login](#)
 - [Appliance \(port 3090\)](#)
 - [Cloud SaaS \(port 3100\)](#)
- [Cloud navigation](#)
- [Site admin — Sites page](#)
 - [Create a site](#)
 - [Manage sites](#)
 - [Repair / re-pair](#)
- [Site admin — Devices](#)
- [Site admin — Remote cameras](#)
 - [Operator flow \(cloud\)](#)
 - [Appliance camera quick start \(Reolink / ONVIF\)](#)
- [Site admin — Cloud remote uplink](#)
- [Tenant admin — People](#)
 - [Invite a user](#)
 - [Manage users](#)
- [Platform admin](#)
 - [Seed environment variables \(production\)](#)
- [Roles](#)
- [First-time commissioning \(appliance\)](#)
- [Troubleshooting](#)
- [Related documentation](#)

mooreVIEW — Site Admin, Login & Quick Start

Operator and administrator guide for **edge appliances** (port 3090) and **Cloud SaaS** (port 3100): sign-in, first-time setup, site pairing, remote cameras, and user administration.

Quick start — PC appliance

Local all-in-one MooreVIEW for Windows or Linux field use.

1. Install dependencies: `npm install`
2. Copy `.env.example` to `.env` (optional flags)
3. Start the server: `npm start` or `npm run start:pc`
4. Open <http://127.0.0.1:3090/login>
5. Sign in with default admin credentials (see Login section below)
6. Configure **Drivers** (Modbus, MQTT, HTTPS, or simulation), then **Tags** or apply a **device template**
7. Edit the **ST program**, click **Validate**, then **Start**

Windows installer: copy `dist/mooreview-appliance-mvp-suite-*` to the target PC, run **Install mooreVIEW.bat**, then **Start mooreVIEW.bat**.

IoT-Link (Linux gateway): upload the tarball, run `deploy/iot-link/install-generic.sh`, open `http://<gateway-ip>:3090/login`.

Bundled demo project: **duplex-lift-station** (`.est.zip` in `data/projects/`).

Press **F1** for in-app Help, **F2** for Training.

Quick start — Cloud SaaS (local dev)

Multi-tenant Cloud Studio with login, Sites, and fleet management.

```
npm install
npm run start:saas      # http://127.0.0.1:3100
npm run seed            # demo org + users (first time only)
```

Open <http://127.0.0.1:3100/login> and sign in with demo credentials (see Login section).

Production: deploy to a Linux VM (DigitalOcean recommended). See `docs/CLOUD_DEPLOY_DO.md` and `docs/CLOUD_SAAS.md`.

Mode	Port	Entry	Use
Appliance	3090	<code>npm start</code>	Site PC / IoT-Link edge
Cloud hub	3090	<code>MOOREVIEW_DEPLOYMENT=ccloud npm start</code>	MQTT Parc ingest, cloud sims

Cloud SaaS	3100	<code>npm run start:saas</code>	Login, tenants, Sites, full Studio
------------	------	---------------------------------	------------------------------------

Quick start — pair a site to cloud

Connect an edge appliance to Cloud Studio for fleet visibility and remote cameras.

On Cloud Studio (`/sites`)

1. Sign in at `/login`
2. Open **Sites** from the nav bar
3. Click **Create site** — enter Site ID, store/name, street address, and optional county
4. Copy the **pairing code** and note the **site ID** and **agent token** shown after creation
5. Optionally open **Devices** → **Assign to site** to link field Optas

On the edge appliance

Telemetry uplink (Parc / MQTT):

1. **Project** → **System setup** → **Cloud remote**
2. Enable uplink
3. Set `tenantId` = your organization slug (e.g. `demo`)
4. Set `gatewayId` = site ID from cloud
5. Broker URL = cloud MQTT (e.g. `mqtt://your.domain:8883`)
6. MQTT username/password = from droplet Mosquitto env
7. Click **Apply all settings**

Remote cameras (site agent):

1. **Tools** → **Cameras** → **Settings** → **Cloud Studio**
2. Enter Cloud URL, Site ID, and Pairing code
3. Click **Save cloud pairing**
4. Agent connects; inventory syncs to cloud automatically

Verify

- Cloud **Sites** table shows **Edge agent: Online**
- **Sites** → **Cameras** lists cameras discovered on the appliance
- **Fleet** map plots sites with county/address set

Login

Appliance (port 3090)

Field	Default value
Email	admin@local

Password	ChangeMeAdmin!
----------	----------------

Operator account (when seeded): `operator@local` (password set in System setup).

- Login page: <http://127.0.0.1:3090/login>
- **Sign out:** Help → Sign out, or top-right Sign out
- Protected routes redirect to `/login` when session expires
- Manage login accounts: **Project** → **System setup** → **Features** tab (admin only)
- **Alarm notifications** are separate from login — configure under **Alarms** → **Notification users**

Change default passwords before production deployment.

Cloud SaaS (port 3100)

Sign in at <https://your-domain/login> (or `http://127.0.0.1:3100/login` locally).

Field	Description
Organization ID	Tenant slug, e.g. demo
Email	User email
Password	User password

Demo accounts (after `npm run seed`):

Role	Organization ID	Email	Password
Operator	demo	operator@demo.local	demo
Platform admin	demo	admin@demo.local	ChangeMeAdmin!

Override seed values with env vars: `MOOREVIEW_SEED_TENANT` , `MOOREVIEW_SEED_ADMIN_EMAIL` , `MOOREVIEW_SEED_ADMIN_PASSWORD` , `MOOREVIEW_SEED_OPERATOR_EMAIL` , `MOOREVIEW_SEED_OPERATOR_PASSWORD` .

Sign out:

Where	How
Studio (/)	Cloud nav bar Sign out , top-right Sign out , or Help → Sign out
Sites, Fleet, CMMS, ...	Top-right Sign out on the Cloud nav bar

New users invited via **People** receive an email invite and set their own password. Sign-in may require an email verification code (platform admin exempt).

Cloud navigation

Area	Path	Purpose
Studio	/	ST program, HMI, tags, drivers, historian

Sites	/sites	Create sites, pair edge appliances, remote cameras
All devices	/sites/devices	Fleet device inventory and site assignment
Assets map	/fleet	Geographic / schematic asset view
People	/people	Tenant user list and invites (admin)
CMMS	/cmms	CMMS entitlement status
Admin	/admin/tenants	Platform tenant admin
Cloud Sims	Tools → Connectivity	Virtual device lab
Cellular Sims	/cellular/sims	SIM vendor inventory

Press **F1** for in-app Help, **F2** for Training.

Site admin — Sites page

Path: **/sites** (Cloud nav → **Sites**)

Create a site

1. Enter **Site ID** (unique identifier, e.g. `7767_Land_0_Lakes_Blvd`)
2. Enter **Store / name** (display label)
3. Enter **Street address** (required for fleet map geocoding)
4. Select **County** (optional — sites with county appear on **Assets map**)
5. Click **Create site**
6. Copy the **pairing code** immediately — it is shown once in the banner

Manage sites

The sites table shows: Site ID, name, address, county, controller status, edge agent status, and camera count.

Action	Purpose
Edit	Update name, address, county
Assign	Open Devices to link field Optas to this site
Cameras	View remote camera inventory for this site
Delete	Remove site (confirm prompt)
Refresh	Reload site list

Repair / re-pair

If the agent token is lost or the site goes offline:

1. Open **Sites** and use **Repair** on the site row (issues new pairing credentials)
2. On the appliance, paste the new pairing code under **Cameras** → **Settings** → **Cloud Studio**
3. Or reconfigure **System setup** → **Cloud remote** with updated gateway ID and broker credentials

Site admin — Devices

Path: `/sites/devices` (Cloud nav → **Devices**)

Assign field Optas and other Parc devices to sites after they check in.

1. Devices that have synced drivers and sent telemetry but are not yet linked show a banner: **"N Opta(s) checked in — Assign to site"**
2. Select a device and assign it to a site
3. Controller column on **Sites** updates to show online/commissioned status

Devices uplink telemetry via MQTT Parc when the appliance or Opta connects to the cloud broker.

Site admin — Remote cameras

Cameras are discovered and probed on the **edge appliance**, not in cloud. Cloud shows inventory synced by the site agent.

Operator flow (cloud)

1. Ensure cameras are configured on the appliance (**Tools** → **Cameras**)
2. Pair the site agent (see Quick start — pair a site)
3. Cloud: **Sites** → **Cameras** for the site
4. Click **Open live** to view stream proxied through the agent (credentials stay on appliance)

Appliance camera quick start (Reolink / ONVIF)

1. Enable **ONVIF** (port 8000) and **RTSP** (port 554) on each camera
2. **Tools** → **Cameras** → **Settings**: set default username/password
3. **Discover ONVIF** → **Probe all**
4. Optional: `npm run go2rtc:download` for H.264 WebRTC streaming

Cloud catalog fields (no passwords): `siteId` , `cameraId` , `name` , `host` , `model` , `probeStatus` , `hasStream` , `viewerPath` , `lastSeenAt` .

Site admin — Cloud remote uplink

On the edge appliance: **Project** → **System setup** → **Cloud remote**

Setting	Value
Enable uplink	On
tenantId	Organization slug from cloud login
gatewayId	Site ID from Sites → Create site
Broker URL	Cloud MQTT (<code>mqtt://your.domain:8883</code>)

MQTT username / password	From droplet Mosquitto env
--------------------------	----------------------------

Click **Apply all settings**. Cloud **Sites** → **Repair** or wait for agent heartbeat to confirm online status.

Note: Modbus RTU and other LAN field buses require an **edge appliance** — cloud cannot reach plant serial ports directly.

Tenant admin — People

Path: **/people** (requires `tenant_admin` or `platform_admin` role)

Invite a user

1. Open **People**
2. Enter email, name, and role (`operator` or `tenant_admin`)
3. Click **Send invite**
4. User receives email, sets password, and may verify email on first sign-in

Manage users

- Edit profile: name, mobile, timezone, password, role
- Configure **alarm contact** settings (email/SMS alerts, contact days/hours) — separate from login
- Platform admin can switch organization via the org selector dropdown

Login accounts and alarm notification contacts are managed separately. Alarm recipients do not need Studio login access.

Platform admin

Path: **/admin/tenants** (requires `platform_admin` role)

Sign in as `admin@demo.local` / `ChangeMeAdmin!` (after seed) or use `PLATFORM_ADMIN_KEY` for API calls.

Task	How
Create organization	Admin → Create organization (org code, name, type)
Enable CMMS	PATCH tenant CMMS flag or Admin UI
Link customer to partner	Admin → Link customer to partner
Invite users to any org	Admin → Invite users on org row, or People with org selector
List all users	<code>/admin/users</code> or People per org
Delete organization	Admin → Edit organization → Delete

Seed environment variables (production)

Variable	Purpose
<code>JWT_SECRET</code>	Session signing

PLATFORM_ADMIN_KEY	Platform admin API key
MONGODB_URI	DO Managed Mongo connection string
PUBLIC_APP_URL	e.g. https://mooreview.io

Roles

Role	Capabilities
operator	Studio, sites read, alarms, acknowledge
tenant_admin	+ tenant user management (People), access matrix
platform_admin	All tenants, admin console, org selector
partner_admin	Partner org staff management
partner_technician	Partner-scoped site access

On the appliance, feature access is controlled per user in **System setup** → **Features** (admin only).

First-time commissioning (appliance)

1. **Drivers** — connect hardware or pick a device template
2. **Tags** — verify I/O mapping, scaling, and alarms
3. **Program** — edit ST, validate, start runtime
4. **Tags** → **Force** — override inputs/outputs while debugging
5. **HMI** — compose screens and bindings; apply settings for live display

Arduino Opta (MQTT Parc) quick start:

1. Flash **MooreviewOptaMqttSt** v2.3.41+ via Arduino IDE; set broker on `/setup`
2. Start Mosquitto on the PC (`npm run mqtt:start`) — broker must listen on **LAN IP**, not only localhost
3. **System setup** → **General** — enable **MQTT Parc hub**, set **broker URL**, enable **Remote ST execution** → **Apply all settings**
4. **Drivers** — template **Arduino Opta — MQTT Parc ST runtime** or **Add Opta Parc devices (bulk)**; `deviceId` must match firmware
5. Restart or wait for telemetry → **Sync tags from device** on the driver card
6. **Program** → **Remote** on → **Download & Start** to deploy and run ST on the Opta

Troubleshooting

Issue	Check
Cannot sign in (cloud)	Org slug matches tenant; user belongs to org; run <code>npm run seed</code> on fresh install
Cannot sign in (appliance)	Default credentials changed? Check System setup → Features user list

Site offline	Agent token, broker URL, firewall 8883/1883, appliance cloud remote enabled
No camera view in cloud	Agent connected; camera probed on appliance; run Sites → Repair
Optas checked in but not on site	Devices → Assign to site
Modbus missing in cloud	Expected — use edge appliance for LAN field buses
BACnet missing in cloud	Expected — BACnet/IP runs on edge appliance
Session expired	Sign out and sign in again; protected routes redirect to /login
Login 502 (production)	Check MONGODB_URI, Mongo allowlist, journalctl -u mooreview-saas

Related documentation

Document	Topic
docs/CLOUD_USER_GUIDE.md	Full cloud operator guide
docs/CLOUD_SAAS.md	SaaS deployment overview
docs/CLOUD_DEPLOY_DO.md	DigitalOcean droplet install
docs/CAMERAS.md	Camera integration and site agent protocol
docs/EST_PC_PARITY.md	Edge vs cloud feature matrix
deploy/appliance/README.md	Appliance install (PC + IoT-Link)
docs/BASELINE_TEST.md	MQTT Parc + Opta baseline test