

sys_clk_n
sys_clk_p
incisvd_0
Vitis™ HLS
Inctsvd_top
risk_0
Risk_matrix
momentum_0
Momentum_signal
clk_wiz_0
Clocking Wizard
const_0
Constant (Discontinued)
const_1
Constant (Discontinued)
rst_0
Processor System Reset
picorv32_0
picorv32_axi_v1_0
axi_ic_0
AXI Interconnect (Discontinued)
axi_bram_ctrl_0
AXI BRAM Controller
regime_0
Regime_classifier
blk_mem_gen_0
Block Memory Generator
lob_0
Lob_filter