VBUS_R_RAW
 ○ TP12 VBUS_R_RAW

 VBUS_R
 ○ TP13 VBUS_R

 +5V_R
 ○ TP14 +5V_R

 +3V3_R
 ○ TP15 +3.3V_R

 GND
 ○ TP16 GND

USB_DET_R

#5V_FAULT_R

TP10 #5V_FAULT_R

BOOT_L O TP3 BOOT_L

BOOT_R O TP11 BOOT_R



