

>> can be flashed directly from the browser.

**b)** Onboard Flasher:

A flasher is built into the System. Wemos D1 can be flashed with our integrated Flashtool found in the Config Menu

QUICKSTART

**VAN PI Dimmy** 

## 2 Assembly

Place the **WEMOS ESP32** on the board. Insert the board and cover into the dimmycase and screw together the cover.

ESP32 to your PC

(www.flashesp.pekaway.de)

## 4 Adjust Tasmota & Webinterface

Search for "PekawayMota" WIFI & connect with it. You will be automatically redirected to the Config page.\* Now enter your Wifi settings from from your VANPI (or from the network which is integrated in the VANPI).

In the webinterface you can name the switches 1-7. Under the switch "Tab" you can now control the dimmers.

\* If this should not work, try it via the IP address: 192.168.4.1

