

QUICKSTART **VAN PI Dimmy** 

Start Chrome Browser, connect Wemos D1/ESP32 to vour PC


>> can be flashed directly from the browser.

(www.flashesp.pekaway.de)

b) Onboard Flasher: A flasher is built into the System. Wemos D1 / ESP32 can be flashed with our integrated Flashtool found in the Config Menu

## 2 Assembly


Place the WEMOS D1/ESP32 on the board. Insert the board and cover into the dimmycase and screw together the cover.



## **3** Accessories & **Power connect**

the fuses!

Now connect 9-16V via the included plug.



In the webinterface you can name the switches 1-7. Under the switch "Tab" you can now control the dimmers.

\* If this should not work, try it via the IP address: 192.168.4.1

## **4** Adjust Tasmota & Webinterface

Search for "PekawayMota" WIFI & connect with it. You will be automatically redirected to the Config page.\* Now enter your Wifi settings from from your VANPI (or from the network which is integrated in the VANPI).