

## Download the image via https://downloads.pekaway.de to your PC. Then load the image to a Micro SD card.

## QUICKSTART VAN PI HAT



3 Assembly \*


Now screw together your RPI model with the case, and secure it with the the spacers. Afterwards screw on the case cover onto the case and screw everything together.\*



\* not necessary for the complete package

**Accessories & connect Power** 

into the card slot of your RPI.



You can connect temperature-& water sensors, measuring shunt and a display to your VAN PI HAT.

5 Hotspot & Webinterface

For configuration your smartphone or tablet has to get connected to the WLAN Hotspot "Vanpi\_Control\_xx " it starts automatically and you have to search for it in your WIFI settings. If you are connected, enter

the address van.pi into your brow-

ser.\*



\* Another way is via the IP address:

192.168.4.1:1880/ui