GPS Signal Processing

Pengluo Wang & Yang Mi

Start with Side Dishes

- Use of GPS in the Gulf War
 - Before the Gulf War, localization is mainly achieved by using fixed landmarks as references.
 - Under severe conditions, landmarks will have great uncertainty, making it hard to locate position accurately.
 - GPS allowed the alliance to know their accurate positions, and also enabled precision strike to the enemies.

One More Side

- Xingxin Gao got scolded by Chinese media because of a paper.
 - She derived Beidou's civil PRN code before it has been released by Chinese government four years later.
- Is she really a traitor, as said by some mainstream?
 - No. It actually helped other scientists analyze Beidou signal characteristics on an early stage, which is beneficial for the development of Beidou.
- How did she derive civil code?
 - Can military code be derived in the same manner?

Outline


- Digital signal processing (DSP) background
 - Signals, modulation, and correlation
- GPS signal structure
 - Carrier wave, pseudorandom code, and navigation message
- Data demodulation
 - Signal acquisition and tracking

DSP Background

Signals, data modulation, and correlation


DSP Background – Signals

• Amplitude




DSP Background – Signals (cont'd)

Frequency




DSP Background – Signals (cont'd)

• Phase




DSP Background – Modulation

- Amplitude Shift Key (ASK)
 - modulate on amplitude
- Frequency Shift Key (FSK)
 - modulate on frequency
- Phase Shift Key (PSK)
 - modulate on phase
- Only one user is allowed for one frequency band.



DSP Background – CDMA

- Code-division multiple access (CDMA) is used for allowing *multiple* users on one frequency band at the same time.
 - Each user has a specific pseudorandom noise (PRN) code for identification.




Reference: https://en.wikipedia.org/wiki/Code-division multiple access

DSP Background – Demodulation of CDMA

- PRN code functions as a key for communication with received signal and the user.
 - Different users have different keys (PRN codes).
 - One door (data modulated for one user) can be only opened by one key.
 - Inserting the key into the door is done by correlation.
- User will generate PRN code locally to correlate with received signal.
 - If signal matches the local PRN code, the correlation will be high.
 - Data information is indicated by the sign (\pm) of correlation result, this process is called data *demodulation*.


DSP Background – Correlation

• Correlation measures the similarity of two signals.



DSP Background – Correlation (cont'd)


Correlation measures the similarity of two signals.



DSP Background – Correlation (cont'd)

Correlation measures the similarity of two signals.

Correlation of sine wave with different frequencies



DSP Background – Correlation (cont'd)

Correlation definition

$$R_{xy}[m] = \sum_{n=-\infty}^{\infty} x[n]y^*[n-m]$$

- Some key points:
 - Random noise r[n] only correlates with itself

$$R_{rr}[m] = \begin{cases} 1, & m = 0 \\ 0, otherwise \end{cases}$$

• The more sinusoid signal frequencies differ, the less their correlation will be.

GPS Signal Structure

Carrier wave, pseudorandom code, and navigation message

GPS Signal Structure

Carrier wave X Navigation message -1X Pseudorandom code $\downarrow \downarrow$ GPS signal (w/o noise)

Carrier Wave

- Sine wave with frequency of 1575.42 MHz.
 - High frequency ensures users to receive accurate data under all weather conditions.
 - High frequency will also lead to strong degradation, thus received signals are rather weak, like the light from a 25W lightbulb shining 20,00 km away.
- Due to Doppler effect, received carrier frequency may be different.
 - The faster the user moves, the bigger the frequency difference will be.
 - Typically Doppler shift (frequency difference) is within \pm 10 kHz.

C/A Code and P code

• Two kinds of *pseudorandom noise* (PRN) codes are modulated.

- Coarse/acquisition (C/A) code with 1023 chips, chip rate 1.023 MHz.
 - Code sequence is open for civil use.
 - Each satellite will have a specific code with a period of $1 \, ms$.
- Precise (P) code with 2.35×10^{14} chips, chip rate 10.23 MHz.
 - The original period of P code is more than half a year, it's been cut to a period of 1 week when broadcast by each satellite.


More on C/A Code and P Code (cont'd)

• Recall Xingxin Gao's work to derive BeiDou C/A code.


- Deriving C/A code sequence is not hard, but
 - it requires a received signal lasting for 50 C/A code period (50 ms).

- Well, using same method for hacking military code, you have to
 - collect signal for almost a year (50 weeks), and
 - gamble that the military encrypted code won't change during that time.

PRN Code – Auto-correlation




PRN Code — Cross-correlation



PRN Code – GPS Signal Correlation

- Signal received by the user is a combination of
 - signals transmitted from different satellites,
 - plus noise caused by receiver, multipath, etc.
- What would be the results if we correlate received signal with different PRN code?
 - Received signal will have signals transmitted by three satellites.
 - PRN1 will have no phase shift, no Doppler (carrier frequency difference).
 - PRN2 will have phase shift, no Doppler.
 - PRN3 will have no phase shift, but Doppler is changing across time.

PRN Code – GPS Signal Correlation (cont'd)



PRN Code – GPS Signal Correlation (cont'd)

- Location of correlation peak indicates code phase shift value.
 - Peak should locate at the center to demodulate data successfully.
 - Need to know initial code phase of received signal to "move" the peak at the center, by generating a local PRN signal with same phase.

- Doppler frequency difference will impact correlation peak amplitude.
 - PRN code is modulated on carrier wave, and a large difference of sine wave frequency or phase will lead to small correlation peak
 - Need to know initial Doppler frequency and phase to ensure a correlation peak with carrier wave.

Navigation Message

- Broadcast at 50 bps.
 - A total of 25 frames, each frame takes 30 seconds to be transmitted.
 - Each satellite transmits its own navigation messages all the time.

Satellite parameters	Contains signal transmission time, SV health status, etc.	Data are updated per 2 hours.
Ephemeris	Contains detailed orbital information for each satellite	Data are updated per 2 hours.
Almanac	Contains inaccurate position over time for <i>all</i> satellites	Data are broadcast across 25 frame and updated every week approximately.

Data Demodulation

Signal acquisition and tracking

GPS Signal Demodulation

- Data modulation can be implemented by correlation.
 - After receiving GPS signal, the user will also generate a local signal with carrier wave and PRN code signal.
 - Sign of the correlation results indicates if the data modulated is 1 or -1.

- For generating suitable local signals, the user needs to know
 - satellite ID (if satellite is visible),
 - carrier frequency (with Doppler shift),
 - initial carrier phase, and
 - initial PRN code phase.


Signal Acquisition

- Satellites have different distance and relative speed w.r.t. user,
 - thus received satellite signals have different carrier/code phase (decided by distance), and difference Doppler shift (decided by relative speed).

- Signal acquisition is a 3D search in the following dimensions:
 - satellite ID (PRN code sequence) ⇒ satellite dimension
 - carrier frequency (with Doppler shift) ⇒ frequency dimension
 - initial PRN code phase ⇒ code dimension

Search Space

• Considering search only in 2D, search in carrier frequency and code.



Reference: Elliott D. Kaplan. Understanding GPS: Principles and Applications. Boston: Artech House, 1996.

Search Space (cont'd)

- Signal acquisition search space:
 - satellite dimension = 31 (total number of GPS satellites)
 - frequency dimension = 41 (if step size = 500 Hz within \pm 10 kHz range)
 - code dimension = 1023 (if step size = 1 chip for C/A code)
 - thus total search space = $31 \times 41 \times 1023$. (It's HUGE!)

- It would be very slow if searching each bin one by one.
 - Doppler and code phase search can be speeded up using FFT.
 - Some prior can be used when searching.

Priors for Signal Acquisition

• With almanac data, the user will know beforehand the visible satellites, thus reducing one dimension for satellite search.

• With ephemeris data, the user could estimate Doppler shift and initial code phase, greatly reducing the remaining 2D search space.

After signal acquisition, almanac is no longer useful.

More on C/A Code and P Code

- For P code the search space at code dimension is 6.18×10^{12} !
 - It's impossible to acquire code phase in real time without any help of prior.
 - The previous search method requires receiving signal for at least one PRN code period. Recall that P code period is one week!

• After tracking using C/A code to obtain current time first, the user can estimate P code phase, reducing the 2D search space.

• That's why C/A code is called **coarse** acquisition code.

Signal Tracking

• After signal acquisition, the user has a rough estimate for Doppler shift and code phase.

 Signal tracking can fine-tune the estimation to an accurate level, and also obtain carrier phase accurately.

- User will track the status of received signal.
 - Adjust the estimation of carrier frequency, carrier phase, and code phase, which may slowly across time.


Tracking Modules

- Frequency-locked loop (FLL) ⇒ tracking carrier frequency
- Phase-locked loop (PLL) ⇒ tracking carrier phase
- Delay lock loop (DLL) ⇒ tracking code phase

• All these lock loops are electronic control systems based on *negative* feedback loop.

Negative Feedback Loop


Negative feedback loop structure



- Discriminator will calculate difference between input and output.
 - Either frequency (FLL), carrier phase (PLL), or code phase (DLL).


Negative Feedback Loop (cont'd)

Negative feedback loop structure




- Loop filter will output a value to control generator.
 - The value is calculated based on previous history.
 - Filter output is the negative of generator's input, hence "negative" feedback.

Negative Feedback Loop (cont'd)




- Generator will generate new output signal based on its input.
 - Taking FLL as an example.
 - If generator input is f_i , and previously the generated signal frequency is f_o .
 - Next time generator will generate new output signal with frequency $f_i + f_o$.

Negative Feedback Loop (cont'd)



- If input and output signal are the same:
 - Discriminator's output will be 0 ($f_I = f_O$).
 - Loop filter's output will be 0 after a short time (considering the filter history).
 - Generator will have zero input ($f_i = 0$), thus keep generating previous output with frequency $f_o = f_i + f_O = f_O$.

FLL




Loop filter output

status: FLL

phase diff: 17.2° freq diff: 100.0Hz

PLL




Loop filter output

status: PLL

phase diff: 17.2° freq diff: 100.0Hz

FLL + PLL




Loop filter output

status: FLL

phase diff: 17.2° freq diff: 100.0Hz

DLL




Demodulation

• PLL and DLL make sure the copied signal has the maximum correlation results with the received signal.

- Data demodulation is then indicated by correlation result.
 - If correlation is above 0, then the data modulated on the signal is +1, otherwise it's -1.

Demodulation



Some Takeaways

• Pseudorandom noise (PRN) code is used for GPS signal modulation.

• C/A code is released for public use and can be easily hacked, but military code is impossible to hack.

 User will generate a local signal matching with signal through signal acquisition and tracking.

Data demodulation is achieved by correlation.

Advertisements • • •



Github for GPS simulation: @PenroseWang/SimGPS



Wechat Official Account: luoxiaoheidebiji



Medium: @penrosewang