



Note: ground plane polygons are not shown in this printout. You will also need to add ground planes to the top and bottom layers.




## Screenshot of finished product, with top layer selected:



## Checklist:


- 2 of the pins in the header are connected to both ground planes. You can see this by the thin tracks coming into the circle from top, bottom, left and right.
- The vias in the middle of the polygons are connected to ground. Again, notice the tracks connecting the vias to the polygons. If you don't see this, make sure your polygons and your vias both have their net set to GND.
- There is a keepout track (pink) around the outside of the board.
- Your name is placed on the top layer (red).

Screenshot of finished product, with bottom layer selected:



• As above, notice the connections to the ground polygon at the header, vias, and many of the components.

## Photo of finished product:



## Photo of underside of PCB:

