



HI

16 × 16 // PENDULUM

01 ■

ROW = PITCH
TOP = HIGHEST NOTE

02 ■

ARMED
WAITS FOR THE CLOCK

03 ■

LEFT WALL
PLAYS ROOT NOTE

04 ■

DOUBLE-TAP
CLEARS THE LANE

05 ■

RIGHT WALL
IN-KEY FIFTH

06 ■

PENDULUM
DECAYS PER HIT

07 ■

SWIPE
WALL + DIRECTION



16 PENDULUM LANES.
SWIPE TO LAUNCH.
WALL HIT = NOTE.



LO

02 SWING RATE

TIME (DEFAULT) – SWIPE SPEED SETS THE RATE.
DIST – REACH FROM THE LAUNCH EDGE SETS IT.

8 PADS = FASTEST

MIRRORED FROM THE RIGHT · 10 CLOCK-SYNCD RATES



AUTHOR PERPLEX ON
PANEL ID perplex_on/pendulum
FIRMWARE BETA
PREFERRED BLOCKS

01 PLAY

SWIPE ≥ 3 PADS
PRESSURE VELO + ENERGY
SWIPE AGAIN RE-LAUNCH
DOUBLE-TAP CLEAR

03 SETTINGS

← SCROLL LEFT FROM PLAY

KEY C – B
SCALE 12 SCALES
OCTAVE –2 ... +2
DAMPING 0 ... 8 · 0 = ∞
RATE SOURCE TIME / DIST

DEFAULTS: OCTAVE 0 · DAMPING 3 · TIME

04 PAGES

0 PLAY PENDULUM GRID
1 SOUND PRESET · XY
2 SAVE/LOAD SONGS

05 SCALES

CHROM	MAJOR	MINOR
DORIAN	PHRYG	LYDIAN
MIXO	LOCRIAN	H.MIN
P.MAJ	P.MIN	BLUES

SETTINGS SAVE GLOBALLY.
SOUND + MIX PRESET TRAVEL WITH THE SONG.



//:001 PLINKY 12

PENDULUM