
PM30AS 馬達安裝配件包

滑塊安裝於右側(注2)

I■AR24SAK-1馬達 CVK525AK馬達共用




MCE-0001

X1

馬達護蓋

PM30S1□SENSOR配件包

I■型號範例:PM30S1L或PM30S1R



PM30左SENSOR配件包

PM30S1L


SENSOR固定板X1 DOG片 X1 PM-R25 X1 SFB-0003 X1 SDB-0002 X1 PM-R25 X1

PM30右SENSOR配件包

PM30S1R

SENSOR固定板X1 DOG片 X1 PM-R25 X1 SFB-0003 X1 SDB-0021 X1 PM-R25 X1

PM50□S馬達安裝配件包



PM50馬達配件包

PM50AS

 聯軸器
 X1

 (塔配馬達孔位AR66SAK-1)
 X4

 馬達法蘭片
 X1


MCP-251010 X1 MPR-0001 X4 MFB-0002 X1

注1:聯軸器會依照模組的馬達規格尺寸搭配製作 注2:圖示配件包,不含金具與相關滑台 PM50CS

 MCP-251008 X1 MPR-0001 X4 MFB-0002 X1

PM□0S2□ SENSOR配件包





PM70左SENSOR配件包

PM70S2L

SENSOR固定板X1	E
SENSOR調整板X1	3
DOG片 X1	K
PM-R25 X1	ľ
PM-F25 X1	ľ

SFB-0001	X1
SRB-0001	X1
SDB-0019	X1
PM-R25	X1
PM-F25	X1

PM70右SENSOR配件包

PM50右SENSOR配件包

PM70S2R

2FM2OK回注	E 极XI
SENSOR調整	を板X1
DOG片	X1
PM-R25	X1
PM-F25	X1

SFB-0001	X1
SRB-0001	X1
SDB-0020	X1
PM-R25	X1
PM-F25	X1

PM50左SENSOR配件包

PM50S2L

SENSOR固定	板X1
SENSOR調整	板X1
DOG片	X1
PM-R25	X1
PM-F25	X1

SFB-0001	X1
SRB-0001	X1
SDB-0003	X1
PM-R25	X1
PM-F25	X1

PM50S2R

SENSOR固定	板X1
SENSOR調整	板X1
DOG片	X1
PM-R25	X1
PM-F25	X1

X1 X1 X1 X1
X1