

Note:

Drill 18 1/4" holes evenly spaced in top half of pipe each side of the tee (6 groups of 3 @ 9, 12 and 3 o'clock). Cover perforated pipe with geofabric drainage sock.