

Technics

Stereo Integrated Amplifier  
SU-A700MK2  
SU-A600MK2

Operating Instructions



The photograph shows the SU-A700MK2 model.

The configuration of the ventilation holes differs according to area.

**Note:**

The "EB" indication shown on the packing case indicates United Kingdom.

Before operating this unit, please read these instructions completely.

E EB EO GC GN

RQT2384-B

# Dear Customer

Thank you for purchasing this Technics product.  
For optimum performance and safety, please read  
these instructions carefully.

These operating instructions are applicable to the SU-A700MK2 and SU-A600MK2 models.

These operating instructions, however, fundamentally explain the operation of SU-A700MK2 model.

Furthermore, the differences between the SU-A700MK2 and SU-A600MK2 are as shown in the table below.

(○ = included, × = not included)

	SU-A700MK2	SU-A600MK2
Remote control transmitter	○	×
Batteries	○	×



Please check and identify the supplied accessories

<input type="checkbox"/> AC power supply cord..... <b>(For United Kingdom)</b>	1
<input type="checkbox"/> Power plug adaptor (SJP5213-2). (Not supplied for United Kingdom, Europe, Australia and N.Z.)	1
<input type="checkbox"/> Remote control transmitter (RAK-SU129WH) <b>SU-A700MK2 only</b>	1
<input type="checkbox"/> Batteries (UM-4, "AAA", R03) <b>SU-A700MK2 only</b>	2

# Contents

<b>Caution for AC mains lead</b>	<b>3</b>
<b>(For United Kingdom)</b>	<b>3</b>
<b>Suggestions for safety</b>	<b>4</b>
<b>Front panel controls</b>	<b>5</b>
<b>Connections</b>	<b>6</b>

<b>Listening to Sound</b>	<b>8</b>
---------------------------	----------

To adjust the tone quality .....	9
To adjust the sound balance .....	9
When listening through headphones.....	9

<b>Recording</b> .....	<b>10</b>
------------------------	-----------

To record from compact discs, etc.....	10
Tape-to-tape recording.....	10

<b>Technical specifications</b> .....	<b>11</b>
---------------------------------------	-----------

<b>Troubleshooting guide</b> .....	<b>Back cover</b>
------------------------------------	-------------------

(For areas except United Kingdom, Europe, Australia and N.Z.)

## CAUTION:

The AC voltage is different according to the area.

Be sure to set the proper voltage in your area before use.

(For details, please refer to the page 7.)