
Supreme Edition S8 Controls



Browse Mode (Enabled in Browser View)

Remix Mode (Enabled when you hold **Remix** Button)


Modify Remix Capture Source on current Remix Deck

Turn

Turn

Browse through your favourite playlists

Supreme Edition Screen & Pads



Loop Roll	Loop Roll	Loop Roll	Loop Roll
BeatJump	BeatJump	BeatJump	BeatJump

Sizes set in Traktor Settings —> S8 Settings

Loop Roll Mode

Loop Roll	Loop Roll	Loop Roll	Loop Roll	
1/16 Beat	1/8 Beat	1/4 Beat	1/2 Beat	
Loop Roll	Loop Roll	Loop Roll	Loop Roll	
Loop Roll 1 Beat	Loop Roll 2 Beats	Loop Roll 4 Beats	Loop Roll 8 Beats	

Remix Mode

Trigger/Capture/	Trigger/Capture/	Trigger/Capture/	Trigger/Capture/
Load Sample	Load Sample	Load Sample	Load Sample
Stop + Delete	Stop + Delete	Stop + Delete	Stop + Delete
Pattern/ Delete	Pattern/ Delete	Pattern/ Delete	Pattern/ Delete
Sample (Shift)	Sample (Shift)	Sample (Shift)	Sample (Shift)
Slot Selector	Slot Selector	Slot Selector	Slot Selector
Mute Player (Shift)	Mute Player (Shift)	Mute Player (Shift)	Mute Player (Shift)

Capture: A Loop Sample of N beats (the Loop Size of the deck will be captured from TrackDeck X/LoopRecorder when an empty cell is pressed and you are not in Browser Mode.

Load: If you are in Browser Mode and you press an empty cell, the currrently selected track/sample will be loaded to that cell.

Sequencer Mode

Enable Step X	Enable Step X	Enable Step X	Enable Step X
Edit Steps 1-8 Slot 1 (Shift)	Edit Steps 1-8 Slot 2 (Shift)	Edit Steps 1-8 Slot 3 (Shift)	Edit Steps 1-8 Slot 4 (Shift)
Enable Step X	Enable Step X	Enable Step X	Enable Step X