Table 32-5. Extended Fuse Byte for ATmega328PB

0

BODLEVELO⁽¹⁾

| Extended Fuse Byte | Bit No. | Description | Default Value |
|--------------------------|---------|----------------------------------|-----------------------------|
| _ | 7 | _ | 1 |
| _ | 6 | _ | 1 |
| _ | 5 | _ | 1 |
| _ | 4 | _ | 1 |
| CFD | 3 | Disable Clock Failure Detection | 0 (programmed, CFD disable) |
| BODLEVEL2 ⁽¹⁾ | 2 | Brown-out Detector trigger level | 1 (unprogrammed) |
| BODLEVEL1 ⁽¹⁾ | 1 | Brown-out Detector trigger level | 1 (unprogrammed) |

Brown-out Detector trigger level

1 (unprogrammed)