First class 1 Reset after overheating



If the machine is not freezing and the red light next to the main green power switch is lit, then you will need to reset the thermal cut out.

This button is located on the right hand side of the machine just in front of the back foot. You can reach your hand under the back of the machine between the bench and the machine base to operate the button. Push up.



If the machine has overheated it is important to ensure this doesn't happen again or serious damage may occur.

Ensure there is nothing blocking the ventilation grills around the outside of the machine such as advertising, menus, cups or glasses, etc.

Ensure the machine has the minimum clearance around the outside as indicated in diagram 5.

If operating in hot environments even more space and airflow is required.



Ensure the back of the machine is clear from dust and lint, it should be spotlessly clean.

If there is a build-up of dirt and lint remove the back cover by undoing the two screws at the base.



The cooling condenser can also be cleaned using a vacuum, dish brush or even better a compressor blasting air through the condenser.



0800264948

info@blendz.co.nz