

WI-3300 Final Assembly and Pack-Out

Sub-Assembly

1. Retrieve the pre-tested control module from the burn-in rack and verify the green pass label is present and legible.
2. Seat the module into the lower chassis until both retention tabs engage. A distinct click confirms engagement on each side.
3. Connect the ribbon cable to J4. Ensure the blue stripe faces the front of the chassis; a reversed cable will not damage the board but the unit will fail functional test.
4. Apply the ESD-safe foam pad over the module. The pad must lie flat with no folded corners.

Enclosure Close-Out

5. Lower the top cover onto the chassis at a slight angle, engaging the rear hooks first, then rotating the front down until flush.
6. Install the four cover screws to 2.0 Nm using the yellow-handled driver. Do not substitute another driver.
7. CAUTION: A pinched cable at the rear hinge is the most common defect at this station. Visually confirm cable clearance before installing the final screw.
8. Wipe the enclosure with the approved anti-static cloth to remove fingerprints.

Test and Pack

9. Place the unit on the functional test fixture and start the cycle. The cycle runs for approximately ninety seconds.
10. On a pass result, apply the serialised QC label to the rear panel in the outlined location.
11. On a fail result, place the unit in the red rework bin and log the failure code shown on the fixture display. Do not attempt to retest.
12. Pack the unit with the accessory bag and desiccant pouch, then seal the carton with two strips of tape across the centre seam.