

WI-2210 Harness Routing and Clip Install

Scope

This instruction covers routing of the main wiring harness from the control module to the front sensor cluster on all production variants.

Procedure

Step 1 Remove the harness from the kitting bin and inspect the connectors for bent or recessed pins.

Step 2 Route the harness along the upper rail, keeping the branch labelled SENSOR-A on the outboard side.

Step 3 Install the P-clips at the three marked locations. Each clip must click audibly when seated.

Step 4 CAUTION: Maintain a minimum 25 mm clearance between the harness and the exhaust shield at all points.

Step 5 Mate both connectors and confirm the locking tab is fully engaged by pulling lightly on the connector body.