

GETTING LOST IN CANADA

Checklists

Quick checklists, refer to howto for more details

Table of Contents

Checklist: Arriving at Campsite	3
Checklist: Leaving Campsite	5

Checklist: Arriving at Campsite

Work through these in order when you pull into a site. The goal is a level, powered, watered van with the awning out and the campsite scouted before you settle in.

Park & level

- ☐ Park the van, be mindful of the door, awning and neighbors
- ☐ Level front-to-back and side-to-side, adding leveling blocks under the wheels as needed
- ☐ Set the parking brake and chock the wheels
- ☐ Shut off the engine

Power

- ☐ If the site has an electrical pedestal, switch its breaker off, connect the shore-power cable, then switch the breaker on
- ☐ Confirm power is live inside (lights, outlets)
- ☐ No hookup? You are on the house batteries or generator — remember the Truma Aventa eco AC needs 120 VAC (shore or generator) and will not start on battery alone

Water

- ☐ If the site has a water tap, connect a potable hose through a pressure regulator to the city-water inlet
- ☐ Otherwise, confirm the fresh-water tank is filled for your stay
- ☐ Turn on the water pump and run a tap until it flows clear and steady
- ☐ For hot water, switch on the Truma Combi (gas, electric, or mix) and give it time to heat

Climate

- ☐ Confirm the Truma CP plus is set to external control so the Garmin panel can drive it
- ☐ On the Garmin: Temperature control → Auto → set your target temperature
- ☐ Open a roof vent or windows for airflow as needed

Outside setup

- ☐ Extend the Carefree Eclipse awning (left toggle ON, press Extend) — keep an eye on it while it moves

- ☐ Set out chairs, mat, and table
- ☐ Scout the site: washrooms, water tap, garbage and recycling, and the dump station

Checklist: Leaving Campsite

Work through these before you pull out. The goal is a secured interior, everything disconnected and stowed, tanks handled, and a clean site behind you.

Inside

- ☐ Wash up and stow all loose items — nothing left on counters
- ☐ Close and latch every cabinet, drawer, the fridge, and the roof vents
- ☐ Secure electronics, and close all windows
- ☐ Switch off the water pump and the Truma Combi water heater
- ☐ Set climate control off (or to its travel setting)

Water & tanks

- ☐ Disconnect and drain the fresh-water hose, then stow it
- ☐ If connected, dump the gray (and black, if equipped) tank at the dump station, rinse, and stow the sewer hose
- ☐ Close all tank valves

Power

- ☐ Switch off the pedestal breaker, disconnect the shore-power cable, and stow it
- ☐ Confirm the van is running on house batteries for travel

Outside

- ☐ Retract the Carefree Eclipse awning (left toggle ON, press Retract) — watch it close and lock fully
- ☐ Stow chairs, mat, table, and any outdoor gear
- ☐ Remove the wheel chocks and leveling blocks

Final walk-around

- ☐ Walk the full perimeter: awning locked, step in, nothing left plugged in or hanging
- ☐ Check overhead clearance for branches before pulling out
- ☐ Leave the site clean — pack out all garbage and make sure any fire is cold to the touch
- ☐ Release the parking brake and go